C2132

User's Guide

April 2013 **www.lexmark.com**

Machine type(s):

5027

Model(s):

639

Contents

Safety information....10

Learning about the printer....12

Finding information about the printer....12
Selecting a location for the printer....13
Printer configurations....14
Using the Embedded Web Server....15

Understanding the printer control panel....17

Using the printer control panel....17
Understanding the colors of the Sleep button and indicator lights....17
Understanding the home screen....18
Using the touch-screen buttons....19

Setting up and using the home screen applications....21

Finding the IP address of the computer....21
Accessing the Embedded Web Server....22
Customizing the home screen....22
Activating the home screen applications....22
Finding information about the home screen applications....22
Using Background and Idle Screen....23
Setting up Forms and Favorites....23
Understanding Eco-Settings....24
Exporting and importing a configuration....24

Additional printer setup....26

Installing internal options....26
Available internal options....26
Accessing the controller board....26
Installing a memory card....29
Installing an optional card....31
Installing a printer hard disk....32
Removing a printer hard disk....34
Installing hardware options....36
Order of installation....36
Installing optional trays....36
Setting up the printer software....39

Installing the printer software 39
Updating available options in the printer driver 39
Attaching cables 40
Networking 41
Preparing to set up the printer on an Ethernet network 41
Installing the printer on an Ethernet network 42
Preparing to set up the printer on a wireless network 43
Connecting the printer using the Wireless Setup Wizard 44
Connecting the printer to a wireless network using Wi-Fi Protected Setup 45
Connecting the printer to a wireless network using the Embedded Web Server 46
Verifying printer setup 46
Printing a menu settings page 46
Printing a network setup page 47

Loading paper and specialty media 48

Setting the paper size and type 48
Configuring Universal paper settings 48
Loading the 250- and 550-sheet tray 48
Loading the multipurpose feeder 52
Loading the manual feeder 54
Linking and unlinking trays 56
Linking and unlinking trays 56
Creating a custom name for a paper type 56
Assigning a custom paper type 57

Paper and specialty media guide 58

Using specialty media 58
Tips on using letterhead 58
Tips on using transparencies 60
Tips on using envelopes 60
Tips on using labels 60
Tips on using card stock 61
Paper guidelines 61
Paper characteristics 61
Unacceptable paper 62
Selecting paper 62
Selecting preprinted forms and letterhead 63
Using recycled paper and other office papers 63
Storing paper 64
Supported paper sizes, types, and weights 64
Supported paper sizes 64
Supported paper types and weights 66

Printing.....68
Printing forms.....68
Printing a document.....68
Printing a document.....68
Printing in black and white.....68
Adjusting toner darkness.....69
Using Max Speed and Max Yield.....69
Printing from a flash drive or mobile device.....70
Printing from a flash drive.....70
Supported flash drives and file types.....71
Printing from a mobile device.....71
Printing confidential and other held jobs.....72
Storing print jobs in the printer.....72
Printing confidential and other held jobs.....72
Printing information pages.....73
Printing a font sample list.....73
Printing a directory list.....73
Canceling a print job.....74
Canceling a print job from the printer control panel.....74
Canceling a print job from the computer.....74

Understanding the printer menus.....75
Menus list.....75
Supplies menu.....76
Paper menu.....77
Default Source menu.....77
Paper Size/Type menu.....77
Configure MP menu.....80
Substitute Size menu.....80
Paper Texture menu.....80
Paper Weight menu.....82
Paper Loading menu.....84
Custom Types menu.....85
Custom Names menu.....85
Universal Setup menu.....85
Reports menu.....86
Reports menu.....86
Network/Ports menu.....87
Active NIC menu.....87
Standard Network or Network [x] menu.....87
Reports menu.....88

Network Card menu....89
TCP/IP menu....89
IPv6 menu....90
Wireless menu....91
AppleTalk menu....92
Standard USB menu....92
SMTP Setup menu....94
Security menu....95
Miscellaneous Security Settings menu....95
Confidential Print menu....95
Disk Wiping menu....96
Security Audit Log menu....97
Set Date and Time menu....97
Settings menu....98
Setup menu....98
General Settings....100
Flash Drive....108
Print Settings....110
Help menu....122

Saving money and the environment....123

Saving paper and toner....123
Using recycled paper....123
Conserving supplies....123
Saving energy....124
Using Eco-Mode....124
Reducing printer noise....124
Adjusting Sleep mode....125
Using Hibernate Mode....126
Setting Hibernate Timeout....126
Using Schedule Power Modes....127
Adjusting the brightness of the display....127
Recycling....128
Recycling Lexmark products....128
Recycling Lexmark packaging....128
Returning Lexmark cartridges for reuse or recycling....128

Securing the printer....130

Using the security lock feature....130
Statement of Volatility....130
Erasing volatile memory....131
Erasing non-volatile memory....131

Erasing printer hard disk memory....132
Finding printer security information....132
Configuring printer hard disk encryption....133

Maintaining the printer....134

Cleaning the printer parts....134
Cleaning the printer....134
Checking the status of supplies....134
Checking the status of parts and supplies on the printer control panel....134
Checking the status of parts and supplies from the Embedded Web Server....134
Estimated number of remaining pages....135
Ordering supplies....135
Using genuine Lexmark parts and supplies....135
Ordering toner cartridges....135
Ordering imaging kits....136
Ordering a waste toner bottle....136
Storing supplies....136
Replacing supplies....137
Replacing the waste toner bottle....137
Replacing a black and color imaging kit....140
Replacing toner cartridges....148
Replacing a developer unit....150
Moving the printer....157
Before moving the printer....157
Moving the printer to another location....157
Shipping the printer....157

Managing the printer....158

Finding advanced networking and administrator information....158
Checking the virtual display....158
Checking the printer status....158
Viewing reports....158
Configuring supply notifications from the Embedded Web Server....159
Modifying confidential print settings....159
Copying printer settings to other printers....160
Restoring factory default settings....160

Clearing jams....161

Avoiding jams....161
Understanding jam messages and locations....162

[x]-page jam, clear standard bin....163
[x]-page jam, open front door to clear fuser....164
[x]-page jam, open front door....165
[x]-page jam, open front door to clear duplex....166
[x]-page jam, open tray [x]....168
[x]-page jam, clear manual feeder....169
[x]-page jam, clear multipurpose feeder....169

Troubleshooting....172

Understanding the printer messages....172
Adjusting color....172
Change [paper source] to [custom type name]....172
Change [paper source] to [custom string]....172
Change [paper source] to [paper type] [paper size]....172
Close door....172
[Color] cartridge low [88.xy]....173
[Color] cartridge very low, [x] estimated pages remain [88.xy]....173
[Type] imaging kit low [84.xy]....173
[Type] imaging kit nearly low [84.xy]....173
[Type] imaging kit very low, [x] estimated pages remain [84.xy]....173
Complex page, some data may not have printed [39]....173
Configuration change, some held jobs were not restored [57]....174
Defective flash detected [51]....174
Error reading USB drive. Remove USB.....174
Error reading USB hub. Remove hub.....174
Incompatible tray [x] [59]....174
Incorrect paper size, open [paper source] [34]....174
Insert Tray [x]....175
Insufficient memory for Flash Memory Defragment operation [37]....175
Insufficient memory, some Held Jobs were deleted [37]....175
Insufficient memory to collate job [37]....175
Insufficient memory to support Resource Save feature [35]....175
Insufficient memory, some held jobs will not be restored [37]....175
Load [paper source] with [custom type name]....176
Load [paper source] with [custom string]....176
Load [paper source] with [paper size]....176
Load [paper source] with [paper type] [paper size]....176
Load Manual Feeder with [custom string]....177
Load Manual Feeder with [custom type name]....177
Load Manual Feeder with [paper size]....177
Load Manual Feeder with [paper type] [paper size]....177
Maintenance kit low [80.xy]....177
Maintenance kit nearly low [80.xy]....178

Maintenance kit very low [80.xy] 178
Memory full [38] 178
Network [x] software error [54] 178
Not enough free space in flash memory for resources [52] 178
Non-Lexmark [color] [supply type], see User's Guide [33.xy] 178
PPDS font error [50] 179
Reinstall missing or unresponsive [color] cartridge [31.xy] 179
Reinstall missing or unresponsive [type] imaging kit [31.xy] 179
Reload printed pages in Tray [x] 180
Remove packaging material, [area name] 180
Remove paper from standard output bin 180
Replace [color] cartridge, 0 estimated pages remain [88.xy] 180
Replace [color] cartridge, printer region mismatch [42.xy] 180
Replace [type] imaging kit, 0 estimated pages remain [84.xy] 180
Replace defective [color] cartridge [31.xy] 181
Replace defective [type] imaging kit [31.xy] 181
Replace maintenance kit, 0 estimated pages remain [80.xy] 181
Replace missing [color] cartridge [31.xy] 181
Replace missing [type] imaging kit [31.xy] 181
Replace waste toner bottle [82.xy] 181
Replace unsupported [color] cartridge [32.xy] 181
Replace unsupported [type] imaging kit [32.xy] 182
Replace missing waste toner bottle [82.xy] 182
Restore held jobs? 182
SMTP server not set up. Contact system administrator. 182
Some held jobs were not restored 182
Standard network software error [54] 182
Standard USB port disabled [56] 182
Supply needed to complete job 183
Too many flash options installed [58] 183
Too many trays attached [58] 183
Unformatted flash detected [53] 183
Waste toner bottle nearly full [82.xy] 184
Weblink server not set up. Contact system administrator. 184
Solving printer problems 184
Basic printer problems 184
Hardware and internal option problems 186
Paper feed problems 188
Solving home screen applications problems 190
An application error has occurred 190
Solving print problems 191
Printing problems 191
Print quality problems 198
Color quality problems 215

FAQ about color printing 215
Prints on color transparencies appear dark when projected 217
The color of the print does not match the color of the original file 218
The print appears tinted 218
Embedded Web Server does not open 218
Contacting customer support 220

Notices 221
Product information 221
Edition notice 221
Power consumption 226

Index 235

Safety information

Connect the power cord to a properly grounded electrical outlet that is near the product and easily accessible.

Do not place or use this product near water or wet locations.

CAUTION—POTENTIAL INJURY: This product uses a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION—POTENTIAL INJURY: The lithium battery in this product is not intended to be replaced. There is a danger of explosion if a lithium battery is incorrectly replaced. Do not recharge, disassemble, or incinerate a lithium battery. Discard used lithium batteries according to the manufacturer's instructions and local regulations.

This product uses a printing process that heats the print media, and the heat may cause the media to release emissions. You must understand the section in your operating instructions that discusses the guidelines for selecting print media to avoid the possibility of harmful emissions.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—POTENTIAL INJURY: To reduce the risk of equipment instability, load each tray separately. Keep all other trays closed until needed.

CAUTION—TIPPING HAZARD: Floor-mounted configurations require additional furniture for stability. You must use either a printer stand or printer base if you are using multiple input options. If you purchased a printer with a similar configuration, then you may need additional furniture. For more information, see **www.lexmark.com/multifunctionprinters**.

CAUTION—POTENTIAL INJURY: Before moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the electrical outlet.
- Disconnect all cords and cables from the printer before moving it.
- Lift the printer off the optional tray, and then set it aside instead of trying to lift the tray and printer at the same time.

  Note: Use the handholds located on both sides of the printer to lift it.

Use only the power cord provided with this product or the manufacturer's authorized replacement.

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

CAUTION—SHOCK HAZARD: Make sure that all external connections (such as Ethernet and telephone system connections) are properly installed in their marked plug-in ports.

This product is designed, tested, and approved to meet strict global safety standards with the use of specific manufacturer's components. The safety features of some parts may not always be obvious. The manufacturer is not responsible for the use of other replacement parts.

CAUTION—POTENTIAL INJURY: Do not cut, twist, bind, crush, or place heavy objects on the power cord. Do not subject the power cord to abrasion or stress. Do not pinch the power cord between objects such as furniture and walls. If any of these things happen, a risk of fire or electrical shock results. Inspect the power cord regularly for signs of such problems. Remove the power cord from the electrical outlet before inspecting it.

Refer service or repairs, other than those described in the user documentation, to a service representative.

CAUTION—SHOCK HAZARD: Do not set up this product or make any electrical or cabling connections, such as the fax feature, power cord, or telephone, during a lightning storm.

CAUTION—SHOCK HAZARD: To avoid the risk of electrical shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.

SAVE THESE INSTRUCTIONS.

Learning about the printer

Finding information about the printer

What are you looking for?	Find it here
Initial setup instructions: • Connecting the printer • Installing the printer software	Setup documentation—The setup documentation came with the printer and is also available at **http://support.lexmark.com**.
Additional setup and instructions for using the printer: • Selecting and storing paper and specialty media • Loading paper • Configuring printer settings • Viewing and printing documents and photos • Setting up and using the printer software • Configuring the printer on a network • Caring for and maintaining the printer • Troubleshooting and solving problems	*User's Guide* and *Quick Reference Guide*—The guides are available on the *Documentation* CD. For more information, visit **http://support.lexmark.com**.
Instructions for: • Connecting the printer to an Ethernet network • Troubleshooting printer connection problems	*Networking Guide*—Open the *Software* CD, and then look for *Printer and Software Documentation* under the Pubs folder. From the list of publications, click the **Networking Guide** link.
Help using the printer software	Windows or Mac Help—Open a printer software program or application, and then click **Help**. Click to view context-sensitive information. **Notes:** • Help is automatically installed with the printer software. • The printer software is located in the printer program folder or on the desktop, depending on your operating system.

What are you looking for?	Find it here
The latest supplemental information, updates, and customer support: • Documentation • Driver downloads • Live chat support • E-mail support • Voice support	Lexmark Support Web site—http://support.lexmark.com **Note:** Select your country or region, and then select your product to view the appropriate support site. Support telephone numbers and hours of operation for your country or region can be found on the Support Web site or on the printed warranty that came with your printer. Record the following information (located on the store receipt and at the back of the printer), and have it ready when you contact customer support so that they may serve you faster: • Machine Type number • Serial number • Date purchased • Store where purchased
Warranty information	Warranty information varies by country or region: • **In the U.S.**—See the Statement of Limited Warranty included with this printer, or at http://support.lexmark.com. • **In other countries and regions**—See the printed warranty that came with your printer.

Selecting a location for the printer

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

When selecting a location for the printer, leave enough room to open trays, covers, and doors. If you plan to install any options, then leave enough room for them also. It is important to:

- Set up the printer near a properly grounded and easily accessible electrical outlet.
- Make sure airflow in the room meets the latest revision of the ASHRAE 62 standard or the CEN Technical Committee 156 standard.
- Provide a flat, sturdy, and stable surface.
- Keep the printer:
  - Clean, dry, and free of dust.
  - Away from stray staples and paper clips.
  - Away from the direct airflow of air conditioners, heaters, or ventilators.
  - Free from direct sunlight and humidity extremes.
- Observe the recommended temperatures and avoid fluctuations:

Ambient temperature	15.6 to 32.2°C (60 to 90°F)
Storage temperature	1 to 35°C (34 to 95°F)

- Allow the following recommended amount of space around the printer for proper ventilation:



1	Right side	102 mm (4 in.)
2	Front	508 mm (20 in.)
3	Left side	152 mm (6 in.)
4	Rear	102 mm (4 in.)
5	Top	254 mm (10 in.)

Printer configurations

CAUTION—TIPPING HAZARD: Floor-mounted configurations require additional furniture for stability. You must use either a printer stand or printer base if you are using multiple input options. If you purchased a printer with a similar configuration, then you may need additional furniture. For more information, see **www.lexmark.com/multifunctionprinters**.



1	Printer control panel
2	Standard bin
3	250-sheet tray (Tray 1)
4	Manual feeder
5	Optional 650-sheet duo tray with integrated multipurpose feeder (Tray 2) **Note:** This tray is standard on the CS410dtn and CS510dte models.
6	Optional 550-sheet tray (Tray 3)

Using the Embedded Web Server

Note: This feature is available only in network printers or printers connected to print servers.

If the printer is installed on a network, then you can use the Embedded Web Server to do the following:

- View the virtual display of the printer control panel.
- Check the status of the printer supplies.
- Configure supply notifications.
- Configure printer settings.
- Configure network settings.
- View reports.

To access the Embedded Web Server for your printer:

1. Obtain the printer IP address:
   - From the TCP/IP section in the Network/Ports menu
   - By printing a network setup page or menu settings page, and then finding the TCP/IP section

     Notes:

     - An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Open a Web browser, and then type the printer IP address in the address field.

3 Press **Enter**.

The Embedded Web Server page appears.

Understanding the printer control panel

Using the printer control panel



	Use the	To
1	Display	• Show the status of the printer. • Set up and operate the printer.
2	Home button	Go to the home screen.
3	Keypad	Enter numbers, letters, or symbols on the printer.
4	Sleep button	Enable Sleep mode or Hibernate mode. **Notes:** • Pressing any hard button, touching the printer control panel, attaching a device to a USB port, sending a print job, or performing a power-on reset with the main power switch wakes the printer from Sleep mode. • Pressing the Sleep button or the power switch causes the printer to wake from Hibernate Mode.
5	Stop or Cancel button	Stop all printer activity.
6	Indicator light	Check the status of the printer.
7	USB port	Connect a USB a flash drive to the printer. **Note:** Only the front USB port supports flash drives.

Understanding the colors of the Sleep button and indicator lights

The colors of the Sleep button and indicator lights on the printer control panel signify a certain printer status or condition.

Indicator light	Printer status
Off	The printer is off or in Hibernate mode.
Blinking green	The printer is warming up, processing data, or printing.
Solid green	The printer is on, but idle.
Blinking red	The printer requires user intervention.

Sleep button light	Printer status
Off	The printer is off, idle or in Ready state.
Solid amber	The printer is in Sleep mode.
Blinking amber	The printer is entering or waking from Hibernate mode.
Blinking amber for 0.1 second, then goes completely off for 1.9 seconds in a slow, pulsing pattern	The printer is in Hibernate mode.

Understanding the home screen

When the printer is turned on, the display shows a basic screen, referred to as the home screen. Use the home screen buttons and icons to initiate an action.

Note: Your home screen may vary depending on your home screen customization settings, administrative setup, and active embedded solutions.

Touch		To
1	Change Language	Change the primary language of the printer.
2	Bookmarks	Create, organize, and save a set of bookmarks (URLs) into a tree view of folders and file links. **Note:** The tree view does not include bookmarks created within Forms and Favorites, and the ones in the tree are not usable in Forms and Favorites.
3	Held Jobs	Display all current held jobs.
4	USB	View, select, or print photos and documents from a flash drive. **Note:** This icon appears only when you return to the home screen while a memory card or flash drive is connected to the printer.

Touch		To
5	Menus	Access printer menus. **Note:** These menus are available only when the printer is in ready state.
6	Status message bar	• Show the current printer status such as **Ready** or **Busy**. • Show the status of printer supplies. • Show intervention messages and the instructions on how to clear them.
7	Status/Supplies	• Show a printer warning or error message whenever the printer requires intervention to continue processing. • View more information on the printer warning or message, and on how to clear it.
8	Tips	View a context-sensitive help information.

This may also appear on the home screen:

Touch	To
Search Held Jobs	Search current held jobs.
Jobs by user	Access print jobs saved by user.
Profiles and Solutions	Access profiles and solutions.

Features

Feature	Description
Attendance message alert	If an attendance message affects a function, then this icon appears and the red indicator light blinks.
Warning	If an error condition occurs, then this icon appears.
Printer IP address Example: **123.123.123.123**	The IP address of your printer is located at the top left corner of the home screen and appears as four sets of numbers separated by periods. You can use the IP address when accessing the Embedded Web Server to view and remotely configure printer settings even when you are not physically near the printer.

Using the touch-screen buttons

Note: Your home screen may vary, depending on your home screen customization settings, administrative setup, and active embedded solutions.



	Touch the	To
1	Radio button	Select or clear an item.
2	Up arrow	Scroll up.
3	Down arrow	Scroll down.
4	Accept button	Save a setting.
5	Cancel button	• Cancel an action or a selection. • Return to the previous screen.

Touch	To
	Return to the home screen.
	Open a context-sensitive Help dialog on the printer control panel.
	Scroll to the left.
	Scroll to the right.

Setting up and using the home screen applications

Notes:

- Your home screen may vary depending on your home screen customization settings, administrative setup, and active embedded applications. Some applications are supported only in select printer models.
- There may be additional solutions and applications available for purchase. To learn more, visit **www.support.lexmark.com** or inquire at your point of purchase.

Finding the IP address of the computer

Note: Make sure that you know how your printer and computer are connected to the network (Ethernet or wireless).

The computer IP address is required when setting up home screen applications, such as:

- Forms and Favorites
- Multi Send
- Scan to Network

For Windows users

1. Open the command window.

   #### In Windows 8

   From the Search charm, type **run**, and then navigate to:

   Apps list > **Run** > type **cmd** > **OK**

   #### In Windows 7 or earlier

   a. Click or click **Start**, and then click **Run**.

   b. In the Start Search or Run dialog, type **cmd**.

   c. Press **Enter**, or click **OK**.

2. Type **ipconfig**, and then click **Go** or press **Enter**.

   Note: Type **ipconfig /all** to see additional useful information.

3. Look for **IP Address**.

   The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

For Macintosh users

Note: This is applicable only in Mac OS X version 10.5 or later.

1. From the Apple menu, navigate to:

   System Preferences > **Network**

2. Click **Ethernet**, **Wi-Fi**, or **AirPort**.

3 Click **Advanced** > **TCP/IP**.

4 Look for **IPv4 Address**.

Accessing the Embedded Web Server

The Embedded Web Server is the printer Web page that lets you view and remotely configure printer settings even when you are not physically near the printer.

1 Obtain the printer IP address:
- From the printer control panel home screen
- From the TCP/IP section in the Network/Ports menu
- By printing a network setup page or menu settings page, and then finding the TCP/IP section

Note: An IP address appears as four sets of numbers separated by periods, such as **123.123.123.123**.

2 Open a Web browser, and then type the printer IP address in the address field.

3 Press **Enter**.

Note: If you are using a proxy server, then temporarily disable it to load the Web page correctly.

Customizing the home screen

1 Open a Web browser, and then type the printer IP address in the address field.

Note: View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2 Do one or more of the following:
- Show or hide the icons of basic printer functions.
  a Click **Settings** > **General Settings** > **Home screen customization**.
  b Select the check boxes to specify which icons appear on the home screen.

  Note: If you clear a check box beside an icon, then the icon does not appear on the home screen.
  c Click **Submit**.
- Customize the icon for an application. For more information, see “Finding information about the home screen applications” on page 22 or see the documentation that came with the application.

Activating the home screen applications

Finding information about the home screen applications

Your printer comes with preinstalled home screen applications. Before you can use these applications, you must first activate and set up these applications using the Embedded Web Server. For more information on accessing the Embedded Web Server, see “Accessing the Embedded Web Server” on page 22.

For more information on configuring and using the home screen applications, do the following:

1 Go to **http://support.lexmark.com**, and then do either of the following:
   - Click **Business Solutions**, and then select the name of the application.
   - Click **Software and Solutions**, and then select either of the following:
     - **Scan to Network**—Find information about the Scan to Network application.
     - **Other Applications**—Find information about the other applications.

2 Click the **Manuals** tab, and then select the document for the home screen application.

Using Background and Idle Screen

Icon	Description
	The application lets you customize the background and idle screen of your printer home screen.

1 From the home screen, navigate to:

Change Background > select background to use

2 Touch .

Setting up Forms and Favorites

Icon	Description
	The application helps you simplify and streamline work processes by letting you quickly find and print frequently used online forms directly from the printer home screen. **Note:** The printer must have permission to access the network folder, FTP site, or Web site where the bookmark is stored. From the computer where the bookmark is stored, use sharing, security, and firewall settings to allow the printer at least a *read* access. For help, see the documentation that came with your operating system.

1 Open a Web browser, and then type the printer IP address in the address field.

Note: View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2 Click **Settings** > **Apps** > **Apps Management** > **Forms and Favorites**.

3 Define the bookmarks, and then customize the settings.

4 Click **Apply**.

To use the application, touch **Forms and Favorites** on the printer home screen, and then navigate through form categories, or search for forms based on a form number, name, or description.

Understanding Eco-Settings

Icon	Description
	The application lets you easily manage energy consumption, noise, toner, and paper usage settings to help reduce the environmental impact of your printer.

Exporting and importing a configuration

You can export configuration settings into a text file, and then import the file to apply the settings to other printers.

1. Open a Web browser, and then type the printer IP address in the address field.

   Note: View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2. To export or import a configuration for one application, do the following:
   a. Click **Settings** > **Apps** > **Apps Management**.
   b. From the list of installed applications, click the name of the application you want to configure.
   c. Click **Configure**, and then do either of the following:
      - To export a configuration to a file, click **Export**, and then follow the instructions on the computer screen to save the configuration file.

        Notes:

        - When saving the configuration file, you can type a unique file name or use the default name.
        - If a "JVM Out of Memory" error occurs, then repeat the export process until the configuration file is saved.

      - To import a configuration from a file, click **Import**, and then browse to the saved configuration file that was exported from a previously configured printer.

        Notes:

        - Before importing the configuration file, you can choose to preview it first or load it directly.
        - If a timeout occurs and a blank screen appears, then refresh the Web browser, and then click **Apply**.

3 To export or import a configuration for multiple applications, do the following:

   a Click **Settings** > **Import/Export**.

   b Do either of the following:

   - To export a configuration file, click **Export Embedded Solutions Settings File**, and then follow the instructions on the computer screen to save the configuration file.
   - To import a configuration file, do the following:

     1 Click **Import Embedded Solutions Settings File** > **Choose File**, and then browse to the saved configuration file that was exported from a previously configured printer.

     2 Click **Submit**.

Additional printer setup

Installing internal options

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

You can customize your printer connectivity and memory capacity by adding optional cards.

Available internal options

Memory cards

- DDR3 DIMM
- Flash memory
  - Fonts
  - Firmware
    - Forms Barcode
    - Prescribe
    - IPDS
- Hard disk*

* This internal option is available only in CS510 printer model.

Accessing the controller board

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Note: This task requires a flat-head screwdriver.

1 At the back of the printer, turn the screws counterclockwise to remove them.



2 Slightly open the controller board access cover, and then shift to the right to remove it.



3 Locate the appropriate connector on the controller board.

Warning—Potential Damage: Controller board electronic components are easily damaged by static electricity. Touch a metal surface on the printer before touching any controller board electronic components or connectors.



1	Flash memory or font card connector
2	Printer hard disk connector
3	Memory card connector

4 Reattach the cover.



5 Turn the screws clockwise to lock the cover.



Installing a memory card

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

1 Access the controller board.

For more information, see “Accessing the controller board” on page 26.

2 Unpack the memory card.

Warning—Potential Damage: Do not touch the connection points along the edge of the card. Doing so may cause damage.

3 Align the notch (1) on the memory card with the ridge (2) on the connector.



4 Push the memory card straight into the connector, and then push the card toward the controller board wall until it *clicks* into place.



5 Close the controller board access cover.

Installing an optional card

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: Controller board electronic components are easily damaged by static electricity. Touch a metal surface on the printer before touching any controller board electronic components or connectors.

1. Access the controller board.

   For more information, see “Accessing the controller board” on page 26.

2. Unpack the optional card.

   Warning—Potential Damage: Avoid touching the connection points along the edge of the card.

3. Holding the card by its sides, align the plastic pins (1) on the card with the holes (2) on the controller board.



4 Push the card firmly into place as shown in the illustration.



Warning—Potential Damage: Improper installation of the card may cause damage to the card and the controller board.

Note: The entire length of the connector on the card must touch and be flushed against the controller board.

5 Close the controller board access door.

Note: When the printer software and any hardware options are installed, it may be necessary to manually add the options in the printer driver to make them available for print jobs. For more information, see “Updating available options in the printer driver” on page 39.

Installing a printer hard disk

Note: This task requires a flathead screwdriver.

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: Controller board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any controller board electrical components or connectors.

1. Access the controller board.

   For more information, see “Accessing the controller board” on page 26.

2. Unpack the printer hard disk.

3. Remove the screws attached to the printer hard disk mounting bracket, and then remove the bracket.



4. Locate the appropriate connector on the controller board.



5 Align the standoffs of the printer hard disk to the holes in the controller board, and then press the printer hard disk down until the standoffs are in place.



6 Insert the plug of the printer hard disk interface cable into the receptacle of the controller board.

Note: The plugs and receptacles are color-coded.



7 Close the controller board access cover.

Note: When the printer software and any hardware options are installed, you may need to manually add the options in the printer driver to make them available for print jobs. For more information, see “Updating available options in the printer driver” on page 39.

Removing a printer hard disk

Note: This task requires a flathead screwdriver.

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: Controller board electronic components are easily damaged by static electricity. Touch something metal on the printer first before touching any controller board electronic components or connectors.

1. Access the controller board.

   For more information, see “Accessing the controller board” on page 26.

2. Unplug the printer hard disk interface cable from the controller board, leaving the cable attached to the printer hard disk. To unplug the cable, squeeze the paddle at the plug of the interface cable to disengage the latch before pulling the cable out.



3. Remove the printer hard disk by pulling it away from the controller board.



4 Set aside the printer hard disk.

5 Close the controller board access cover.

Installing hardware options

Order of installation

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Install the printer and any optional tray in the following order:

- Optional 550-sheet tray (Tray 3)
- Optional 650-sheet duo tray with integrated multipurpose feeder (Tray 2)
- Printer

Installing optional trays

The printer supports two optional input sources: a 550-sheet tray (Tray 3) and a 650-sheet duo tray (Tray 2) with an integrated multipurpose feeder.

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—SHOCK HAZARD: If you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

1 Unpack the optional tray and the dust cover, and then remove all packing material.



2 Place the tray near the printer.

3 Align the 650-sheet duo tray with the 550-sheet tray, and then lower it into place.

Notes:

- If you are installing both the optional trays, then the 550-sheet tray (Tray 3) must always be below the 650-sheet tray (Tray 2).
- The standard 250-sheet tray can be labeled as Tray 1 by using the tray number label that came with the optional tray.



4 Align the printer with the 650-sheet duo tray, and then lower the printer into place.



5 Install the dust covers.



Note: When the printer software and any hardware options are installed, you may need to manually add the options in the printer driver to make them available for print jobs. For more information, see “Updating available options in the printer driver” on page 39.

Setting up the printer software

Installing the printer software

Notes:

- If you installed the printer software on the computer before but need to reinstall the software, then uninstall the current software first.
- Close all open software programs before installing the printer software.
- For Macintosh users, you may download all the drivers and utilities from our Web site.

1. Obtain a copy of the software installer package.
   - From the *Software* CD that came with your printer
   - From our Web site:
     Go to **http://support.lexmark.com**, and then navigate to:
     SUPPORT & DOWNLOAD > select your printer > select your operating system
2. Double-click the software installer package.
   Wait for the installation dialog to appear.
   If you are using the *Software* CD and the installation dialog does not appear, then do the following:

   In Windows 8

   From the Search charm, type **`run`**, and then navigate to:
   Apps list > **Run** > type **`D:\setup.exe`** > **OK**.

   In Windows 7 or earlier

   a. Click or click **Start**, and then click **Run**.
   b. In the Start Search or Run dialog, type **`D:\setup.exe`**.
   c. Press **Enter**, or click **OK**.

   Note: **`D`** is the letter of your CD or DVD drive.
3. Click **Install**, and then follow the instructions on the computer screen.

Updating available options in the printer driver

When any hardware options are installed, you may need to manually add the options in the printer driver to make them available for use.

For Windows users

1. Open the printers folder.

   In Windows 8

   From the Search charm, type **`run`**, and then navigate to:
   Apps list > **Run** > type **`control printers`** > **OK**

In Windows 7 or earlier

a Click or click **Start**, and then click **Run**.

b In the Start Search or Run dialog, type `control printers`.

c Press **Enter**, or click **OK**.

2 Depending on your device, do either of the following:

- Press and hold the printer you want to update.
- Right-click the printer you want to update.

3 From the menu that appears, do either of the following:

- For Windows 7 or later, select **Printer properties**.
- For earlier versions, select **Properties**.

4 Click the **Configuration** tab.

5 Do either of the following:

- Click **Update Now - Ask Printer**.
- Under Configuration Options, manually add any installed hardware options.

6 Click **Apply**.

For Macintosh users

1 From the Apple menu, navigate to either of the following:

- **System Preferences** > **Print & Scan** > select your printer > **Options & Supplies** > **Driver**
- **System Preferences** > **Print & Fax** > select your printer > **Options & Supplies** > **Driver**

2 Add any installed hardware options, and then click **OK**.

Attaching cables

Make sure to match the following:

- The USB symbol on the cable with the USB symbol on the printer
- The appropriate Ethernet cable to the Ethernet port



	Use the	To
1	Rear USB port	Attach a keyboard to the printer.
2	USB printer port	Connect the printer to a computer.
3	Ethernet port	Connect the printer to a network.
4	USB wireless port	Attach an optional wireless network adapter.
5	Security lock port	Lock the system controller board.
6	Printer power cord socket	Connect the printer to a properly grounded electrical outlet.

Networking

Notes:

- Purchase a MarkNet™ N8352 wireless network adapter first before setting up the printer on a wireless network. For information on installing the wireless network adapter, see the instruction sheet that came with the adapter.
- A Service Set Identifier (SSID) is a name assigned to a wireless network. Wired Equivalent Privacy (WEP), Wi-Fi Protected Access (WPA), WPA2, and 802.1X - RADIUS are types of security used on a network.

Preparing to set up the printer on an Ethernet network

To configure your printer to connect to an Ethernet network, organize the following information before you begin:

Note: If your network automatically assigns IP addresses to computers and printers, continue on to installing the printer.

- A valid, unique IP address for the printer to use on the network
- The network gateway

- The network mask
- A nickname for the printer (optional)

  Note: A printer nickname can make it easier for you to identify your printer on the network. You can choose to use the default printer nickname, or assign a name that is easier for you to remember.

You will need an Ethernet cable to connect the printer to the network and an available port where the printer can physically connect to the network. Use a new network cable when possible to avoid potential problems caused by a damaged cable.

Installing the printer on an Ethernet network

For Windows users

1. Obtain a copy of the software installer package.
   - From the *Software* CD that came with your printer
   - From our Web site:
     Go to **http://support.lexmark.com**, and then navigate to:
     SUPPORT & DOWNLOAD > select your printer > select your operating system
2. Double-click the software installer package.
   Wait for the installation dialog to appear.
   If you are using the *Software* CD and the installation dialog does not appear, then do the following:

   In Windows 8

   From the Search charm, type **`run`**, and then navigate to:

   Apps list > **Run** > type **`D:\setup.exe`** > **OK**

   In Windows 7 or earlier

   a. Click or click **Start**, and then click **Run**.
   b. In the Start Search or Run dialog, type **`D:\setup.exe`**.
   c. Press **Enter**, or click **OK**.

   Note: **`D`** is the letter of your CD or DVD drive.
3. Click **Install**, and then follow the instructions on the computer screen.
4. Select **Ethernet connection**, and then click **Continue**.
5. Attach the Ethernet cable when instructed to do so.
6. Select the printer from the list, and then click **Continue**.

   Note: If the configured printer does not appear in the list, then click **Modify Search**.
7. Follow the instructions on the computer screen.

For Macintosh users

1. Allow the network DHCP server to assign an IP address to the printer.
2. Obtain the printer IP address either:
   - From the printer control panel
   - From the TCP/IP section in the Network/Ports menu
   - By printing a network setup page or menu settings page, and then finding the TCP/IP section

Note: You will need the IP address if you are configuring access for computers on a different subnet than the printer.

3. Install the printer driver on the computer.
   a. Download the driver at **http://support.lexmark.com**.
   b. Double-click the installer package for the printer, and then follow the instructions on the computer screen.
   c. Select a destination, and then click **Continue**.
   d. From the Easy Install screen, click **Install**.
   e. Type the user password, and then click **OK**.
   All the necessary applications are installed on the computer.
   f. Click **Close** when installation is complete.
4. Add the printer.
   - For IP printing:
     a. From the Apple menu, navigate to either of the following:
        – **System Preferences** > **Print & Scan**
        – **System Preferences** > **Print & Fax**
     b. Click **+**.
     c. Click the **IP** tab.
     d. Type the printer IP address in the address field, and then click **Add**.
   - For AppleTalk printing:

     Notes:

     – Make sure AppleTalk is activated on your printer.
     – This feature is supported only in Mac OS X version 10.5.

     a. From the Apple menu, navigate to:
     System Preferences > **Print & Fax**
     b. Click **+**, and then navigate to:
     AppleTalk > select your printer > **Add**

Preparing to set up the printer on a wireless network

Notes:

- Make sure your wireless network adapter is installed in your printer and working properly. For more information, see the instruction sheet that came with the wireless network adapter.
- Make sure your access point (wireless router) is turned on and is working properly.

Make sure you have the following information before setting up the printer on a wireless network:

- **SSID**—The SSID is also referred to as the network name.
- **Wireless Mode (or Network Mode)**—The mode is either infrastructure or ad hoc.
- **Channel (for ad hoc networks)**—The channel defaults to automatic for infrastructure networks.

  Some ad hoc networks will also require the automatic setting. Check with your system support person if you are not sure which channel to select.
- **Security Method**—There are four basic options for Security Method:
  - WEP key

    If your network uses more than one WEP key, then enter up to four in the provided spaces. Select the key currently in use on the network by selecting the default WEP transmit key.
  - WPA or WPA2 preshared key or passphrase

    WPA includes encryption as an additional layer of security. The choices are AES or TKIP. Encryption must be set for the same type on the router and on the printer, or the printer will not be able to communicate on the network.
  - 802.1X–RADIUS

    If you are installing the printer on an 802.1X network, then you may need the following:
    - Authentication type
    - Inner authentication type
    - 802.1X user name and password
    - Certificates
  - No security

    If your wireless network does not use any type of security, then you will not have any security information.

    Note: We do not recommend using an unsecured wireless network.

Notes:

- If you do not know the SSID of the network that your computer is connected to, then launch the wireless utility of the computer network adapter, and then look for the network name. If you cannot find the SSID or the security information for your network, then see the documentation that came with the access point, or contact your system support person.
- To find the WPA/WPA2 preshared key or passphrase for the wireless network, see the documentation that came with the access point, see the Embedded Web Server associated with the access point, or consult your system support person.

Connecting the printer using the Wireless Setup Wizard

Before you begin, make sure that:

- A wireless network adapter is installed in the printer and is working properly. For more information, see the instruction sheet that came with the wireless network adapter.
- An Ethernet cable is disconnected from the printer.
- Active NIC is set to Auto. To set this to Auto, navigate to:

  > **Network/Ports** > **Active NIC** > **Auto** >

Note: Make sure to turn off the printer, then wait for at least five seconds, and then turn the printer back on.

1 From the printer control panel, navigate to:

> **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Wireless** > **Wireless Connection Setup**

2 Select a wireless connection setup.

Use	To
Search for networks	Show available wireless connections. **Note:** This menu shows all broadcast secured or unsecured SSIDs.
Enter a network name	Manually type the SSID. **Note:** Make sure to type the correct SSID.
Wi-Fi Protected Setup	Connect the printer to a wireless network using Wi-Fi Protected Setup.

3 Follow the instructions on the printer display.

Connecting the printer to a wireless network using Wi-Fi Protected Setup

Before you begin, make sure that:

- The access point (wireless router) is Wi-Fi Protected Setup (WPS) certified or WPS-compatible. For more information, see the documentation that came with your access point.
- A wireless network adapter installed in your printer is attached and working properly. For more information, see the instruction sheet that came with the wireless network adapter.

Using the Push Button Configuration method

1 From the printer control panel, navigate to:

> **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Wireless** > **Wireless Connection Setup** > **Wi-Fi Protected Setup** > **Start Push Button Method**

2 Follow the instructions on the printer display.

Using the Personal Identification Number (PIN) method

1 From the printer control panel, navigate to:

> **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Wireless** > **Wireless Connection Setup** > **Wi-Fi Protected Setup** > **Start PIN Method**

2 Copy the eight-digit WPS PIN.

3 Open a Web browser, and then type the IP address of your access point in the address field.

Notes:

- The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

4 Access the WPS settings. For more information, see the documentation that came with your access point.

5 Enter the eight-digit PIN, and then save the setting.

Connecting the printer to a wireless network using the Embedded Web Server

Before you begin, make sure that:

- Your printer is connected temporarily to an Ethernet network.
- A wireless network adapter is installed in your printer and working properly. For more information, see the instruction sheet that came with the wireless network adapter.

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer control panel. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Network/Ports** > **Wireless**.
3. Modify the settings to match the settings of your access point (wireless router).

   Note: Make sure to enter the correct SSID, security method, preshared key or passphrase, network mode, and channel.

4. Click **Submit**.
5. Turn off the printer, and then disconnect the Ethernet cable. Then wait for at least five seconds, and then turn the printer back on.
6. To verify if your printer is connected to the network, print a network setup page. Then in the Network Card [x] section, see if the status is Connected.

Verifying printer setup

When all hardware and software options are installed and the printer is turned on, verify that the printer is set up correctly by printing the following:

- **Menu settings page**—Use this page to verify that all printer options are installed correctly. A list of installed options appears toward the bottom of the page. If an option you installed is not listed, then it is not installed correctly. Remove the option and install it again.
- **Network setup page**—If your printer is connected to a network or connected to a print server, print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

Printing a menu settings page

From the home screen, navigate to:

> **Reports** > **Menu Settings Page**

Printing a network setup page

If the printer is attached to a network, then print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

1 From the home screen, navigate to:

> **Reports** > **Network Setup Page**

2 Check the first section of the network setup page, and confirm that the status is **Connected**.

If the status is **Not Connected**, then the LAN drop may not be active, or the network cable may be malfunctioning. Consult a system support person for a solution, and then print another network setup page.

Loading paper and specialty media

This chapter covers the selection and handling of paper and specialty media. Proper selection and loading of media can improve how reliably documents print. For more information, see “Avoiding jams” on page 161 and “Storing paper” on page 64.

Setting the paper size and type

From the home screen navigate to:

> **Paper Menu** > **Paper Size/Type** > select a tray > select the paper size or type >

Configuring Universal paper settings

The Universal paper size is a user-defined setting that lets you print on paper sizes that are not preset in the printer menus.

Notes:

- The smallest supported Universal size is 76 x 127 mm (3 x 5 inches) and is loaded only in the multipurpose feeder and manual feeder.
- The largest supported Universal size is 215.9 x 359.9 mm (8.5 x 14.17 inches) and is loaded only in the multipurpose feeder and manual feeder.

1. From the home screen, navigate to:

   > **Paper Menu** > **Universal Setup** > **Units of Measure** > select a unit of measure

2. Touch **Portrait Width** or **Portrait Height**.

3. Select the width or height, and then touch .

Loading the 250- and 550-sheet tray

The printer has one 250-sheet tray (Tray 1) with an integrated manual feeder. The 250-sheet tray, the 650-sheet duo tray, and the 550-sheet tray support the same paper sizes and types and are loaded in the same way.

CAUTION—POTENTIAL INJURY: To reduce the risk of equipment instability, load each tray separately. Keep all other trays closed until needed.

1. Pull out the tray completely.

   Note: Do not remove trays while a job is printing or while **Busy** appears on the display. Doing so may cause a jam.



2 If the paper is longer than letter-size paper, then squeeze and then slide the length guide at the back of the tray to extend it.



3 Squeeze, and then slide the length guide tab to the correct position for the size of the paper being loaded.



Note: Use the paper size indicators on the bottom of the tray to help position the guide.

4 Squeeze, and then slide the width guide tab to the correct position for the size of the paper being loaded.



Note: Use the paper size indicators on the bottom of the tray to help position the guides.

5 Flex the sheets back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.



6 Load the paper stack with the recommended printable side faceup.



7 Place the paper guides securely against the edges of the paper.

8 Insert the tray.



9 From the printer control panel, set the paper size and paper type in the Paper menu to match the paper loaded in the tray.

Note: Mixing paper sizes or paper types in a tray may cause jams.

Loading the multipurpose feeder

1 Push the multipurpose feeder latch to the left.

2 Open the multipurpose feeder.

3 Pull the multipurpose feeder extender.

Note: Guide the extender gently so that the multipurpose feeder is fully extended and open.

4 Prepare the paper for loading.

- Flex the sheets of paper back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.



- Hold transparencies by the edges, and then fan them. Straighten the edges on a level surface.

  Note: Avoid touching the printable side of transparencies. Be careful not to scratch them.



- Flex a stack of envelopes back and forth to loosen them, and then fan them. Straighten the edges on a level surface.

  Warning—Potential Damage: Never use envelopes with stamps, clasps, snaps, windows, coated linings, or self-stick adhesives. These envelopes may severely damage the printer.

5 Locate the maximum paper fill indicator and tab.

Note: Make sure the paper or specialty media is below the maximum paper fill indicator located on the paper guides.



1	Width guide tab
2	Maximum paper fill indicator

3	Width guide
4	Feeder extender
5	Paper size indicator

6 Load the paper, and then adjust the width guide to lightly touch the edge of the paper stack.

- Load paper, card stock, and transparencies with the recommended printable side facedown and the top edge entering the printer first.

- Load envelopes with the flap side up and against the right side of the paper guide.



Notes:

- Do not load or close the multipurpose feeder while a job is printing.
- Load only one size and type of paper at a time.
- Paper should lie flat in the multipurpose feeder. Make sure the paper fits loosely in the multipurpose feeder and is not bent or wrinkled.

7 From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the tray.

Loading the manual feeder

The standard 250-sheet tray has an integrated manual feeder that can be used to print on different types of paper one sheet at a time.

1 Load a sheet of paper into the manual feeder:

- Printable side facedown for one-sided printing
- Printable side faceup for two-sided (duplex) printing

Note: There are different ways for loading letterhead depending on the mode of printing.

One-sided printing using a letterhead	Two-sided printing using a letterhead

- Load envelope with the flap side up and against the right side of the paper guide.



2 Feed paper into the manual feeder only to the point where its leading edge can contact the paper guides.

Note: To achieve the best possible print quality, use only high-quality media designed for laser printers.

3 Adjust the paper guides to the width of the paper loaded.

Warning—Potential Damage: Do not force the paper into the feeder. Forcing the paper may cause jams.



Linking and unlinking trays

When the paper size and paper type for any trays are the same, the printer links those trays. When one linked tray becomes empty, paper feeds from the next linked tray. We recommend giving all unique paper, such as letterhead and different colored plain papers, a different custom type name so that the trays they are in do not automatically link.

Linking and unlinking trays

Note: This feature applies only in network printers.

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Paper Menu**.
3. Change the tray settings to specify the paper size and type for the tray.
   - To link trays, make sure the paper size and type for the tray match with that of the other tray.
   - To unlink trays, make sure the paper size or type for the tray *does not* match with that of the other tray.
4. Click **Submit**.

Warning—Potential Damage: Paper loaded in the tray should match the paper type name assigned in the printer. The temperature of the fuser varies according to the specified paper type. Printing issues may occur if settings are not properly configured.

Creating a custom name for a paper type

Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Paper Menu** > **Custom Names**.
3. Select a custom name, and then type a custom paper type name.
4. Click **Submit**.
5. Click **Custom Types**, and then verify if the new custom paper type name has replaced the custom name.

Using the printer control panel

1 From the home screen, navigate to:

> **Paper Menu** > **Custom Names**

2 Select a custom name, and then type a custom paper type name.

3 Touch .

4 Touch **Custom Types**, and then verify that the new custom paper type name has replaced the custom name.

Assigning a custom paper type

Using the Embedded Web Server

Assign a custom paper type name to a tray when linking or unlinking trays.

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Paper Menu** > **Custom Types**.

3 Select a custom paper type name, and then select a paper type

Note: Paper is the factory default paper type for all user-defined custom names.

4 Click **Submit**.

Using the printer control panel

1 From the home screen, navigate to:

> **Paper Menu** > **Custom Types**

2 Select a custom paper type name, and then select a paper type

Note: Paper is the factory default paper type for all user-defined custom names.

3 Touch .

Paper and specialty media guide

Notes:

- Make sure the paper size, type, and weight are set correctly on the computer or on the printer control panel.
- Flex, fan, and straighten specialty media before loading it.
- The printer may print at a reduced speed to prevent damage to the fuser.
- For more information on card stock and labels, see the *Card Stock & Label Guide* on the Lexmark support Web site at **http://support.lexmark.com**.

Using specialty media

Tips on using letterhead

- Use letterhead designed specifically for laser printers.
- Print a test page on the letterhead being considered for use before buying large quantities.
- Before loading letterhead, flex, fan, and straighten the stacks to prevent sheets from sticking together.
- Page orientation is important when printing on letterhead.

Source	Printing	Printable side	Paper orientation
Trays	One-sided	Faceup	Load the sheet with the top edge entering the printer first.
Trays	Two-sided	Facedown	Load the sheet with the bottom edge entering the printer first.
Note: Check with the manufacturer or vendor to determine whether or not the preprinted letterhead is acceptable for laser printers.			

Source	Printing	Printable side	Paper orientation
Manual feeder	One-sided	Facedown	Load the sheet with the top edge entering the printer first.
Manual feeder	Two-sided	Faceup	Load the sheet with the bottom edge entering the printer first.
Multipurpose feeder	One-sided	Facedown	Load the sheet with the top edge entering the printer first.
Multipurpose feeder	Two-sided	Faceup	Load the sheet with the bottom edge entering the printer first.

Note: Check with the manufacturer or vendor to determine whether or not the preprinted letterhead is acceptable for laser printers.

Tips on using transparencies

Print a test page on the transparencies being considered for use before buying large quantities.

- From the printer control panel, set the paper size, type, texture, and weight in the Paper menu to match the transparencies loaded in the tray.
- Print a test page on the transparencies being considered for use before buying large quantities.
- Feed transparencies from the 250-sheet tray, manual feeder, or multipurpose feeder.
- Use transparencies designed specifically for laser printers.
- Avoid getting fingerprints on the transparencies to prevent print quality problems.
- Before loading transparencies, flex, fan, and straighten the stacks to prevent sheets from sticking together.

Tips on using envelopes

- From the printer control panel, set the paper size, type, texture, and weight in the Paper menu to match the envelopes loaded in the tray.
- Print samples on the envelopes being considered for use before buying large quantities.
- Use envelopes designed specifically for laser printers.
- For best performance, use envelopes made from 90-g/m^2 (24-lb) paper or 25% cotton.
- Use only new envelopes from undamaged packages.
- To optimize performance and minimize jams, do not use envelopes that:
  - Have excessive curl or twist.
  - Are stuck together or damaged in any way.
  - Have windows, holes, perforations, cutouts, or embossing.
  - Have metal clasps, string ties, or folding bars.
  - Have an interlocking design.
  - Have postage stamps attached.
  - Have any exposed adhesive when the flap is in the sealed or closed position.
  - Have bent corners.
  - Have rough, cockle, or laid finishes.
- Adjust the width guides to fit the width of the envelopes.
- Before loading the envelopes on the tray, flex and fan the envelopes to loosen them. Straighten the edges on a level surface.

Note: A combination of high humidity (over 60%) and high printing temperature may wrinkle or seal envelopes.

Tips on using labels

- From the printer control panel, set the paper size, type, texture, and weight in the Paper menu to match the labels loaded in the tray.
- Print samples on labels being considered for use before buying large quantities.
- For more information on label printing, characteristics, and design, see the *Card Stock & Label Guide* at **http://support.lexmark.com**.
- Use labels designed specifically for laser printers.
- Do not use labels with slick backing material.

- Use full label sheets. Partial sheets may cause labels to peel off during printing, resulting in a jam. Partial sheets also contaminate the printer and the cartridge with adhesive, and could void the printer and toner cartridge warranties.
- Do not use labels with exposed adhesive.
- Before loading labels on the tray, flex and fan labels to loosen them. Straighten the edges on a level surface.

Tips on using card stock

Card stock is heavy, single-ply specialty media. Many of its variable characteristics, such as moisture content, thickness, and texture, can significantly affect print quality.

- From the printer control panel, set the paper size, type, texture, and weight in the Paper menu to match the card stock loaded in the tray.
- Print samples on the card stock being considered for use before buying large quantities.
- Specify the paper texture and weight from the tray settings to match the paper loaded in the tray.
- Preprinting, perforation, and creasing may significantly affect the print quality and cause jams or other paper feed problems.
- Before loading the card stock on the tray, flex and fan the card stock to loosen them. Straighten the edges on a level surface.

Paper guidelines

Select the correct paper or specialty media to reduce printing problems. For the best print quality, try a sample of the paper or specialty media before buying large quantities.

Paper characteristics

The following paper characteristics affect print quality and reliability. Consider these characteristics when evaluating new paper stock.

Weight

The printer trays can automatically feed paper weights up to 176-g/m^2 (47-lb) bond grain long paper. The multipurpose feeder can automatically feed paper weights up to 176-g/m^2 (47-lb) bond grain long paper. Paper lighter than 60 g/m^2 (16 lb) might not be stiff enough to feed properly, causing jams. For best performance, use 75-g/m^2 (20-lb) bond grain long paper. For paper smaller than 182 x 257 mm (7.2 x 10.1 inches), we recommend 90 g/m^2 (24 lb) or heavier paper.

Note: Duplex printing is supported from 60–105-g/m^2 (16–28-lb) bond grain long paper.

Curl

Curl is the tendency for paper to curl at its edges. Excessive curl can cause paper feeding problems. Curl can occur after the paper passes through the printer, where it is exposed to high temperatures. Storing paper unwrapped in hot, humid, cold, or dry conditions, even in the trays, can contribute to paper curling prior to printing and can cause feeding problems.

Smoothness

Paper smoothness directly affects print quality. If paper is too rough, then toner cannot fuse to it properly. If paper is too smooth, then it can cause paper feeding or print quality issues. Always use paper between 100 and 300 Sheffield points; smoothness between 150 and 250 Sheffield points produces the best print quality.

Moisture content

The amount of moisture in paper affects both print quality and the ability of the printer to feed the paper correctly. Leave paper in its original wrapper until it is time to use it. This limits the exposure of paper to moisture changes that can degrade its performance.

Store paper in its original wrapper in the same environment as the printer for 24 to 48 hours before printing. Extend the time to several days if the storage or transportation environment is very different from the printer environment. Thick paper may also require a longer conditioning period.

Grain direction

Grain refers to the alignment of the paper fibers in a sheet of paper. Grain is either *grain long*, running the length of the paper, or *grain short*, running the width of the paper.

For 60–90-g/m^2 (16–24-lb) bond paper, grain long paper is recommended.

Fiber content

Most high-quality xerographic paper is made from 100% chemically treated pulped wood. This content provides the paper with a high degree of stability resulting in fewer paper feeding problems and better print quality. Paper containing fibers such as cotton can negatively affect paper handling.

Unacceptable paper

The following paper types are not recommended for use with the printer:

- Chemically treated papers used to make copies without carbon paper, also known as carbonless papers, carbonless copy paper (CCP), or no carbon required (NCR) paper
- Preprinted papers with chemicals that may contaminate the printer
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise print location on the page) greater than ±2.3 mm (±0.9 in.), such as optical character recognition (OCR) forms

  In some cases, registration can be adjusted with a software application to successfully print on these forms.
- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers, or curled papers
- Recycled papers that fail EN12281:2002 (European)
- Paper weighing less than 60 g/m^2 (16 lb)
- Multiple-part forms or documents

Selecting paper

Using the appropriate paper prevents jams and helps ensure trouble-free printing.

To help avoid paper jams and poor print quality:

- *Always* use new, undamaged paper.
- Before loading paper, know the recommended printable side of the paper. This information is usually indicated on the paper package.
- *Do not* use paper that has been cut or trimmed by hand.
- *Do not* mix paper sizes, types, or weights in the same tray; mixing results in jams.
- *Do not* use coated papers unless they are specifically designed for electrophotographic printing.

Selecting preprinted forms and letterhead

Use these guidelines when selecting preprinted forms and letterhead:

- Use grain long for 60–90-g/m^2 (16–24-lb) paper.
- Use only forms and letterhead printed using an offset lithographic or engraved printing process.
- Avoid paper with rough or heavily textured surfaces.

Use inks that are not affected by the resin in toner. Inks that are oxidation-set or oil-based generally meet these requirements; latex inks might not.

When in doubt, contact your paper supplier.

Using recycled paper and other office papers

As an environmentally conscious company, Lexmark supports the use of recycled office paper produced specifically for use in laser (electrophotographic) printers. In 1998, Lexmark presented to the US government a study demonstrating that recycled paper produced by major mills in the US fed as well as non-recycled paper. However, no blanket statement can be made that *all* recycled paper will feed well.

Lexmark consistently tests its printers with recycled paper (20–100% post-consumer waste) and a variety of test paper from around the world, using chamber tests for different temperature and humidity conditions. Lexmark has found no reason to discourage the use of today's recycled office papers, but generally the following property guidelines apply to recycled paper.

- Low moisture content (4–5%)
- Suitable smoothness (100–200 Sheffield units, or 140–350 Bendtsen units, European)

  Note: Some much smoother papers (such as premium 24 lb laser papers, 50–90 Sheffield units) and much rougher papers (such as premium cotton papers, 200–300 Sheffield units) have been engineered to work very well in laser printers, despite surface texture. Before using these types of paper, consult your paper supplier.
- Suitable sheet-to-sheet coefficient of friction (0.4–0.6)
- Sufficient bending resistance in the direction of feed

Recycled paper, paper of lower weight (<60 g/m^2 [16 lb bond]) and/or lower caliper (<3.8 mils [0.1 mm]), and paper that is cut grain-short for portrait (or short-edge) fed printers may have lower bending resistance than is required for reliable paper feeding. Before using these types of paper for laser (electrophotographic) printing, consult your paper supplier. Remember that these are general guidelines only and that paper meeting these guidelines may still cause paper feeding problems in any laser printer (for example, if the paper curls excessively under normal printing conditions).

Storing paper

Use these paper storage guidelines to help avoid jams and uneven print quality:

- For best results, store paper where the temperature is 21°C (70°F) and the relative humidity is 40 percent. Most label manufacturers recommend printing in a temperature range of 18–24°C (65–75°F) with relative humidity between 40 and 60 percent.
- Store paper in cartons, on a pallet or shelf, rather than on the floor.
- Store individual packages on a flat surface.
- Do not store anything on top of individual paper packages.
- Take paper out of the carton or wrapper only when you are ready to load it in the printer. The carton and wrapper help keep the paper clean, dry, and flat.

Supported paper sizes, types, and weights

This chapter provides provides information on standard and optional paper sources and the types of paper they support.

Note: For unlisted paper sizes, types, and weights, select the closest *larger* listed size.

Supported paper sizes

Note: Your printer model may have a 650-sheet duo tray, which consists of a 550-sheet tray and an integrated 100-sheet multipurpose feeder. The 550-sheet tray of the 650-sheet duo tray supports the same paper sizes as the optional 550-sheet tray. The integrated multipurpose feeder supports different paper sizes, types, and weights.

Paper size and dimension	Standard 250-sheet tray	Manual feeder	650-sheet duo tray		550-sheet tray	Duplex mode
			550-sheet tray	Multipurpose feeder		
A4 210 x 297 mm (8.3 x 11.7 in.)	√[1]	√	√[1]	√[1]	√[1]	√
A5 148 x 210 mm (5.83 x 8.3 in.)	√[1]	√	√[2]	√[1]	√[2]	X
A6 105 x 148 mm (4.1 x 5.8 in.)	X	√	X	√[1]	X	X

[1] The paper source supports paper size without *size sensing*.

[2] Universal is only supported in the standard 250and optional 550sheet tray if the paper size is from 148 x 215.9 mm (5.83 x 8.5 inches) to 215.9 x 355.6 mm (8.5 x 14 inches).

[3]Universal is only supported in the multipurpose feeder and manual feeder if the paper size is from 76.2 x 127 mm (3 x 5 inches) to 215.9 x 359.9 mm (8.5 x 14.17 inches).

[4]Universal is only supported in duplex mode if the width is between 210 mm (8.27 inches) and 215.9 mm (8.5 inches) and length is between 279.4 mm (11 inches) and 355.6 mm (14 inches).

Paper size and dimension	Standard 250-sheet tray	Manual feeder	650-sheet duo tray		550-sheet tray	Duplex mode
			550-sheet tray	Multipurpose feeder		
JIS B5 182 x 257 mm (7.2 x 10.1 in.)	√[1]	√	√[1]	√[1]	√[1]	X
Letter 216 x 279 mm (8.5 x 11 in.)	√[1]	√	√[1]	√[1]	√[1]	√
Legal 216 x 356 mm (8.5 x 14 in.)	√[1]	√	√[1]	√[1]	√[1]	√
Executive 184 x 267 mm (7.3 x 10.5 in.)	√[1]	√	√[1]	√[1]	√[1]	X
Oficio (Mexico) 216 x 340 mm (8.5 x 13.4 in.)	√[1]	√	√[1]	√[1]	√[1]	√
Folio 216 x 330 mm (8.5 x 13 in.)	√[1]	√	√[1]	√[1]	√[1]	√
Statement 140 x 216 mm (5.5 x 8.5 in.)	X	√	X	√[1]	X	X
Universal 76 x 127 mm (3 x 5 in.) to 216 x 356 mm (8.5 x 14 in.)	X	√[1,3]	X	√[1,3]	X	X
Universal 148 x 210 mm (5.8 x 8.3 in) to 216 x 356 mm (8.5 x 14 in).	√[1,2]	√	√[1,2]	√	√[1,2]	√[4]
7 3/4 Envelope (Monarch) 98 x 191 mm (3.9 x 7.5 in.)	X	√	X	√[1]	X	X

[1] The paper source supports paper size without *size sensing*.

[2] Universal is only supported in the standard 250and optional 550sheet tray if the paper size is from 148 x 215.9 mm (5.83 x 8.5 inches) to 215.9 x 355.6 mm (8.5 x 14 inches).

[3]Universal is only supported in the multipurpose feeder and manual feeder if the paper size is from 76.2 x 127 mm (3 x 5 inches) to 215.9 x 359.9 mm (8.5 x 14.17 inches).

[4]Universal is only supported in duplex mode if the width is between 210 mm (8.27 inches) and 215.9 mm (8.5 inches) and length is between 279.4 mm (11 inches) and 355.6 mm (14 inches).

Paper size and dimension	Standard 250-sheet tray	Manual feeder	650-sheet duo tray		550-sheet tray	Duplex mode
			550-sheet tray	Multipurpose feeder		
9 Envelope 98 x 225 mm (3.9 x 8.9 in.)	X	√	X	√[1]	X	X
10 Envelope 105 x 241 mm (4.1 x 9.5 in.)	X	√	X	√[1]	X	X
DL Envelope 110 x 220 mm (4.3 x 8.7 in.)	X	√	X	√[1]	X	X
C5 Envelope 162 x 229 mm (6.4 x 9 in.)	X	√	X	√[1]	X	X
B5 Envelope 176 x 250 mm (6.9 x 9.8 in.)	X	√	X	√[1]	X	X
Other Envelope 98 x 162 mm (3.9 x 6.3 in.) up to 176 x 250 mm (6.9 x 9.8 in.)	X	√	X	√[1]	X	X

[1] The paper source supports paper size without *size sensing*.

[2] Universal is only supported in the standard 250and optional 550sheet tray if the paper size is from 148 x 215.9 mm (5.83 x 8.5 inches) to 215.9 x 355.6 mm (8.5 x 14 inches).

[3]Universal is only supported in the multipurpose feeder and manual feeder if the paper size is from 76.2 x 127 mm (3 x 5 inches) to 215.9 x 359.9 mm (8.5 x 14.17 inches).

[4]Universal is only supported in duplex mode if the width is between 210 mm (8.27 inches) and 215.9 mm (8.5 inches) and length is between 279.4 mm (11 inches) and 355.6 mm (14 inches).

Supported paper types and weights

Notes:

- Your printer model may have a 650-sheet duo tray, which consists of a 550-sheet tray and an integrated 100-sheet multipurpose feeder. The 550-sheet tray of the 650-sheet duo tray supports the same paper as the 550-sheet tray. The integrated multipurpose feeder supports different paper sizes, types, and weights.
- Labels, transparencies, envelopes, and card stock always print at reduced speed.

Paper type	250-sheet tray	Manual feeder	650-sheet duo tray		550-sheet tray	Duplex mode
			550-sheet tray	Multipurpose feeder		
Paper • Plain • Recycled • Glossy • Bond • Letterhead • Preprinted • Colored • Light • Heavy • Rough/Cotton • Custom Type [x]	✓	✓	✓	✓	✓	✓
Card stock	✓	✓	✓	✓	✓	X
Transparencies	✓	✓	X	✓	X	X
Labels • Paper	✓	✓	✓	✓	✓	X
Envelope	X	✓	X	✓	X	X

Printing

Printing forms

Use the Forms and Favorites application to quickly and easily access frequently used forms or other information that is regularly printed. Before you can use this application, first set it up on the printer. For more information, see “Setting up Forms and Favorites” on page 23.

1. From the printer home screen, navigate to:

   Forms and Favorites > select the form from the list > enter the number of copies > adjust other settings

2. Depending on your printer model, touch , , or **Submit**.

Printing a document

Printing a document

1. From the printer control panel, set the paper type and size to match the paper loaded.
2. Send the print job:

   #### For Windows users

   a. With a document open, click **File** > **Print**.

   b. Click **Properties**, **Preferences**, **Options**, or **Setup**.

   c. Adjust the settings, if necessary.

   d. Click **OK** > **Print**.

   #### For Macintosh users

   a. Customize the settings in the Page Setup dialog:

      1. With a document open, choose **File** > **Page Setup**.
      2. Choose a paper size or create a custom size to match the paper loaded.
      3. Click **OK**.

   b. Customize the settings in the Print dialog:

      1. With a document open, choose **File** > **Print**.
         If necessary, click the disclosure triangle to see more options.
      2. From the print options pop-up menus, adjust the settings, if necessary.

         Note: To print on a specific paper type, adjust the paper type setting to match the paper loaded, or select the appropriate tray or feeder.
      3. Click **Print**.

Printing in black and white

From the home screen, navigate to:

> **Settings** > **Print Settings** > **Quality Menu** > **Print Mode** > **Black Only** >

Adjusting toner darkness

Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Print Settings** > **Quality Menu** > **Toner Darkness**.
3. Adjust the setting, and then click **Submit**.

Using the printer control panel

1. From the home screen, navigate to:

   > **Settings** > **Print Settings** > **Quality Menu** > **Toner Darkness**

2. Adjust the setting, and then touch .

Using Max Speed and Max Yield

Max Speed and Max Yield let you choose between a faster print speed or a higher toner yield. Max Yield is the factory default setting.

- **Max Speed**—This lets you print in either black or color depending on what is set in the printer driver. The printer prints in color unless Black Only is selected in the printer driver.
- **Max Yield**—This lets you switch from black to color based on the color content found on each page. Frequent color mode switching can result to slower printing if the content of pages is mixed.

Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Print Settings** > **Setup Menu**.
3. From the Printer Usage list, select **Max Speed** or **Max Yield**.
4. Click **Submit**.

Using the printer control panel

1 From the home screen, navigate to:

> **Settings** > **Print Settings** > **Setup Menu**

2 From the Printer Usage list, select **Max Speed** or **Max Yield**.

3 Touch **Submit**.

Printing from a flash drive or mobile device

Printing from a flash drive

Notes:

- Before printing an encrypted PDF file, you will be prompted to type the file password from the printer control panel.
- You cannot print files for which you do not have printing permissions.

1 Insert a flash drive into the USB port.

Notes:

- A flash drive icon appears on the printer home screen when a flash drive is inserted.
- If you insert the flash drive when the printer requires attention, such as when a jam has occurred, then the printer ignores the flash drive.
- If you insert the flash drive while the printer is processing other print jobs, then **Busy** appears. After these print jobs are processed, you may need to view the held jobs list to print documents from the flash drive.

Warning—Potential Damage: Do not touch the printer or the flash drive in the area shown while actively printing, reading, or writing from the memory device. Loss of data can occur.



2 From the printer control panel, touch the document you want to print.

3 Touch the arrows to specify the number of copies for printing, and then touch **Print**.

Notes:

- Do not remove the flash drive from the USB port until the document has finished printing.
- If you leave the flash drive in the printer after leaving the initial USB menu screen, then touch **Held Jobs** on the home screen to print files from the flash drive.

Supported flash drives and file types

Notes:

- High-speed USB flash drives must support the full-speed standard. Low-speed USB devices are not supported.
- USB flash drives must support the File Allocation Table (FAT) system. Devices formatted with New Technology File System (NTFS) or any other file system are not supported.

Recommended flash drives	File type
• Lexar JumpDrive FireFly (512MB and 1GB) • SanDisk Cruzer Micro (512MB and 1GB) • Sony Micro Vault Classic (512MB and 1GB)	Documents: • .pdf • .xps Images: • .dcx • .gif • .jpeg or .jpg • .bmp • .pcx • .tiff or .tif • .png • .fls

Printing from a mobile device

To download a compatible mobile printing application, visit **www.lexmark.com/mobile**.

Note: Mobile printing applications may also be available from your mobile device manufacturer.

Printing confidential and other held jobs

Storing print jobs in the printer

1 From the home screen, navigate to:

> **Security** > **Confidential Print** > select a print job type

Use	To
Max Invalid PIN	Limit the number of times an invalid PIN can be entered. **Note:** When the limit is reached, the print jobs for that user name and PIN are deleted.
Confidential Job Expiration	Hold print jobs in the computer until you enter the PIN from the printer control panel. **Note:** The PIN is set from the computer. It must be four digits, using the numbers 0–9.
Repeat Job Expiration	Print and store print jobs in the printer memory.
Verify Job Expiration	Print one copy of a print job and hold the remaining copies. It lets you examine if the first copy is satisfactory or not. The print job is automatically deleted from the printer memory when all copies are printed.
Reserve Job Expiration	Store print jobs for printing at a later time. **Note:** The print jobs are held until deleted from the Held Jobs menu.

Notes:

- Confidential, Verify, Reserve, and Repeat print jobs may be deleted if the printer requires extra memory to process additional held jobs.
- You can set the printer to store print jobs in the printer memory until you start the print job from the printer control panel.
- All print jobs that can be initiated by the user at the printer are called *held jobs*.

2 Touch .

Printing confidential and other held jobs

Note: Confidential and Verify print jobs are automatically deleted from memory after printing. Repeat and Reserve jobs are *held* in the printer until you delete them.

For Windows users

1 With a document open, click **File** > **Print**.

2 Click **Properties**, **Preferences**, **Options**, or **Setup**.

3 Click **Print and Hold**.

4 Select the print job type (Confidential, Repeat, Reserve, or Verify), and then assign a user name. For a confidential print job, also enter a four-digit PIN.

5 Click **OK** or **Print**.

6 From the printer home screen, release the print job.

- For confidential print jobs, navigate to:
  Held jobs > select your user name > **Confidential Jobs** > enter the PIN > **Print**
- For other print jobs, navigate to:
  Held jobs > select your user name > select the print job > specify the number of copies > **Print**

For Macintosh users

1 With a document open, choose **File** > **Print**.

If necessary, click the disclosure triangle to see more options.

2 From the print options or Copies & Pages pop-up menu, choose **Job Routing**.

3 Select the print job type (Confidential, Repeat, Reserve, or Verify), and then assign a user name. For a confidential print job, also enter a four-digit PIN.

4 Click **OK** or **Print**.

5 From the printer home screen, release the print job.

- For confidential print jobs, navigate to:
  Held jobs > select your user name > **Confidential Jobs** > enter the PIN > **Print**
- For other print jobs, navigate to:
  Held jobs > select your user name > select the print job > specify the number of copies > **Print**

Printing information pages

Printing a font sample list

1 From the home screen, navigate to:

> **Reports** > **Print Fonts**

2 Touch **PCL Fonts** or **PostScript Fonts**.

Printing a directory list

A directory list shows the resources stored in a flash memory or on the printer hard disk.

From the home screen, navigate to:

> **Reports** > **Print Directory**

Canceling a print job

Canceling a print job from the printer control panel

1. From the printer control panel, touch **Cancel Job** or press ✕ on the keypad.
2. Touch the print job you want to cancel, and then touch **Delete Selected Jobs**.

   Note: If you press ✕ on the keypad, then touch **Resume** to return to the home screen.

Canceling a print job from the computer

For Windows users

1. Open the printers folder.

   In Windows 8

   From the Search charm, type `run`, and then navigate to:

   Apps list > **Run** > type `control printers` > **OK**

   In Windows 7 or earlier

   a. Click or click **Start**, and then click **Run**.

   b. In the Start Search or Run dialog, type `control printers`.

   c. Press **Enter**, or click **OK**.
2. Double-click the printer icon.
3. Select the print job you want to cancel.
4. Click **Delete**.

For Macintosh users

1. From the Apple menu, navigate to either of the following:
   - **System Preferences** > **Print & Scan** > select your printer > **Open Print Queue**
   - **System Preferences** > **Print & Fax** > select your printer > **Open Print Queue**
2. From the printer window, select the print job you want to cancel, and then delete it.

Understanding the printer menus

Note: The Embedded Web Server is available only in network printers or printers connected to print servers.

Menus list

Note: Some menus are available only in select printer models.

Supplies	Paper Menu	Reports	Network/Ports
Cyan Cartridge	Default Source	Menu Settings Page	Active NIC
Magenta Cartridge	Paper Size/Type	Device Statistics	Standard Network or Network [x]
Yellow Cartridge	Configure MP[1]	Network Setup Page	Standard USB
Black Cartridge	Substitute Size	Network [x] Setup Page	SMTP Setup
Waste Toner Bottle	Paper Texture	Profiles List	
Black or Color Imaging Kit	Paper Weight	Print Fonts	
Maintenance Kit	Paper Loading	Print Directory	
	Custom Types	Print Demo	
	Custom Names	Asset Report	
	Universal Setup		

Security	Settings	Help	Option Card Menu
Miscellaneous Security Settings	General Settings	Print All Guides	**Note:** A list of installed DLEs (Download Emulators) appears.
Confidential Print	Flash Drive Menu	Color Quality	
Disk Wiping	Print Settings	Print Quality	
Security Audit Log		Printing Guide	
Set Date and Time		Print Defects Guide	
		Information Guide	
		Supplies Guide	

[1] This menu item appears only when a 650-sheet duo tray is attached.

Supplies menu

Use	To
Cyan, Magenta, Yellow, or Black Toner Cartridge Nearly Low Low Very Low Replace Missing Defective Missing or Unresponsive Unsupported Invalid Region OK Non-genuine Lexmark Cartridge	Show the status of the cyan, magenta, yellow, or black toner cartridge.
Black or Color Imaging Kit Nearly Low Low Very Low Replace Missing Defective Missing or Unresponsive Unsupported OK Non-genuine Lexmark Imaging Kit	Show the status of the black or color imaging kit.
Waste Toner Bottle Near Full Replace Missing OK	Show the status of the waste toner bottle.
Maintenance Kit Nearly Low Low Very Low Replace OK	Show the status of the maintenance kit.

Paper menu

Default Source menu

Use	To
Default Source Tray [x] MP Feeder Manual Paper Manual Envelope	Set a default paper source for all print jobs. **Notes:** • Tray 1 (standard tray) is the factory default setting. • From the Paper menu, set Configure MP to “Cassette” for MP Feeder to appear as a menu setting. • If the same size and type of paper are in two trays and the paper size and paper type settings match, then the trays are automatically linked. When one tray is empty, the print job continues using the linked tray.

Paper Size/Type menu

Use	To
Tray [x] Size A4 A5 JIS-B5 Letter Legal Executive Oficio (Mexico) Folio Universal	Specify the size of the paper loaded in each tray. **Note:** Letter is the US factory default setting. A4 is the international factory default setting.
Tray [x] Type Plain Paper Card Stock Transparency Recycled Glossy Labels Bond Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Custom Type [x]	Specify the type of the paper loaded in each tray. **Notes:** • Plain Paper is the factory default setting for Tray 1. Custom Type [x] is the factory default setting for all other trays. • If available, a user-defined name will appear instead of Custom Type [x]. • Use this menu to configure automatic tray linking. • Only the 250-sheet tray supports Transparency.
Note: Only installed trays and feeders are listed in this menu.	

Use	To
MP Feeder Size A4 A5 A6 JIS B5 Letter Legal Executive Oficio (Mexico) Folio Statement Universal 7 3/4 Envelope 9 Envelope 10 Envelope DL Envelope C5 Envelope B5 Envelope Other Envelope	Specify the size of the paper loaded in the multipurpose feeder. **Notes:** • Letter is the U.S. factory default setting. A4 is the international factory default setting. • From the Paper menu, set Configure MP to Cassette in order for MP Feeder Size to appear as a menu. • The multipurpose feeder does not automatically detect the paper size. Make sure the paper size is set.
MP Feeder Type Plain Paper Card Stock Transparency Recycled Glossy Labels Bond Envelope Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Custom Type [x]	Specify the type of the paper loaded in the multipurpose feeder. **Notes:** • Custom [x] is the factory default setting. • From the Paper menu, set Configure MP to Cassette in order for MP Feeder Type to appear as a menu.
Note: Only installed trays and feeders are listed in this menu.	

Use	To
Manual Paper Size A4 A5 A6 JIS B5 Letter Legal Executive Oficio (Mexico) Folio Statement Universal	Specify the size of the paper being manually loaded. **Note:** Letter is the US factory default setting. A4 is the international factory default setting.
Manual Paper Type Plain Paper Card Stock Transparency Recycled Glossy Labels Bond Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Custom Type [x]	Specify the type of the paper being manually loaded. **Notes:** • Plain Paper is the factory default setting. • From the Paper menu, set Configure MP to Manual in order for Manual Paper Type to appear as a menu.
Manual Envelope Size 7 3/4 Envelope 9 Envelope 10 Envelope DL Envelope C5 Envelope B5 Envelope Other Envelope	Specify the size of the envelope being manually loaded. **Note:** 10 Envelope is the US factory default setting. DL Envelope is the international factory default setting.
Manual Envelope Type Envelope Custom Type [x]	Specify the type of the envelope being manually loaded. **Note:** Envelope is the factory default setting.
Note: Only installed trays and feeders are listed in this menu.	

Configure MP menu

Use	To
Configure MP Cassette Manual First	Determine when the printer selects paper from the multipurpose feeder. **Notes:** • Cassette is the factory default setting. Cassette configures the multipurpose feeder as the automatic paper source. • Manual sets the multipurpose feeder only for manual-feed print jobs. • First configures the multipurpose feeder as the primary paper source.

Substitute Size menu

Use	To
Substitute Size Off Statement/A5 Letter/A4 All Listed	Substitute a specified paper size if the requested paper size is not available. **Notes:** • All Listed is the factory default setting. All available substitutions are allowed. • Off indicates that no size substitutions are allowed. • Setting a size substitution lets the print job continue without **Change Paper** appearing.

Paper Texture menu

Use	To
Plain Texture Smooth Normal Rough	Specify the relative texture of the plain paper loaded. **Note:** Normal is the factory default setting.
Card Stock Texture Smooth Normal Rough	Specify the relative texture of the card stock loaded. **Notes:** • Normal is the factory default setting. • The options appear only if card stock is supported.
Transparency Texture Smooth Normal Rough	Specify the relative texture of the transparencies loaded. **Note:** Normal is the factory default setting.
Recycled Texture Smooth Normal Rough	Specify the relative texture of the recycled paper loaded. **Note:** Normal is the factory default setting.

Use	To
Glossy Texture Smooth Normal Rough	Specify the relative texture of the glossy paper loaded. **Note:** Normal is the factory default setting.
Heavy Glossy Texture Smooth Normal Rough	Specify the relative texture of the heavy glossy paper loaded. **Note:** Normal is the factory default setting.
Labels Texture Smooth Normal Rough	Specify the relative texture of the labels loaded. **Note:** Normal is the factory default setting.
Bond Texture Smooth Normal Rough	Specify the relative texture of the bond paper loaded. **Note:** Rough is the factory default setting.
Envelope Texture Smooth Normal Rough	Specify the relative texture of the envelopes loaded. **Note:** Normal is the factory default setting.
Letterhead Texture Smooth Normal Rough	Specify the relative texture of the letterhead loaded. **Note:** Normal is the factory default setting.
Preprinted Texture Smooth Normal Rough	Specify the relative texture of the preprinted paper loaded. **Note:** Normal is the factory default setting.
Colored Texture Smooth Normal Rough	Specify the relative texture of the colored paper loaded. **Note:** Normal is the factory default setting.
Light Texture Smooth Normal Rough	Specify the relative texture of the light paper loaded. **Note:** Normal is the factory default setting.
Heavy Texture Smooth Normal Rough	Specify the relative texture of the heavy paper loaded. **Note:** Normal is the factory default setting.
Rough/Cotton Texture Rough	Specify the relative texture of the cotton paper loaded.

Use	To
Custom [x] Texture Smooth Normal Rough	Specify the relative texture of the custom paper loaded. **Notes:** • Normal is the factory default setting. • The options appear only if custom type is supported.

Paper Weight menu

Use	To
Plain Weight Light Normal Heavy	Specify the relative weight of the plain paper loaded. **Note:** Normal is the factory default setting.
Card Stock Weight Light Normal Heavy	Specify the relative weight of the card stock loaded. **Note:** Normal is the factory default setting.
Transparency Weight Light Normal Heavy	Specify the relative weight of the transparencies loaded. **Note:** Normal is the factory default setting.
Recycled Weight Light Normal Heavy	Specify the relative weight of the recycled paper loaded. **Note:** Normal is the factory default setting.
Glossy Weight Light Normal Heavy	Specify the relative weight of the glossy paper loaded. **Note:** Normal is the factory default setting.
Heavy Glossy Weight Light Normal Heavy	Specify the relative weight of the heavy glossy paper loaded. **Note:** Normal is the factory default setting.
Labels Weight Light Normal Heavy	Specify the relative weight of the labels loaded. **Note:** Normal is the factory default setting.
Bond Weight Light Normal Heavy	Specify the relative weight of the bond paper loaded. **Note:** Normal is the factory default setting.

Use	To
Envelope Weight Light Normal Heavy	Specify the relative weight of the envelope loaded. **Note:** Normal is the factory default setting.
Rough Envelope Weight Light Normal Heavy	Specify the relative weight of the rough envelope loaded. **Note:** Heavy is the factory default setting.
Letterhead Weight Light Normal Heavy	Specify the relative weight of the letterhead loaded. **Note:** Normal is the factory default setting.
Preprinted Weight Light Normal Heavy	Specify the relative weight of the preprinted paper loaded. **Note:** Normal is the factory default setting.
Colored Weight Light Normal Heavy	Specify the relative weight of the colored paper loaded. **Note:** Normal is the factory default setting.
Light Weight Light	Specify that the relative weight of the paper loaded is light.
Heavy Weight Heavy	Specify that the relative weight of the paper loaded is heavy.
Rough/Cotton Weight Light Normal Heavy	Specify the relative weight of the rough or cotton paper loaded. **Note:** Normal is the factory default setting.
Custom [x] Weight Light Normal Heavy	Specify the relative weight of the custom paper loaded. **Notes:** • Normal is the factory default setting. • The options appear only when the custom type is supported.

Paper Loading menu

Use	To
Cardstock Loading Off	Determine and set two-sided printing for all print jobs that specify Cardstock as the paper type.
Recycled Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Recycled as the paper type.
Glossy Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Glossy as the paper type.
Heavy Glossy Loading Off	Determine and set two-sided printing for all print jobs that specify Heavy Glossy as the paper type.
Labels Loading Off	Determine and set two-sided printing for all print jobs that specify Labels as the paper type.
Bond Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Bond as the paper type.
Letterhead Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Letterhead as the paper type.
Preprinted Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Preprinted as the paper type.
Colored Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Colored as the paper type.
Light Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Light as the paper type.
Heavy Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Heavy as the paper type.
Rough/Cotton Loading Off	Determine and set two-sided printing for all print jobs that specify Rough/Cotton as the paper type.

Notes:

- Duplex sets the printer default to two-sided printing for every print job unless one-sided printing is selected from Printing Preferences or the Print dialog.
- Off is the factory default setting for all the menus.

Use	To
Custom [x] Loading Duplex Off	Determine and set two-sided printing for all print jobs that specify Custom [x] as the paper type. **Note:** Custom [x] Loading is available only when the custom type is supported.

Notes:

- Duplex sets the printer default to two-sided printing for every print job unless one-sided printing is selected from Printing Preferences or the Print dialog.
- Off is the factory default setting for all the menus.

Custom Types menu

Use	To
Custom Type [x] Paper Card Stock Transparency Glossy Rough/Cotton Labels Envelope	Associate a paper or specialty media type with a factory default Custom Type [x] name or a user-defined custom name created in the Embedded Web Server or MarkVision™ Professional. **Notes:** • Paper is the factory default setting for Custom Type [x]. • The custom media type must be supported in the selected tray or feeder in order to print from that source.
Recycled Paper Card Stock Transparency Glossy Rough/Cotton Labels Envelope	Specify a paper type when Recycled is selected. **Notes:** • Paper is the factory default setting. • The Recycled paper type must be supported in the selected tray or feeder in order to print from that source.

Custom Names menu

Use	To
Custom Name [x]	Specify a custom name for a paper type. This name replaces Custom Type [x] in the printer menus.

Universal Setup menu

Use	To
Units of Measure Inches Millimeters	Identify the units of measure. **Notes:** • Inches is the US factory default setting. • Millimeters is the international factory default setting.

Use	To
Portrait Width 3–8.5 inches 76–216 mm	Set the width for portrait orientation. **Notes:** • If the width exceeds the maximum, then the printer uses the maximum width allowed. • 8.5 inches is the US factory default setting. You can increase the width in 0.01-inch increments. • 216 mm is the international factory default setting. You can increase the width in 1-mm increments.
Portrait Height 3–14.17 inches 76–360 mm	Set the width for portrait orientation. **Notes:** • If the height exceeds the maximum, then the printer uses the maximum height allowed. • 14 inches is the US factory default setting. You can increase the height in 0.01-inch increments. • 356 mm is the international factory default setting. You can increase the height in 1-mm increments.

Reports menu

Reports menu

Use	To
Menu Settings Page	Print a report containing information about paper loaded in trays, installed memory, the total page count, alarms, timeouts, the printer control panel language, the TCP/IP address, the status of supplies, the status of the network connection, and other information.
Device Statistics	Print a report containing printer statistics such as supply information and details about printed pages.
Network Setup Page	Print a report containing information about the network printer settings, such as the TCP/IP address. **Note:** This menu appears only in network printers or printers connected to print servers.
Network [x] Setup Page	Print a report containing information on network printer settings, such as the TCP/IP address information. **Notes:** • This menu item is available only when more than one network option is installed. • This menu item appears only in network printers or in printers connected to print servers.
Profiles List	Print a list of profiles stored in the printer.

Use	To
Print Fonts PCL Fonts PostScript Fonts	Print a report in English of all the fonts available for the printer language currently set in the printer. **Note:** A separate list is available for PCL and PostScript emulations. Each emulation report contains print samples and information about the available fonts for each language.
Print Demo Demo Page [list of available demo pages]	Print demo files that are available in the RIP code, the flash option, and the disk option.
Asset Report	Print a report containing asset information including the printer serial number and model name. The report contains text and UPC bar codes that can be scanned into an asset database.

Network/Ports menu

Active NIC menu

Use	To
Active NIC Auto [list of available network cards]	Allow the printer to connect to a network. **Notes:** • Auto is the factory default setting. • This menu item appears only if an optional network adapter is installed.

Standard Network or Network [x] menu

Note: Only active ports appear in this menu.

Use	To
PCL SmartSwitch On Off	Set the printer to automatically switch to PCL emulation when a print job requires it, regardless of the default printer language. **Notes:** • On is the factory default setting. • If PCL SmartSwitch is enabled, then the printer uses PostScript emulation. • If PCL SmartSwitch is disabled, then the printer does not examine incoming data and it uses the default printer language specified in the Setup menu.
PS SmartSwitch On Off	Set the printer to automatically switch to PS emulation when a print job requires it, regardless of the default printer language. **Notes:** • On is the factory default setting. • If PS SmartSwitch is enabled, then the printer uses PostScript emulation. • If PS SmartSwitch is disabled, then the printer does not examine incoming data and it uses the default printer language specified in the Setup menu.

Use	To
NPA Mode Off Auto	Set the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol. **Notes:** • Auto is the factory default setting. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Network Buffer Disabled Auto 3KB to [maximum size allowed]	Set the size of the network input buffer. **Notes:** • Auto is the factory default setting. • The value can be changed in 1-KB increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the Network Buffer, disable or reduce the size of the parallel, serial, and USB buffers. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Mac Binary PS On Off Auto	Set the printer to process Macintosh binary PostScript print jobs. **Notes:** • Auto is the factory default setting. • Off filters print jobs using the standard protocol. • On processes raw binary PostScript print jobs.
Standard Network Setup OR Network [x] Setup Reports Network Card TCP/IP IPv6 Wireless AppleTalk	Display and set the printer network settings. **Note:** The Wireless menu appears only when the printer is connected to a wireless network.

Reports menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **Reports**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Reports**

Use	To
Print Setup Page	Print a report containing information about the network printer settings, such as the TCP/IP address.

Network Card menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **Network Card**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **Network Card**

Use	To
View Card Status Connected Disconnected	View the connection status of the network card.
View Card Speed	View the speed of an active network card.
Network Address UAA LAA	View the network addresses.
Job Timeout 0, 10–225 seconds	Set the amount of time it takes for a network print job to be canceled. **Notes:** • 90 seconds is the factory default setting. • A setting value of 0 disables the timeout. • If a value between 1 and 9 is selected, then **Invalid** appears on the display, and the value is not saved.

TCP/IP menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **TCP/IP**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **TCP/IP**

Note: This menu is available only in network printers or printers connected to print servers.

Use	To
Set Hostname	Set the current TCP/IP host name. **Note:** This menu is available only in select printer models.
IP Address	View or change the current TCP/IP address. **Note:** Manually setting the IP address sets the Enable DHCP and Enable Auto IP settings to Off. It also sets Enable BOOTP and Enable RARP to Off on systems that support BOOTP and RARP.
Netmask	View or change the current TCP/IP netmask.
Gateway	View or change the current TCP/IP gateway.
Enable DHCP On Off	Specify the DHCP address and parameter assignment. **Note:** On is the factory default setting.
Enable RARP On Off	Specify the RARP address assignment setting. **Note:** Off is the factory default setting.

Use	To
Enable BOOTP On Off	Specify the BOOTP address assignment setting. **Note:** On is the factory default setting.
Enable AutoIP Yes No	Specify the Zero Configuration Networking setting. **Note:** Yes is the factory default setting.
Enable FTP/TFTP Yes No	Enable the built-in FTP server, which lets you send files to the printer using File Transfer Protocol. **Note:** Yes is the factory default setting.
Enable HTTP Server Yes No	Enable the built-in Web server (Embedded Web Server). When enabled, the printer can be monitored and managed remotely using a Web browser. **Note:** Yes is the factory default setting.
WINS Server Address	View or change the current WINS server address.
Enable DDNS Yes No	View or change the current DDNS setting. **Note:** Yes is the factory default setting.
Enable mDNS Yes No	View or change the current mDNS setting. **Note:** Yes is the factory default setting.
DNS Server Address	View or change the current DNS server address.
Backup DNS Server Address [x]	View or change the current DNS server address.
Enable HTTPS Yes No	View or change the current HTTPS setting. **Note:** Yes is the factory default setting.

IPv6 menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **IPv6**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **IPv6**

Note: This menu is available only in network printers or printers that are attached to print servers.

Use	To
Enable IPv6 On Off	Enable IPv6 in the printer. **Note:** On is the factory default setting.
Auto Configuration On Off	Specify whether or not the wireless network adapter accepts the automatic IPv6 address configuration entries provided by a router. **Note:** On is the factory default setting.

Use	To
View Hostname	Set the host name. **Note:** These settings can be changed only from the Embedded Web Server.
View Address	
View Router Address	
Enable DHCPv6 On Off	Enable DHCPv6 in the printer. **Note:** On is the factory default setting.

Wireless menu

Note: This menu is available only in printers connected to a wireless network or printer models that have a wireless network adapter.

To access the menu, navigate to:

Network/Ports > **Network [x]** > **Network [x] Setup** > **Wireless**

Use	To
Wi-Fi Protected Setup Start Push Button Method Start PIN Method	Establish a wireless network and enable network security. **Notes:** • Start Push Button Method connects the printer to a wireless network when buttons on both the printer and the access point (wireless router) are pressed within a given period of time. • Start PIN Method connects the printer to a wireless network when a PIN on the printer is entered into the wireless settings of the access point.
Enable/Disable WPS Auto-detection Enable Disable	Automatically detect the connection method that an access point with WPS uses—Start Push Button Method or Start PIN Method. **Note:** Disable is the factory default setting.
Network Mode BSS Type Infrastructure Ad hoc	Specify the network mode. **Notes:** • Infrastructure is the factory default setting. This lets the printer access a network using an access point. • Ad hoc configures wireless connection directly between the printer and a computer.
Compatibility 802.11b/g 802.11b/g/n	Specify the wireless standard for the wireless network. **Note:** 802.11b/g/n is the factory default setting.
Choose Network	Select an available network for the printer to use.
View Signal Quality	View the quality of the wireless connection.
View Security Mode	View the encryption method for the wireless network.

AppleTalk menu

Note: This menu is available only in printer models connected to a wired network or when an optional network card is installed.

To access the menu, navigate to any of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **AppleTalk**
- **Network/Ports** > **Network Setup [x]** > **AppleTalk**

Use	To
Activate Yes No	Enable or disable AppleTalk support. **Note:** Yes is the factory default setting.
View Name	Show the assigned AppleTalk name. **Note:** The name can be changed only from the Embedded Web Server.
View Address	Show the assigned AppleTalk address. **Note:** The address can be changed only from the Embedded Web Server.
Set Zone [list of zones available on the network]	Provide a list of AppleTalk zones available on the network. **Note:** The factory default setting is the default zone for the network. If no default zone exists, then the zone marked with an asterisk (*) is the default setting.

Standard USB menu

Use	To
PCL SmartSwitch On Off	Set the printer to automatically switch to PCL emulation when a print job received through a USB port requires it, regardless of the default printer language. **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PostScript emulation if the PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if the PS SmartSwitch is set to Off.
PS SmartSwitch On Off	Set the printer to automatically switch to PS emulation when a print job received through a USB port requires it, regardless of the default printer language. **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PCL emulation if the PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if the PCL SmartSwitch is set to Off.

Use	To
NPA Mode On Off Auto	Set the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol. **Notes:** • Auto is the factory default setting. Auto sets the printer to examine data, determine the format, and then process it appropriately. • The printer automatically restarts when changing the setting from the printer control panel. The menu selection is then updated.
USB Buffer Disabled Auto 3K to [maximum size allowed]	Set the size of the USB input buffer. **Notes:** • Auto is the factory default setting. • Disabled turns off job buffering. Any jobs already buffered on the printer hard disk are printed before normal processing resumes. • The USB buffer size value can be changed in 1-K increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the USB Buffer, disable or reduce the size of the parallel, serial, and network buffers. • The printer automatically restarts when the setting is changed from the printer control panel. The menu selection is then updated.
Job Buffering Off On Auto	Temporarily store print jobs in the printer hard disk before printing. **Notes:** • Off is the factory default setting. • On buffers jobs on the printer hard disk. • Auto buffers print jobs only if the printer is busy processing data from another input port. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Mac Binary PS On Off Auto	Set the printer to process Macintosh binary PostScript print jobs. **Notes:** • Auto is the factory default setting. • On processes raw binary PostScript print jobs. • Off filters print jobs using the standard protocol.
ENA Address yyy.yyy.yyy.yyy	Set the network address information for an external print server. **Note:** This menu is available only when the printer is attached to an external print server through the USB port.
ENA Netmask yyy.yyy.yyy.yyy	Set the netmask information for an external print server. **Note:** This menu is available only when the printer is attached to an external print server through the USB port.

Use	To
ENA Gateway yyy.yyy.yyy.yyy	Set the gateway information for an external print server. **Note:** This menu is available only when the printer is attached to an external print server through the USB port.

SMTP Setup menu

Use	To
Primary SMTP Gateway	Specify SMTP server gateway and port information. **Note:** 25 is the default SMTP gateway port.
Primary SMTP Gateway Port	
Secondary SMTP Gateway	
Secondary SMTP Gateway Port	
SMTP Timeout 5–30	Specify the amount of time in seconds before the server stops trying to send an e-mail. **Note:** 30 seconds is the factory default setting.
Reply Address	Specify a reply address of up to 128 characters in the e-mail sent by the printer.
Use SSL Disabled Negotiate Required	Set the printer to use SSL for increased security when connecting to the SMTP server. **Notes:** • Disabled is the factory default setting. • When the Negotiate setting is used, the SMTP server determines if SSL will be used.
SMTP Server Authentication No authentication required Login/Plain CRAM-MD5 Digest-MD5 NTLM Kerberos 5	Specify the type of user authentication required for printing privileges. **Note:** “No authentication required” is the factory default setting.
Device-Initiated E-mail None Use Device SMTP Credentials	Specify what credentials will be used when communicating to the SMTP server. Some SMTP servers require credentials to send an e-mail. **Notes:** • None is the factory default setting for Device-Initiated E-mail. • Device Userid and Device Password are used to log in to the SMTP server when Use Device SMTP Credentials is selected.
Device Userid	
Device Password	

Security menu

Miscellaneous Security Settings menu

Use	To
Login Restrictions Login failures Failure time frame Lockout time Panel Login Timeout Remote Login Timeout	Limit the number and time frames of failed login attempts from the printer control panel before *all* users are locked out. **Notes:** • "Login failures" specifies the number of failed login attempts before users are locked out. You can choose from 1 to 10 attempts. The factory default setting is 3. • "Failure time frame" specifies the time frame during which failed login attempts can be made before users are locked out. You can choose from 1 to 60 minutes. The factory default setting is 5 minutes. • "Lockout time" specifies how long users are locked out after exceeding the login failures limit. You can choose from 1 to 60 minutes. The factory default setting is 5 minutes. The printer does not impose a lockout time if you set to 1 minute. • Panel Login Timeout specifies how long the printer remains idle on the home screen before automatically logging the user off. You can choose from 1 to 900 seconds. The factory default setting is 30 seconds. • Remote Login Timeout specifies how long a remote interface remains idle before automatically logging the user off. You can choose from 1 to 120 minutes. The factory default setting is 10 minutes.
Minimum PIN Length 1–16	Limit the digit length of the PIN. **Note:** 4 is the factory default setting.

Confidential Print menu

Use	To
Max Invalid PIN Off 2–10	Limit the number of times an invalid PIN can be entered. **Notes:** • This menu appears only when a formatted, non-defective printer hard disk is installed. • Once the limit is reached, the print jobs for that user name and PIN are deleted.
Confidential Job Expiration Off 1 hour 4 hours 24 hours 1 week	Limit the amount of time a confidential print job stays in the printer before it is deleted. **Notes:** • If the "Confidential Job Expiration" setting is changed while confidential print jobs reside in the printer RAM or printer hard disk, then the expiration time for those print jobs does not change to the new default value. • If the printer is turned off, then all confidential jobs held in the printer RAM are deleted.
Note: Off is the factory default setting.	

Use	To
Repeat Job Expiration Off 1 hour 4 hours 24 hours 1 week	Set a time limit on how long the printer stores print jobs.
Verify Job Expiration Off 1 hour 4 hours 24 hours 1 week	Set a time limit on how long the printer stores print jobs needing verification.
Reserve Job Expiration Off 1 hour 4 hours 24 hours 1 week	Set a time limit on how long the printer stores print jobs for printing at a later time.
Note: Off is the factory default setting.	

Disk Wiping menu

Disk Wiping erases *only* print job data on the printer hard disk that *are not* currently in use by the file system. All permanent data on the printer hard disk are preserved, such as downloaded fonts, macros, and held jobs.

Note: This menu appears only when a formatted, non-defective printer hard disk is installed.

Use	To
Wiping Mode Auto	Specify the mode for disk wiping.
Automatic Method Single pass Multiple pass	Mark all disk space used by a previous print job. This method does not permit the file system to reuse this space until it has been cleared. **Notes:** • "Single pass" is the factory default setting. • Only automatic wiping enables users to activate disk wiping without having to turn the printer off for an extended amount of time. • Highly confidential information should be wiped using *only* the Multiple pass method.

Security Audit Log menu

Use	To
Export Log	Let an authorized user export the audit log. **Notes:** • To export the audit log from the printer control panel, attach a flash drive to the printer. • The audit log can be downloaded from the Embedded Web Server and saved on a computer.
Delete Log Yes No	Specify whether or not audit logs are deleted. **Note:** Yes is the factory default setting.
Configure Log Enable Audit Yes No Enable Remote Syslog No Yes Remote Syslog Facility 0–23 Severity of Events to Log 0–7	Specify how and whether or not audit logs are created. **Notes:** • Enable Audit determines if events are recorded in the secure audit log and remote syslog. No is the factory default setting. • Enable Remote Syslog determines if logs are sent to a remote server. No is the factory default setting. • Remote Syslog Facility determines the value used to send logs to the remote syslog server. 4 is the factory default setting. • If the security audit log is activated, then the severity value of each event is recorded. 4 is the factory default setting.

Set Date and Time menu

Use	To
Current Date and Time	View the current date and time settings for the printer.
Manually Set Date and Time	Enter the date and time. **Notes:** • Date/Time is set in YYYY-MM-DD HH:MM:SS format. • Manually setting the date and time sets “Enable NTP” (Network Time Protocol) to On.
Time Zone	Select the time zone. **Note:** GMT is the factory default setting.
Automatically Observe DST On Off	Set the printer to use the applicable daylight saving time (DST) start and end times associated with the printer Time Zone setting. **Note:** On is the factory default setting and uses the applicable Daylight Saving Time associated with the Time Zone setting.
Enable NTP On Off	Enable Network Time Protocol, which synchronizes the clocks of devices on a network. **Note:** On is the factory default setting.

Settings menu

Setup menu

Use	To
Printer Language PCL Emulation PS Emulation	Set the default printer language. **Notes:** • PS Emulation is the factory default setting. PS Emulation uses a PS interpreter for processing print jobs. • PCL Emulation uses a PCL interpreter for processing print jobs. • Setting a printer language as the default does not prevent a software program from sending print jobs that use another printer language.
Job Waiting On Off	Determine if print jobs are removed from the print queue when they require unavailable printer options or custom settings. These print jobs are stored in a separate print queue, so other jobs print normally. When the missing information or options are obtained, the stored jobs print. **Notes:** • Off is the factory default setting. • This menu item appears only if a non-read-only printer hard disk is installed. This requirement ensures that stored jobs are not deleted if the printer loses power.
Print Area Normal Fit To Page Whole Page	Set the logical and physical printable area. **Notes:** • Normal is the factory default setting. When attempting to print data in the non-printable area defined by the Normal setting, the printer clips the image. • Fit to Page fits the page content into the selected paper size. • Whole Page allows the image to be moved into the non-printable area defined by the Normal setting, but the printer clips the image at the Normal setting boundary. This setting affects only pages printed using a PCL 5e interpreter and has no effect on pages printed using the PCL XL or PostScript interpreter.
Printer Usage Max Yield Max Speed	Set color toner use in printing. **Note:** Max Yield is the factory default setting.

Use	To
Black Only Mode On Off	Set the printer to print text and graphics using only the black toner cartridge. **Notes:** • Off is the factory default setting. • The setting value does not affect the ability of the printer to generate color output from flash drive print jobs.
Download Target RAM Flash Disk	Set the storage location for downloads. **Notes:** • RAM is the factory default setting. Storing downloads in the RAM is temporary. • Storing downloads in a flash memory or on a printer hard disk places them in permanent storage. Downloads remain in the flash memory or printer hard disk even when the printer is turned off. • This menu item appears only if an optional flash memory or printer hard disk is installed.
Resource Save On Off	Specify how the printer handles temporary downloads, such as fonts and macros stored in the RAM, when the printer receives a job that requires more memory than is available. **Notes:** • Off is the factory default setting. Off sets the printer to retain the downloads only until memory is needed. Downloads are deleted in order to process print jobs. • On sets the printer to retain downloads during language changes and printer resets. If the printer runs out of memory, **38 Memory full** appears, but downloads are not deleted.
Print All Order Alphabetical Oldest First Newest First	Specify the order in which held and confidential jobs are printed . **Note:** Alphabetical is the factory default setting.

General Settings

General Settings menu

Use	To
Display Language English Francais Deutsch Italiano Espanol Dansk Norsk Nederlands Svenska Portuguese Suomi Russian Polski Greek Magyar Turkce Cesky Simplified Chinese Traditional Chinese Korean Japanese (Kanji)	Set the language of the text that appears on the printer display. **Note:** Not all languages are available for all printer models, and you may need to install special hardware for those languages to appear.
Show Supply Estimates Show estimates Do not show estimates	Display the estimates of the supplies on the printer control panel, Web page, menu settings, and the device statistics reports. **Note:** "Show estimates" is the factory default setting.
Eco-Mode Eco-Mode Off Energy Energy/Paper Paper	Minimize the use of energy, paper, or specialty media. **Notes:** • Off is the factory default setting. Off resets the printer to its factory default settings. • Energy minimizes the power used by the printer. Performance may be affected, but print quality is not. • Energy/Paper minimizes the use of power and of paper and specialty media. • Paper minimizes the amount of paper and specialty media needed for a print job. Performance may be affected, but print quality is not.

Use	To
Quiet Mode Quiet Mode Off On	Reduce the amount of noise produced by the printer. **Notes:** • Off is the factory default setting. This setting supports the performance specifications for your printer. • On configures the printer to produce as little noise as possible. This setting is best suited for printing text and line art. • For optimal printing of color-rich documents, set Quiet mode to Off. • Selecting Photo from the printer driver may disable Quiet mode and provide better print quality and full-speed printing.
Run Initial setup Yes No	Instruct the printer to run the setup wizard. **Notes:** • Yes is the factory default setting. • After you complete the setup wizard by selecting Done from the “Country select” screen, the default setting becomes No.
Keyboard Keyboard Type English Francais Francais Canadien Deutsch Italiano Espanol Greek Dansk Norsk Nederlands Svenska Suomi Portuguese Russian Polski Swiss German Swiss French Korean Magyar Turkce Cesky Simplified Chinese Traditional Chinese Japanese (Kanji) Custom Key [x]	Specify a language and custom key information for the printer control panel keyboard. The additional tabs enable access to accent marks and symbols.

Use	To
Paper Sizes US Metric	Specify the unit of measurement for paper sizes. **Notes:** • US is the factory default setting. • The initial setting is determined by your country or region selection in the initial setup wizard.
Displayed Information Left Side Right Side Custom Text [x]	Specify what is displayed on the upper left and right corners of the home screen. For the Left Side and Right Side options, select from the following options: None IP Address Hostname Contact Name Location Date/Time mDNS/DDNS Service Name Zero Configuration Name Custom Text [x] Model Name **Notes:** • IP Address is the factory default setting for Left Side. • Date/Time is the factory default setting for Right Side.
Displayed Information (Continued) Black Toner Cyan Toner Magenta Toner Yellow Toner Waste Toner Bottle Fuser Transfer Module	Customize the displayed information for Black Toner. Select from the following options: When to display Do not display Display Message to display Default Alternate Default [text entry] Alternate [text entry] **Notes:** • “Do not display” is the factory default setting for “When to display.” • Default is the factory default setting for “Message to display.”

Use	To
Displayed Information (Continued) Paper Jam Load Paper Service Errors	Customize the displayed information for Waste Toner Bottle, Paper Jam, Load Paper, and Service Errors. Select from the following options: Display Yes No Message to display Default Alternate Default [text entry] Alternate [text entry] **Notes:** • No is the factory default setting for “Display.” • Default is the factory default setting for “Message to display.”
Home screen customization Change Language Search Held Jobs Held Jobs USB Drive Profiles and Solutions Bookmarks Jobs by user	Change the icons and buttons that appear on the home screen. For each icon or button, select from the following options: Display Do not display **Notes:** • Display is the factory default setting for Search Held Jobs, Held Jobs, and USB Drive. • “Do not display” is the factory default setting for “Change Language,” “Profiles and Solutions,” “Bookmarks,” and “Jobs by user.” • “Search Held Jobs” and “Profiles and Solutions” appear only if one or more held jobs exist on the printer. • USB Drive appears only if a USB drive is installed on the printer.
Home screen customization (Continued) Forms and Favorites Background and Idle Screen Eco-Settings	Change the icons and buttons that appear on the home screen. For each icon or button, select from the following options: Display Do not display **Note:** Display is the factory default setting.
Date Format MM-DD-YYYY DD-MM-YYYY YYYY-MM-DD	Format the printer date. **Notes:** • MM-DD-YYYY is the US factory default setting. • DD-MM-YYYY is the international factory default setting.

Use	To
Time Format 12 hour A.M./P.M. 24 hour clock	Format the printer time. **Note:** "12 hour A.M./P.M." is the factory default setting.
Screen Brightness 20–100	Specify the brightness of the display. **Note:** 100 is the factory default setting.
Audio Feedback Button Feedback On Off Volume 1–10	Specify whether icons and buttons have audio feedback. **Notes:** • On is the factory default setting for Button Feedback. • 5 is the factory default setting for Volume.
Show Bookmarks Yes No	Specify whether bookmarks are displayed from the Held Jobs area. **Note:** Yes is the factory default setting. When Yes is selected, bookmarks appear in the Held Jobs area.
Web Page Refresh Rate 30–300	Specify the number of seconds between Embedded Web Server refreshes. **Note:** 120 is the factory default setting.
Contact Name	Specify a contact name for the printer. **Note:** The contact name will be stored on the Embedded Web Server.
Location	Specify the location of the printer. **Note:** The location will be stored on the Embedded Web Server.
Alarms Alarm Control Off Single Continuous Cartridge Alarm Off Single Continuous	Set an alarm to sound when the printer requires user intervention. For each alarm type, select from the following options: Off Single Continuous **Notes:** • Single is the factory default setting. Single sounds three quick beeps. • Off means no alarm will sound. • Continuous repeats three beeps every 10 seconds.
Timeouts Standby Mode Disabled 1–240	Specify the number of minutes of inactivity before the printer enters a lower power state. **Note:** 15 is the factory default setting.

Use	To
Timeouts (Continued) Sleep Mode Disabled 1–180	Set the amount of time in minutes the printer waits after a job is printed before it goes into a reduced power state. **Notes:** • 30 is the factory default setting. • Disabled appears only when Energy Conserve is set to Off. • Lower settings conserve more energy, but may require longer warm-up times. • Select a high setting if the printer is in constant use. Under most circumstances, this keeps the printer ready to print with minimum warm-up time.
Timeouts (Continued) Hibernate Timeout Disabled 1 hour 2 hours 3 hours 6 hours 1 day 2 days 3 days 1 week 2 weeks 1 month	Set the printer to operate at a low power state. **Notes:** • When the Hibernate Timeout timer expires, the printer uses Ethernet connection to check the value of “Hibernate Timeout on Connection.” • If “Hibernate Timeout on Connection” is set to “Do Not Hibernate,” then the device never automatically hibernates. • If “Hibernate Timeout on Connection” is set to “Hibernate,” then the device follows the value of the “Hibernate Timeout” setting, except when it is set to Disabled. • Disabled is the factory default setting except in Canada, Switzerland, and countries in the European Union. • “3 days” is the factory default setting in Canada, Switzerland, and countries in the European Union.
Timeouts (Continued) Screen Timeout 15–300	Set the amount of time in seconds the printer waits before returning the display to Ready state. **Note:** 30 is the factory default setting.
Timeouts (Continued) Prolong Screen Timeout On Of	Set the printer to continue the specified job without returning to the home screen when the Screen Timeout timer expires. **Notes:** • On allows the user to reset the Screen Timeout timer instead of returning to Ready state. • Off follows value of the normal Screen Timeout setting. • Off is the factory default setting.

Use	To
Timeouts (Continued) Print Timeout Disabled 1–255	Set the amount of time in seconds the printer waits to receive an end-of-job message before canceling the remainder of the print job. **Notes:** • 90 is the factory default setting. • When the timer expires, any partially printed page still in the printer is printed, and then the scanner checks to see if any new print jobs are waiting. • Print Timeout is available only when using PCL emulation. This setting has no effect on PostScript emulation print jobs.
Timeouts (Continued) Wait Timeout Disabled 15–65535	Set the amount of time in seconds the printer waits for additional data before canceling a print job. **Notes:** • 40 is the factory default setting. • Wait Timeout is available only when the scanner is using PostScript emulation. This setting has no effect on PCL emulation print jobs.
Timeouts (Continued) Job Hold Timeout 5–255	Set the amount of time in seconds the printer waits for user intervention before it holds jobs that require unavailable resources and continues to print other jobs in the print queue. **Notes:** • 30 is the factory default setting. • This menu appears only when a printer hard disk is installed.
Error Recovery Auto Reboot Reboot when idle Reboot always Reboot never Max Auto Reboots 1–20	Set the printer to restart when an error is encountered. **Notes:** • “Reboot when idle” is the factory default setting for Auto Reboot. • 5 is the factory default setting for Max Auto Reboots. • If the printer performs a number of automatic reboots that is the same as the menu setting within a certain amount of time, then the printer shows the applicable error instead of restarting.
Print Recovery Auto Continue Disabled 5–255	Let the printer automatically continue printing from certain offline situations when these are not resolved within the specified time period. **Note:** Disabled is the factory default setting.

Use	To
Print Recovery (Continued) Jam Recovery On Off Auto	Specify whether the printer reprints jammed pages. **Notes:** • Auto is the factory default setting. The printer reprints jammed pages unless the memory required to hold the pages is needed for other printer tasks. • On sets the printer to always reprint jammed pages. • Off sets the printer to never reprint jammed pages.
Print Recovery (Continued) Page Protect Off On	Let the printer successfully print a page that may not have printed otherwise. **Notes:** • Off is the factory default setting. Off prints a partial page when there is not enough memory to print the whole page. • On sets the printer to process the whole page so that the entire page prints.
Hibernate Timeout on Connection Hibernate Do Not Hibernate	Set the printer to follow the setting of “Hibernate Timeout” even when an active Ethernet connection exists. **Notes:** • If “Hibernate Timeout on Connection” is set to “Do Not Hibernate,” then the device never automatically hibernates. • If “Hibernate Timeout on Connection” is set to “Hibernate,” then the device follows the value of the “Hibernate Timeout” setting, except when it is set to Disabled. • “Do Not Hibernate” is the factory default setting.
Press Sleep Button Do Nothing Sleep Hibernate	Determine how the printer, while in idle state, reacts to a short press of the Sleep button. **Note:** Sleep is the factory default setting.
Press and Hold Sleep Button Do Nothing Sleep Hibernate	Determine how the printer, while in idle state, reacts to a long press of the Sleep button. **Note:** “Do nothing” is the factory default setting.
GUI Log Level Everything (0) Keys (1) Debug (2) Warnings (3) Errors (4) Critical (5) System Info (6)	Store the amount of log files populated from the GUI component, where each log entry is marked at a certain level.

Use	To
Factory Defaults Do Not Restore Restore Now	Restore the printer settings to the factory default settings. **Notes:** • Do Not Restore is the factory default setting. Do Not Restore keeps the user-defined settings. • Restore Now restores all printer settings to the factory default settings except Network/Ports menu settings. All downloads stored in the RAM are deleted. Downloads stored in the flash memory or in the printer hard disk are not affected.
Export Configuration Package Export	Export the printer configuration package to a flash drive. **Note:** Make sure a flash drive is attached to the printer.

Flash Drive

Flash Drive menu

Use	To
Copies 1–999	Specify a default number of copies for each print job. **Note:** 1 is the factory default setting.
Paper Source Tray [x] MP Feeder Manual Paper Manual Envelope	Set a default paper source for all print jobs. **Note:** Tray 1 is the factory default setting.
Color Color Black Only	Generate color or black-and-white outputs. **Notes:** • Color is the factory default setting. • This setting can generate color output only from a flash drive print job.
Collate 1,1,1–2,2,2 1,2,3–1,2,3	Stack the pages of a print job in sequence when printing multiple copies. **Note:** 1,2,3–1,2,3 is the factory default setting.
Sides (Duplex) 1 sided 2 sided	Specify whether prints are on one side or on both sides of the paper. **Note:** “1 sided” is the factory default setting.
Duplex Binding Long Edge Short Edge	Define binding for duplexed pages in relation to paper orientation. **Notes:** • Long Edge is the factory default setting. Long Edge assumes binding along the long edge of the page (left edge for portrait and top edge for landscape). • Short Edge assumes binding along the short edge of the page (top edge for portrait and left edge for landscape).

Use	To
Paper Saver Orientation Auto Landscape Portrait	Specify the orientation of a multiple-page document. **Notes:** • Auto is the factory default setting. The printer chooses between portrait and landscape. • This setting affects jobs only when Paper Saver is set to any value other than Off.
Paper Saver Off 2-Up 3-Up 4-Up 6-Up 9-Up 12-Up 16-Up	Print multiple-page images on one side of the paper. **Notes:** • Off is the factory default setting. • The number selected is the number of page images that will print per side.
Paper Saver Border None Solid	Print a border on each page image when using Paper Saver Border. **Notes:** • None is the factory default setting. • This setting affects jobs only when Paper Saver is set to any value other than Off.
Paper Saver Ordering Horizontal Reverse Horizontal Reverse Vertical Vertical	Specify the positioning of multiple-page images when using Paper Saver Ordering. **Notes:** • Horizontal is the factory default setting. • Positioning depends on the number of page images and whether they are in portrait or landscape orientation. • This setting affects jobs only when Paper Saver is set to any value other than Off.
Separator Sheets Off Between Copies Between Jobs Between Pages	Specify whether blank separator sheets are inserted. **Notes:** • Off is the factory default setting. • Between Copies inserts a blank sheet between each copy of a print job when Collate is set to On. When Collate is set to Off, then a blank page is inserted between each set of printed pages, such as after all page 1's and after all page 2's. • Between Jobs inserts a blank sheet between print jobs. • Between Pages inserts a blank sheet between each page of the print job. This setting is useful when printing transparencies or inserting blank pages in a document for notes.
Separator Sheet Source Tray [x] Manual Feeder	Specify the paper source for separator sheets. **Note:** Tray 1 is the factory default setting.

Use	To
Blank Pages Do Not Print Print	Specify whether blank pages are inserted in a print job. **Note:** Do Not Print is the factory default setting.

Print Settings

Finishing menu

Use	To
Sides (Duplex) 1 sided 2 sided	Specify whether two-sided (duplex) printing is set as the default setting for all print jobs. **Notes:** • "1 sided" is the factory default setting. • You can set two-sided printing from the software program. For Windows users: Click **File** > **Print**, and then click **Properties**, **Preferences**, **Options**, or **Setup**. For Macintosh users: Choose **File** > **Print**, and then adjust the settings from the Print dialog and pop-up menus.
Duplex Binding Long Edge Short Edge	Define binding for duplexed pages in relation to paper orientation. **Notes:** • Long Edge is the factory default setting. This assumes binding along the long edge of the page (left edge for portrait and top edge for landscape). • Short Edge assumes binding along the short edge of the page (top edge for portrait and left edge for landscape).
Copies 1–999	Specify the default number of copies for each print job. **Note:** 1 is the factory default setting.
Blank Pages Do Not Print Print	Specify whether blank pages are inserted in a print job. **Note:** Do Not Print is the factory default setting.
Collate (1,1,1) (2,2,2) (1,2,3) (1,2,3)	Stack the pages of a print job in sequence when printing multiple copies. **Note:** "(1,1,1) (2,2,2)" is the factory default setting.

Use	To
Separator Sheets Off Between Copies Between Jobs Between Pages	Specify whether blank separator sheets are inserted. **Notes:** • Off is the factory default setting. • Between Copies inserts a blank sheet between each copy of a print job when Collate is set to On. When Collate is set to Off, then a blank page is inserted between each set of printed pages, such as after all page 1's and after all page 2's. • Between Jobs inserts a blank sheet between print jobs. • Between Pages inserts a blank sheet between each page of the print job. This setting is useful when printing transparencies or when inserting blank pages in a document.
Separator Source Tray [x] Manual Feeder	Specify the paper source for separator sheets. **Note:** Tray 1 (standard tray) is the factory default setting.
Paper Saver Off 2-Up 3-Up 4-Up 6-Up 9-Up 12-Up 16-Up	Specify that multiple-page images be printed on one side of a paper. **Notes:** • Off is the factory default setting. • The number selected is the number of page images that will print per side.
Paper Saver Ordering Horizontal Reverse Horizontal Reverse Vertical Vertical	Specify the positioning of multiple-page images. **Notes:** • Horizontal is the factory default setting. • Positioning depends on the number of images and whether they are in portrait or in landscape orientation. • This setting affects jobs only when Paper Saver is set to any value other than Off.
Paper Saver Orientation Auto Landscape Portrait	Specify the orientation of a multiple-page document. **Notes:** • Auto is the factory default setting. • This setting affects jobs only when Paper Saver is set to any value other than Off.
Paper Saver Border None Solid	Print a border around each page. **Notes:** • None is the factory default setting. • This setting affects jobs only when Paper Saver is set to any value other than Off.

Quality menu

Use	To
Print Mode Color Black Only	Specify whether images are printed in black and white or in color. **Notes:** • Color is the factory default setting. • The printer driver is capable of overriding this setting.
Color Correction Auto Off Manual	Adjust the color output on the printed page. **Notes:** • Auto is the factory default setting. Auto applies different color conversion tables to each object on the printed page. • Off turns off color correction. • Manual allows customization of the color tables using the settings available from the Manual Color menu. • Due to the differences in additive and subtractive colors, certain colors that appear on computer monitors are impossible to duplicate on the printed page.
Print Resolution 1200 dpi 4800 CQ	Specify the printed output resolution in dots per inch or in color quality (CQ). **Note:** 4800 CQ is the factory default setting.
Toner Darkness 1–5	Lighten or darken the printed output. **Notes:** • 4 is the factory default setting. • Selecting a smaller number can help conserve toner.
Enhance Fine Lines On Off	Enable a print mode preferable for files such as architectural drawings, maps, electrical circuit diagrams, and flow charts. **Notes:** • Off is the factory default setting. • To set this option using the Embedded Web Server, type the network printer IP address in the Web browser address field. • You can set this option from the software program. For Windows users: Click **File** > **Print**, and then click **Properties**, **Preferences**, **Options**, or **Setup**. For Macintosh users: Choose **File** > **Print**, and then adjust the settings from the print dialog and pop-up menus.
Color Saver On Off	Reduce the amount of toner used for graphics and images. The amount of toner used for text is not reduced. **Notes:** • Off is the factory default setting. • On overrides Toner Darkness settings.

Use	To
RGB Brightness -6 to 6	Adjust the printed output either by lightening or darkening it. You can conserve toner by lightening the output. **Note:** 0 is the factory default setting.
RGB Contrast 0–5	Adjust the contrast of printed objects. **Note:** 0 is the factory default setting.
RGB Saturation 0–5	Adjust saturation in color outputs. **Note:** 0 is the factory default setting.
Color Balance Cyan -5 to 5 Magenta -5 to 5 Yellow -5 to 5 Black -5 to 5 Reset Defaults	Adjust color in printed output by increasing or decreasing the amount of toner being used for each color. **Note:** 0 is the factory default setting.
Color Samples sRGB Display sRGB Vivid Display—True Black Vivid Off—RGB US CMYK Euro CMYK Vivid CMYK Off—CMYK	Print sample pages for each of the RGB and CMYK color conversion tables used in the printer. **Notes:** • Selecting any setting prints the sample. • Color samples consist of a series of colored boxes along with the RGB or CMYK combination that creates the color observed. These pages can be used to help decide which combinations to use to get the desired printed output. • To access a complete list of color sample pages using the Embedded Web Server, type the network printer IP address in the Web browser address field.

Use	To
Manual Color RGB Image RGB Text RGB Graphics	Customize the RGB color conversions. Select from the following options: Vivid sRGB Display Display—True Black sRGB Vivid Off **Notes:** • sRGB Display is the factory default setting for RGB Image. This applies a color conversion table to an output that matches the colors displayed on a computer monitor. • sRGB Vivid is the factory default setting for RGB Text and RGB Graphics. sRGB Vivid applies a color table that increases saturation. This is preferred for business graphics and text. • Vivid applies a color conversion table that produces brighter, more saturated colors. • Display—True Black applies a color conversion table that uses only black toner for neutral gray colors. • Off turns off color conversion.
Manual Color (continued) CMYK Image CMYK Text CMYK Graphics	Customize the CMYK color conversions. Select from the following options: US CMYK Euro CMYK Vivid CMYK Off **Notes:** • US CMYK is the factory default setting. US CMYK applies a color conversion table that tries to produce output that matches SWOP color output. • Euro CMYK is the international factory default setting. Euro CMYK applies a color conversion table that tries to produce output that matches Euroscale color output. • Vivid CMYK increases color saturation for the US conversion table. • Off turns off color conversion.
Spot Color Replacement	Assign specific CMYK values to named spot colors.
Color Adjust	Initiate a recalibration of color conversion tables and allow the printer to make adjustments for color variations in output. **Notes:** • Adjusting color starts when the menu is selected. **`Adjusting color`** appears on the display until the process is finished. • Color variations in output sometimes result from changeable conditions such as room temperature and humidity. Color adjustments are made on printer algorithms. Color alignment is also recalibrated in this process.

Job Accounting menu

Note: This menu appears only when a formatted, non-defective printer hard disk is installed. Make sure the printer hard disk is not read/write- or write-protected.

Use	To
Job Accounting Log Off On	Determine and set if the printer creates a log of the print jobs it receives. **Note:** Off is the factory default setting.
Job Accounting Utilities	Print and delete log files or export them to a flash drive.
Accounting Log Frequency Weekly Monthly	Determine and set how often a log file is created. **Note:** Monthly is the factory default setting.
Log Action at End of Frequency None E-mail Current Log E-mail & Delete Current Log Post Current Log Post & Delete Current Log	Determine and set how the printer responds when the frequency threshold expires. **Note:** None is the factory default setting.
Disk Near Full Level Off 1–99	Specify the maximum size of the log file. **Note:** 5 is the factory default setting.
Disk Near Full Action None E-mail Current Log E-mail & Delete Current Log E-mail & Delete Oldest Log Post Current Log Post & Delete Current Log Post & Delete Oldest Log Delete Current Log Delete Oldest Log Delete All Logs Delete All But Current	Determine and set how the printer responds when the printer hard disk is nearly full. **Notes:** • None is the factory default setting. • The value defined in Disk Near Full Level determines when this action is triggered.
Disk Full Action None E-mail & Delete Current Log E-mail & Delete Oldest Log Post & Delete Current Log Post & Delete Oldest Log Delete Current Log Delete Oldest Log Delete All Logs Delete All But Current	Determine and set how the printer responds when disk usage reaches the maximum limit (100MB). **Note:** None is the factory default setting.
URL to Post Logs	Determine and set where the printer posts job accounting logs.

Use	To
E-mail to Send Logs	Specify the e-mail address to which the device sends job accounting logs.
Log File Prefix	Specify the prefix you want for the log file name. **Note:** The current host name defined in the TCP/IP menu is used as the default log file prefix.

Utilities menu

Use	To
Remove Held Jobs Confidential Held Not Restored All	Delete confidential and held jobs from the printer hard disk. **Notes:** • Selecting a setting affects only print jobs that are resident in the printer. Bookmarks, print jobs on flash drives, and other types of held jobs are not affected. • Not Restored removes all Print and Hold jobs that are *not* restored from the printer hard disk or memory.
Format Flash Yes No	Format the flash memory. **Warning—Potential Damage:** Do not turn off the printer while the flash memory is being formatted. **Notes:** • Yes deletes all data stored in flash memory. • No cancels the format request. • Flash memory refers to the memory added by installing a flash memory card in the printer. • The flash memory option card must not be read/write- or write-protected. • This menu item appears only when a non-defective flash memory card is installed.
Delete Downloads on Disk Delete Now Do Not Delete	Delete downloads from the printer hard disk, including all held jobs, buffered jobs, and parked jobs. **Notes:** • Delete Now sets the printer to delete the downloads and allows the display to return to the originating screen after the deletion. • Do Not Delete sets the printer display to return to the main Utilities menu for touch-screen printer models. When selected in non-touch-screen printer models, Do Not Delete sets the printer to return to the originating screen after the deletion.
Activate Hex Trace	Assist in isolating the source of a print job problem. **Notes:** • When activated, all data sent to the printer is printed in hexadecimal and character representation, and control codes are not executed. • To exit or deactivate Hex Trace, turn off or reset the printer.

Use	To
Coverage Estimator Off On	Provide an estimate of the percentage coverage of toner on a page. The estimate is printed on a separate page at the end of each print job. **Note:** Off is the factory default setting.

XPS menu

Use	To
Print Error Pages Off On	Print a page containing information on errors, including XML markup errors. **Note:** Off is the factory default setting.

PDF menu

Use	To
Scale to Fit Yes No	Scale page content to fit the selected paper size. **Note:** No is the factory default setting.
Annotations Do Not Print Print	Print annotations in a PDF. **Note:** Do Not Print is the factory default setting.

PostScript menu

Use	To
Print PS Error On Off	Print a page containing the PostScript error. **Note:** Off is the factory default setting.
Lock PS Startup Mode On Off	Enable users to disable the SysStart file. **Note:** Off is the factory default setting.
Font Priority Resident Flash/Disk	Establish the font search order. **Notes:** • Resident is the factory default setting. • This menu item appears only when a formatted, non-defective flash memory option card or printer hard disk is installed. • Make sure the flash memory option or printer hard disk is not read/write-, write-, or password-protected. • Job Buffer Size must not be set to 100%.

Use	To
Image Smoothing On Off	Enhance the contrast and sharpness of low-resolution images and smoothen their color transitions. **Notes:** • Off is the factory default setting. • Image Smoothing has no effect on images that are 300 dpi or higher in resolution.

PCL Emul menu

Use	To
Font Source Resident Download All	Specify the set of fonts used in the Font Name menu. **Notes:** • "Resident" is the factory default setting. It shows the factory default set of fonts downloaded in the RAM. • "Download" shows all the fonts downloaded in the RAM. • "All" shows all fonts available to any option.
Font Name Courier 10	Identify a specific font and where it is stored. **Note:** Courier 10 is the factory default setting.
Symbol Set 10U PC-8 12U PC-850	Specify the symbol set for each font name. **Notes:** • 10U PC-8 is the US factory default setting. 12U PC-850 is the international factory default setting. • A symbol set is a set of alphabetical and numeric characters, punctuation, and special symbols. Symbol sets support the different languages or specific programs, such as math symbols for scientific text. Only the supported symbol sets are shown.
PCL Emulation Settings Point Size 1.00–1008.00	Change the point size for scalable typographic fonts. **Notes:** • 12 is the factory default setting. • Point size refers to the height of the characters in the font. One point equals approximately 0.014 of an inch. This can be increased or decreased in 0.25-point increments.
PCL Emulation Settings Pitch 0.08–100.00	Specify the font pitch for scalable monospaced fonts. **Notes:** • 10 is the factory default setting. • Pitch refers to the number of fixed-space characters per inch (cpi). This can be increased or decreased in 0.01-cpi increments. • For non-scalable monospaced fonts, the pitch appears on the display but cannot be changed.

Use	To
PCL Emulation Settings Orientation Portrait Landscape	Specify the orientation of text and graphics on a page. **Notes:** • Portrait is the factory default setting. It prints text and graphics parallel to the short edge of the page. • Landscape prints text and graphics parallel to the long edge of the page.
PCL Emulation Settings Lines per Page 1–255	Specify the number of lines that print on each page. **Notes:** • 60 is the US factory default setting. 64 is the international default setting. • The printer sets the amount of space between each line based on the Lines per Page, Paper Size, and Orientation settings. Select the paper size and orientation before setting Lines per Page.
PCL Emulation Settings A4 Width 198 mm 203 mm	Set the printer to print on A4-size paper. **Notes:** • 198 mm is the factory default setting. • The 203-mm setting sets the width of the page to allow the printing of eighty 10-pitch characters.
PCL Emulation Settings Auto CR after LF On Off	Specify whether the printer automatically performs a carriage return (CR) after a line feed (LF) control command. **Note:** Off is the factory default setting.
PCL Emulation Settings Auto LF after CR On Off	Specify whether the printer automatically performs a line feed (LF) after a carriage return (CR) control command. **Note:** Off is the factory default setting.
Tray Renumber Assign MP Feeder Off None 0–199 Assign Tray [x] Off None 0–199 Assign Manual Paper Off None 0–199 Assign Manual Envelope Off None 0–199	Configure the printer to work with printer software or programs that use different source assignments for trays and feeders. **Notes:** • “Off” is the factory default setting. • “None” ignores the Select Paper Feed command. This option appears only when it is selected by the PCL 5e interpreter. • “0–199” allows a custom setting to be assigned.

Use	To
Tray Renumber View Factory Defaults MPF Default = 8 T1 Default = 1 T2 Default = 4 T3 Default = 5 T4 Default = 20 T5 Default = 21 Env Default = 6 MPaper Default = 2 MEnv Default = 3	Show the factory default setting assigned to each tray or feeder.
Tray Renumber Restore Defaults Yes No	Restore all tray and feeder assignments to the factory default settings.

HTML menu

Use		To
Font Name Albertus MT Antique Olive Apple Chancery Arial MT Avant Garde Bodoni Bookman Chicago Clarendon Cooper Black Copperplate Coronet Courier Eurostile Garamond Geneva Gill Sans Goudy Helvetica Hoefler Text Intl CG Times Intl Courier Intl Univers	Joanna MT Letter Gothic Lubalin Graph Marigold MonaLisa Recut Monaco New CenturySbk New York Optima Oxford Palatino StempelGaramond Taffy Times TimesNewRoman Univers Zapf Chancery NewSansMTCS NewSansMTCT New SansMTJA NewSansMTKO	Set the default font for HTML documents. **Note:** The Times font is used in HTML documents that do not specify a font.

Use	To
Font Size 1–255 pt	Set the default font size for HTML documents. **Notes:** • 12 pt is the factory default setting. • Font size can be increased in 1-point increments.
Scale 1–400%	Scale the default font for HTML documents. **Notes:** • 100% is the factory default setting. • Scaling can be increased in 1% increments.
Orientation Portrait Landscape	Set the page orientation for HTML documents. **Note:** Portrait is the factory default setting.
Margin Size 8–255 mm	Set the page margin for HTML documents. **Notes:** • 19 mm is the factory default setting. • Margin size can be increased in 1-mm increments.
Backgrounds Do Not Print Print	Specify whether to print backgrounds on HTML documents. **Note:** Print is the factory default setting.

Image menu

Use	To
Auto Fit On Off	Select the optimal paper size, scaling, and orientation. **Note:** On is the factory default setting. It overrides scaling and orientation settings for some images.
Invert On Off	Invert bitonal monochrome images. **Notes:** • Off is the factory default setting. • This setting does not apply to GIF or JPEG images.
Scaling Anchor Top Left Best Fit Anchor Center Fit Height/Width Fit Height Fit Width	Scale the image to fit the selected paper size. **Notes:** • Best Fit is the factory default setting. • When Auto Fit is set to On, Scaling is automatically set to Best Fit.

Use	To
Orientation Portrait Landscape Reverse Portrait Reverse Landscape	Set the image orientation. **Note:** Portrait is the factory default setting.

Help menu

The Help menu consists of a series of Help pages that are stored in the printer as PDFs. They contain information about using the printer and performing printing tasks.

English, French, German, and Spanish translations are stored in the printer. Other translations are available at **http://support.lexmark.com**.

Menu item	Description
Print All Guides	Prints all the guides
Media Guide	Provides a list of the paper sizes supported in trays and feeders
Menu Map	Provides a list of the printer control panel menus and settings
Printing Guide	Provides information about loading paper and other specialty media
Media Guide	Provides a list of the paper sizes supported in trays and feeders
Color Quality Guide	Provides information about solving color quality issues
Print Quality	Provides information about solving print quality issues
Supplies Guide	Provides part numbers for ordering supplies
Moving Guide	Provides instructions for safely moving the printer
Connection Guide	Provides information about connecting the printer locally (USB) or to a network
Print Defects Guide	Provides information about resolving print defects

Saving money and the environment

Lexmark is committed to environmental sustainability and is continually improving its printers to reduce their impact on the environment. We design with the environment in mind, engineer our packaging to reduce materials, and provide collection and recycling programs. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at **www.lexmark.com/environment**
- The Lexmark recycling program at **www.lexmark.com/recycle**

By selecting certain printer settings or tasks, you may be able to reduce your printer's impact even further. This chapter outlines the settings and tasks that may yield a greater environmental benefit.

Saving paper and toner

Studies show that as much as 80% of the carbon footprint of a printer is related to paper usage. You can significantly reduce your carbon footprint by using recycled paper and the following printing suggestions, such as printing on both sides of the paper and printing multiple pages on one side of a single sheet of paper.

For information on how you can quickly save paper and energy using one printer setting, see "Using Eco-Mode".

Using recycled paper

As an environmentally conscious company, Lexmark supports the use of recycled office paper produced specifically for use in laser printers. For more information on recycled papers that work well with your printer, see “Using recycled paper and other office papers” on page 63.

Conserving supplies

Use both sides of the paper

If your printer model supports duplex printing, then you can control whether print appears on one or two sides of the paper by selecting **2-sided printing** from the Print dialog or from the Lexmark Toolbar.

Place multiple pages on one sheet of paper

You can print up to 16 consecutive pages of a multiple-page document onto one side of a single sheet of paper by selecting a setting from the Multipage printing (N-Up) section of the Print dialog screen.

Check your first draft for accuracy

Before printing or making multiple copies of a document:

- Use the preview feature, which you can select from the Print dialog or from the Lexmark Toolbar to see how the document will look like before you print it.
- Print one copy of the document to check its content and format for accuracy.

Avoid paper jams

Correctly set the paper type and size to avoid paper jams. For more information, see “Avoiding jams” on page 161.

Saving energy

Using Eco-Mode

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **General Settings** > **Eco-Mode** > select a setting

Use	To
Off	Use the factory default settings for all settings associated with Eco-Mode. Off supports the performance specifications of the printer.
Energy	Reduce energy use, especially when the printer is idle. • Printer engine motors do not start until it is ready to print. You may notice a short delay before the first page is printed. • The printer enters Sleep mode after one minute of inactivity.
Energy/Paper	Use all the settings associated with Energy and Paper modes.
Plain Paper	• Enable the automatic two-sided (duplex) feature. • Turn off print log features.

3 Click **Submit**.

Reducing printer noise

Enable Quiet Mode to reduce printer noise.

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **General Settings** > **Quiet Mode** > select a setting

Use	To
On	Reduce printer noise. **Notes:** • Print jobs are processed at a reduced speed. • Printer engine motors do not start until a document is ready to print. There will be a short delay before the first page is printed.
Off	Use factory default settings. **Note:** This setting supports the performance specifications of the printer.

3 Click **Submit**.

Adjusting Sleep mode

To save energy, decrease the number of minutes the printer waits before it enters Sleep mode. Select from 1 to 120. The factory default setting is 30 minutes.

Note: The printer still accepts print jobs when in Sleep mode.

Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **General Settings** > **Timeouts**.

3 In the Sleep Mode field, enter the number of minutes you want for the printer to wait before it enters Sleep mode.

4 Click **Submit**.

Using the printer control panel

1 From the home screen, navigate to:

> **Settings** > **General Settings** > **Timeouts** > **Sleep Mode**

2 In the Sleep Mode field, select the number of minutes you want for the printer to wait before it enters Sleep mode.

3 Touch .

Using Hibernate Mode

Hibernate is an ultra-low power operating mode. When operating in Hibernate mode, the printer is essentially off, and all other systems and devices are powered down safely.

Note: The Hibernate and Sleep modes can be scheduled.

Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **General Settings** > **Sleep Button Settings**.
3. From the Press Sleep Button or Press and Hold Sleep Button drop-down menu, select **Hibernate**.
4. Click **Submit**.

Using the printer control panel

1. From the home screen, navigate to:

   > **Settings** > **General Settings**

2. Touch **Press Sleep Button** or **Press and Hold Sleep Button**.
3. Touch **Hibernate** > .

Setting Hibernate Timeout

Hibernate Timeout lets you set the amount of time the printer waits after a print job is processed before it goes into a reduced power state.

Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **General Settings** > **Timeouts**.
3. From the Hibernate Timeout menu, select the number of hours, days, weeks, or months you want for the printer to wait before it goes into a reduced power state.
4. Click **Submit**.

Using the printer control panel

1 From the printer control panel, navigate to:

> **Settings** > **General Settings** > **Timeouts** > **Hibernate Timeout**

2 Select the amount of time the printer waits after a print job is processed before it enters Hibernate mode.

3 Touch .

Using Schedule Power Modes

Schedule Power Modes lets you schedule when the printer goes into a reduced power state or into Ready state.

Note: This feature is available only in network printers or printers connected to print servers.

Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **General Settings** > **Schedule Power Modes**.

3 From the Action menu, select the power mode.

4 From the Time menu, select the time.

5 From the Day(s) menu, select the day or days.

6 Click **Add**.

Adjusting the brightness of the display

To save energy, or if you are have trouble reading your display, adjust the brightness of the display.

Available settings range from 20–100. The factory default setting is 100.

Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **General Settings**.

3 In the Screen Brightness field, enter the brightness percentage you want for the display.

4 Click **Submit**.

Using the printer control panel

1 From the home screen, navigate to:

> **Settings** > **General Settings** > **Screen Brightness**

2 In the Screen Brightness field, enter the brightness percentage you want for the display.

3 Touch .

Recycling

Lexmark provides collection programs and environmentally progressive approaches to recycling. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at **www.lexmark.com/environment**
- The Lexmark recycling program at **www.lexmark.com/recycle**

Recycling Lexmark products

To return Lexmark products for recycling:

1 Go to **www.lexmark.com/recycle**.

2 Find the product type you want to recycle, and then select your country or region from the list.

3 Follow the instructions on the computer screen.

Note: Printer supplies and hardware not listed in the Lexmark collection program may be recycled through your local recycling center. Contact your local recycling center to determine the items they accept.

Recycling Lexmark packaging

Lexmark continually strives to minimize packaging. Less packaging helps to ensure that Lexmark printers are transported in the most efficient and environmentally sensitive manner and that there is less packaging to dispose of. These efficiencies result in fewer greenhouse emissions, energy savings, and natural resource savings.

Lexmark cartons are 100% recyclable where corrugated recycling facilities exist. Facilities may not exist in your area.

The foam used in Lexmark packaging is recyclable where foam recycling facilities exist. Facilities may not exist in your area.

When you return a cartridge to Lexmark, you can reuse the box that the cartridge came in. Lexmark will recycle the box.

Returning Lexmark cartridges for reuse or recycling

Lexmark Cartridge Collection Program diverts millions of Lexmark cartridges from landfills annually by making it both easy and free for Lexmark customers to return used cartridges to Lexmark for reuse or recycling. One hundred percent of the empty cartridges returned to Lexmark are either reused or demanufactured for recycling. Boxes used to return the cartridges are also recycled.

To return Lexmark cartridges for reuse or recycling, follow the instructions that came with your printer or cartridge and use the prepaid shipping label. You can also do the following:

1. Go to **www.lexmark.com/recycle**.
2. From the Toner Cartridges section, select your country or region.
3. Follow the instructions on the computer screen.

Securing the printer

Using the security lock feature

The printer is equipped with a security lock feature. Attach a security lock compatible with most laptop computers in the location shown to secure the printer in place.



Statement of Volatility

Your printer contains various types of memory that can store device and network settings, and user data.

Type of memory	Description
Volatile memory	Your printer uses standard *random access memory* (RAM) to temporarily buffer user data during simple print jobs.
Non-volatile memory	Your printer may use two forms of non-volatile memory: EEPROM and NAND (flash memory). Both types are used to store the operating system, device settings, network information and bookmark settings, and embedded solutions.
Hard disk memory	Some printers have a hard disk drive installed. The printer hard disk is designed for printer-specific functionality. This lets the printer retain buffered user data from complex print jobs, as well as form data, and font data.

Erase the content of any installed printer memory in the following circumstances:

- The printer is being decommissioned.
- The printer hard disk is being replaced.

- The printer is being moved to a different department or location.
- The printer is being serviced by someone from outside your organization.
- The printer is being removed from your premises for service.
- The printer is being sold to another organization.

Disposing of a printer hard disk

Note: Some printer models may not have a printer hard disk installed.

In high-security environments, it may be necessary to take additional steps to make sure that confidential data stored in the printer hard disk cannot be accessed when the printer—or its hard disk—is removed from your premises.

- **Degaussing**—Flushes the hard disk with a magnetic field that erases stored data
- **Crushing**—Physically compresses the hard disk to break component parts and render them unreadable
- **Milling**—Physically shreds the hard disk into small metal bits

Note: Most data can be erased electronically, but the only way to guarantee that all data are completely erased is to physically destroy each hard disk where data is stored.

Erasing volatile memory

The volatile memory (RAM) installed in your printer requires a power source to retain information. To erase the buffered data, simply turn off the printer.

Erasing non-volatile memory

Erase individual settings, device and network settings, security settings, and embedded solutions by following these steps:

1. Turn off the printer.
2. Hold down **2** and **6** on the keypad while turning the printer on. Release the buttons only when the screen with the progress bar appears.

   The printer performs a power-on sequence, and then the Configuration menu appears. When the printer is fully turned on, a list of functions appears on the printer display instead of the standard home screen icons.
3. Touch **Wipe All Settings**.

   The printer will restart several times during this process.

   Note: Wipe All Settings securely removes device settings, solutions, jobs, and passwords from the printer memory.
4. Touch **Back** > **Exit Config Menu**.

The printer will perform a power-on reset, and then return to normal operating mode.

Erasing printer hard disk memory

Note: Some printer models may not have a printer hard disk installed.

Configuring Disk Wiping in the printer menus lets you remove residual confidential material left by print jobs by securely overwriting files that have been marked for deletion.

Using the printer control panel

1. Turn off the printer.
2. Hold down **2** and **6** while turning the printer on. Release the buttons only when the screen with the progress bar appears.

   The printer performs a power-on sequence, and then the Configuration menu appears. When the printer is fully turned on, the touch screen displays a list of functions.
3. Touch **Wipe Disk**, and then touch one of the following:
   - **Wipe disk (fast)**—This lets you overwrite the disk with all zeroes in a single pass.
   - **Wipe disk (secure)**—This lets you overwrite the disk with random bit patterns several times, followed by a verification pass. A secure overwrite is compliant with the DoD 5220.22-M standard for securely erasing data from a hard disk. Highly confidential information should be wiped using this method.
4. Touch **Yes** to proceed with disk wiping.

   Notes:

   - A status bar will indicate the progress of the disk wiping task.
   - Disk wiping can take from several minutes to more than an hour, during which the printer will be unavailable for other user tasks.
5. Touch **Back** > **Exit Config Menu**.

The printer will perform a power-on reset, and then return to normal operating mode.

Finding printer security information

In high-security environments, it may be necessary to take additional steps to make sure that confidential data stored in the printer cannot be accessed by unauthorized persons. For more information, visit the **Lexmark security Web page**.

You can also see the *Embedded Web Server Administrator's Guide* for additional information:

1. Go to **http://support.lexmark.com**.
2. In the Search field, type the model name of your printer, and then click **Go**.
3. Click the **Manuals** tab, and then select the *Embedded Web Server Administrator's Guide*.

Configuring printer hard disk encryption

Enable hard disk encryption to prevent loss of sensitive data in the event the printer or its hard disk is stolen.

Note: Some printer models may not have a printer hard disk installed.

Using the Embedded Web Server

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Security** > **Disk Encryption**.

   Note: Disk Encryption appears in the Security Menu only when a formatted, non-defective printer hard disk is installed.

3. From the Disk encryption menu, select **Enable**.

   Notes:

   - Enabling disk encryption will erase the contents of the printer hard disk.
   - Disk encryption can take from several minutes to more than an hour, during which the printer will be unavailable for other user tasks.

4. Click **Submit**.

Using the printer control panel

1. Turn off the printer.
2. Hold down **2** and **6** while turning the printer on. Release the buttons only when the screen with the progress bar appears.

   The printer performs a power-on sequence, and then the Configuration menu appears. When the printer is fully turned on, a list of functions appears on the printer display.

3. Touch **Disk Encryption** > **Enable**.

   Note: Enabling disk encryption will erase the contents of the printer hard disk.

4. Touch **Yes** to proceed with disk wiping.

   Notes:

   - Do not turn off the printer during the encryption process. Doing so may result in loss of data.
   - Disk encryption can take from several minutes to more than an hour, during which the printer will be unavailable for other user tasks.
   - A status bar will indicate the progress of the disk wiping task. After the disk has been encrypted, the printer will return to the Enable/Disable screen.

5. Touch **Back** > **Exit Config Menu**.

The printer will perform a power-on reset, and then return to normal operating mode.

Maintaining the printer

Warning—Potential Damage: Failure to maintain optimum printer performance periodically, or to replace parts and supplies, may cause damage to your printer.

Cleaning the printer parts

Cleaning the printer

Note: You may need to perform this task after every few months.

Warning—Potential Damage: Damage to the printer caused by improper handling is not covered by the printer warranty.

1. Make sure that the printer is turned off and unplugged from the electrical outlet.

   CAUTION—SHOCK HAZARD: To avoid the risk of electrical shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.

2. Remove paper from the standard bin, multipurpose feeder, and manual feeder.
3. Remove any dust, lint, and pieces of paper around the printer using a soft brush or vacuum.
4. Dampen a clean, lint-free cloth with water, and use it to wipe the outside of the printer.

   Warning—Potential Damage: Do not use household cleaners or detergents, as they may damage the finish of the printer.

5. Make sure all areas of the printer are dry before sending a new print job.

Checking the status of supplies

A message appears on the display when a replacement supply item is needed or when maintenance is required. For more information, see “Supplies menu” on page 76.

Checking the status of parts and supplies on the printer control panel

From the home screen, navigate to:

Status/Supplies > **View Supplies**

Checking the status of parts and supplies from the Embedded Web Server

Note: Make sure the computer and the printer are connected to the same network.

1. Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Device Status** > **More Details**.

Estimated number of remaining pages

The estimated number of remaining pages is based on the recent printing history of the printer. Its accuracy may vary significantly and is dependent on many factors, such as actual document content, print quality settings, and other printer settings.

The accuracy of the estimated number of remaining pages may decrease when the actual printing consumption is different from the historical printing consumption. Consider the variable level of accuracy before purchasing or replacing supplies based on the estimate. Until an adequate print history is obtained on the printer, initial estimates assume future supplies consumption based on the International Organization for Standardization* test methods and page content.

* Average continuous black or composite CMY declared cartridge yield in accordance with ISO/IEC 19798.

Ordering supplies

Using genuine Lexmark parts and supplies

Your Lexmark printer is designed to function best with genuine Lexmark supplies and parts. Use of third-party supplies or parts may affect the performance, reliability, or life of the printer and its imaging components. Use of third-party supplies or parts can affect warranty coverage. Damage caused by the use of third-party supplies or parts is not covered by the warranty. All life indicators are designed to function with Lexmark supplies and parts, and may deliver unpredictable results if third-party supplies or parts are used. Imaging component usage beyond the intended life may damage your Lexmark printer or its associated components.

Ordering toner cartridges

Notes:

- Estimated cartridge yield is based on the ISO/IEC 19798 standard.
- Extremely low print coverage for extended periods of time may negatively affect actual yield and may cause cartridge parts to fail prior to exhaustion of toner.

Item	Part number
Black	24B6011
Cyan	24B6008
Magenta	24B6009
Yellow	24B6010

Ordering imaging kits

Item	All countries and regions
Black and Color imaging kit	70C0Z50
Black imaging kit	70C0Z10

Ordering a waste toner bottle

Item	All countries and regions
Waste toner bottle	C540X75G

Storing supplies

Choose a cool, clean storage area for the printer supplies. Store supplies right side up in their original packing until you are ready to use them.

Do not expose supplies to:

- Direct sunlight
- Temperatures above 35°C (95°F)
- High humidity above 80%
- Salty air
- Corrosive gases
- Heavy dust

Replacing supplies

Replacing the waste toner bottle



1	Top door
2	Waste toner bottle
3	Right side cover
4	Front door

1 Unpack the replacement waste toner bottle.

2 Open the front door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.



3 Slide the release latch on the right side of the printer, and then open the top door.



4 Remove the right side cover.



5 Press the green levers on each side of the waste toner bottle, and then remove the waste toner bottle.



6 Seal the used waste toner bottle in the enclosed packaging.

For more information, see “Recycling Lexmark products” on page 128.

7 Insert the replacement waste toner bottle.



8 Insert the right side cover.



9 Close the top door.



10 Close the front door.



Replacing a black and color imaging kit

1 Open the front door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.



2 Slide the release latch on the right side of the printer, and then open the top door.



3 Remove the toner cartridges by lifting the handles, and then gently pulling them away from the imaging kit.



4 Remove the right side cover.



5 Press the green levers on each side of the waste toner bottle, and then remove the waste toner bottle.



6 Lift the blue levers on the imaging kit, and then pull the imaging kit until it stops.



7 Press down the blue lever, and then grasp the green handles on the sides to pull out the imaging kit.



8 Unpack the replacement black and color imaging kit.



Notes:

- Color imaging kit includes the imaging kit and the cyan, magenta, yellow, and black developer units.
- Black imaging kit includes the imaging kit and the black developer unit.

9 Seal the used imaging kit in the bag that the replacement imaging kit came.

For more information, see “Recycling Lexmark products” on page 128.



Note: When replacing the black imaging kit, save the cyan, magenta, and yellow developer units . Dispose only the black developer unit.

10 Gently shake the yellow, cyan, magenta, and black developer units side-to-side.



11 Remove the red packing strip and the attached fabric from the developer units.



12 Gently insert the yellow, cyan, magenta, and black developer units.



Note: Make sure each developer unit is inserted into a matching color slot.

13 Remove the red packing strip from the imaging kit.



Warning—Potential Damage: Do not touch the shiny photoconductor drum under the imaging kit. Doing so may affect the quality of future print jobs.

14 Align, and then insert the imaging kit.



15 Gently, but firmly push the blue levers down until the imaging kit fits into place.



Note: Make sure that the imaging kit is fully seated.

16 Insert the waste toner bottle.



17 Insert the right side cover.



18 Insert the toner cartridges.



19 Close the top door.



20 Close the front door.



Replacing toner cartridges

Warning—Potential Damage: Damage caused by use of a non-Lexmark toner cartridge is not covered under warranty.

Note: Reduced print quality may result from using non-Lexmark toner cartridges.

1 Slide the release latch on the right side of the printer, and then open the top door.



2 Remove the toner cartridge by lifting the handle, and then gently pulling it away from the imaging kit.



3 Unpack the new toner cartridge, and then remove its packaging.



4 Align the new toner cartridge, and then press the cartridge down until it fits into place.



5 Close the top door.

6 Seal the used toner cartridge in the bag that the replacement toner cartridge came in before disposing.

For more information, see “Recycling Lexmark products” on page 128.

Replacing a developer unit

Replace the developer unit when a print quality defect occurs or when damage occurs to the printer.

1 Open the front door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.



2 Slide the release button on the right side of the printer, and then open the top door.



3 Lift the toner cartridge handle, and then gently pull it from the imaging kit.



4 Remove the right side cover.



5 Press the green levers on each side of the waste toner bottle, and then remove the waste toner bottle.



6 Lift the blue levers on the imaging kit, and then pull the imaging kit until it stops.



7 Press down the blue lever, and then grasp the green handles on the sides to pull out the imaging kit.

Warning—Potential Damage: Do not touch the underside of the imaging kit. This could damage the imaging kit.



8 Remove the used developer unit.



9 Gently shake the replacement developer unit side-to-side before removing it from its packaging.



10 Remove the red shipping cover from the developer unit.



11 Insert the developer unit.



12 Align, and then insert the imaging kit.



13 Gently, but firmly push the blue levers down until the imaging kit fits into place.



Note: Make sure that the imaging kit is fully seated.

14 Replace the waste toner bottle.



15 Insert the right side cover.



16 Insert the toner cartridges.



17 Close the top door.



18 Close the front door.



19 Seal the used developer unit in the bag that the replacement developer unit came in before disposing.

For more information, see “Recycling Lexmark products” on page 128.

Moving the printer

Before moving the printer

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—POTENTIAL INJURY: Before moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the electrical outlet.
- Disconnect all cords and cables from the printer before moving it.
- Lift the printer off the optional tray, and then set it aside instead of trying to lift the tray and printer at the same time.

Note: Use the handholds located on both sides of the printer to lift it.

Warning—Potential Damage: Damage to the printer caused by improper moving is not covered by the printer warranty.

Moving the printer to another location

The printer and its hardware options can be safely moved to another location by following these precautions:

- Any cart used to move the printer must have a surface able to support the full footprint of the printer.
- Any cart used to move the hardware options must have a surface able to support the dimensions of the hardware options.
- Keep the printer in an upright position.
- Avoid severe jarring movements.

Shipping the printer

When shipping the printer, use the original packaging.

Managing the printer

Finding advanced networking and administrator information

This chapter covers basic administrative support tasks using the Embedded Web Server. For more advanced system support tasks, see the *Networking Guide* on the *Software* CD or the *Embedded Web Server Administrator's Guide* at **http://support.lexmark.com**.

Checking the virtual display

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Check the virtual display that appears at the top left corner of the screen.

The virtual display works as an actual display would work on a printer control panel.

Checking the printer status

You can view paper tray settings, the level of toner in the toner cartridges, the percentage of life remaining in the maintenance kit, and capacity measurements of certain printer parts from the Device Status page of the Embedded Web Server.

1 Type the printer IP address in the address field of your Web browser.

Note: If you do not know the IP address of the printer, then you can:

- View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Device Status**.

Viewing reports

You can view some reports from the Embedded Web Server. These reports are useful for assessing the status of the printer, network, and supplies.

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Reports**, and then click the type of report you want to view.

Configuring supply notifications from the Embedded Web Server

You can determine how you would like to be notified when supplies run nearly low, low, very low, or reach their end-of-life by setting the selectable alerts.

Notes:

- You can select alerts for toner cartridges, imaging kit, maintenance kit, and waste toner bottle.
- All alerts can be set for nearly low, low, and very low supply conditions. Not all alerts can be set for the end-of-life supply condition. E-mail alert is available for all supply conditions.
- The percentage of estimated remaining supply that prompts the alert can be set on some supplies for some supply conditions.

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
   - If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2. Click **Settings** > **Print Settings** > **Supply Notifications**.

3. From the drop-down menu for each supply, select one of the following notification options:

Notification	Description
Off	The normal printer behavior for all supplies occurs.
E-mail Only	The printer generates an e-mail when the supply condition is reached. The status of the supply appears on the menus page and status page.
Warning	The printer shows the warning message and generates an email about the status of the supply. The printer does not stop when the supply condition is reached.
Continuable Stop[1]	The printer stops processing jobs when the supply condition is reached. The user needs to press a button to continue printing.
Non Continuable Stop[1,2]	The printer stops when the supply condition is reached. The supply must be replaced to continue printing.
[1] The printer generates an e-mail about the status of the supply when supply notification is enabled. [2] The printer stops when some supplies become empty to prevent damage.	

4. Click **Submit**.

Modifying confidential print settings

Note: This feature is available only in network printers or printers connected to print servers.

1. Open a Web browser, and then type the printer IP address in the address field.

   Notes:

   - View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** tab > **Security** > **Confidential Print Setup**.

3 Modify the settings:

- Set a maximum number of PIN entry attempts. When a user exceeds a specific number of PIN entry attempts, all of the jobs for that user are deleted.
- Set an expiration time for confidential print jobs. When a user has not printed the jobs within the specified time, all of the jobs for that user are deleted.

4 Save the modified settings.

Copying printer settings to other printers

Note: This feature is available only in network printers.

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address in the TCP/IP section in the Network/Ports menu. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click the **Copy Printer Settings**.

3 To change the language, select a language from the drop-down menu, and then click **Click here to submit language**.

4 Click **Printer Settings**.

5 Type the IP addresses of the source and target printers in their appropriate fields.

Note: If you want to add or remove a target printer, then click **Add Target IP** or **Remove Target IP**.

6 Click **Copy Printer Settings**.

Restoring factory default settings

If you want to keep a list of the current menu settings for reference, then print a menu settings page before restoring the factory default settings. For more information, see “Printing a menu settings page” on page 46.

If you want a more comprehensive method of restoring the printer factory default settings, then perform the Wipe All Settings option. For more information, see “Erasing non-volatile memory” on page 131.

Warning—Potential Damage: Restoring factory defaults returns most printer settings to the original factory default settings. Exceptions include the display language, custom sizes and messages, and network/port menu settings. All downloads stored in the RAM are deleted. Downloads stored in the flash memory or in a printer hard disk are not affected.

From the home screen, navigate to:

> **Settings** > **General Settings** > **Factory Defaults** > **Restore Now** >

Clearing jams

Avoiding jams

Load paper properly

- Make sure paper lies flat in the tray.



- Do not remove a tray while the printer is printing.
- Do not load a tray while the printer is printing. Load it before printing, or wait for a prompt to load it.
- Do not load too much paper. Make sure the stack height is below the maximum paper fill indicator.

- Do not slide the paper into the tray. Load paper as shown in the illustration.



- Make sure the guides in the tray or the multipurpose feeder are properly positioned and are not pressing tightly against the paper or envelopes.
- Push the tray firmly into the printer after loading paper.

Use recommended paper

- Use only recommended paper or specialty media.
- Do not load wrinkled, creased, damp, bent, or curled paper.
- Flex, fan, and straighten paper before loading it.



- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same tray.
- Make sure the paper size and type are set correctly on the computer or printer control panel.
- Store paper according to manufacturer recommendations.

Understanding jam messages and locations

When a jam occurs, a message indicating the jam location and information to clear the jam appears on the printer display. Open the doors, covers, and trays indicated on the display to remove the jam.

Note: When Jam Recovery is set to On or Auto, the printer reprints jammed pages. However, Auto does not guarantee that the page will print.



	Jam location	Message on the display	What to do
1	Standard bin	[x]-page jam, clear standard bin. [203.xx]	Remove the jammed paper.
2	Fuser	[x]-page jam, open front door to clear fuser. [202.xx]	Open the front door, pull the tab and hold the fuser cover down, and then remove the jammed paper.
3	Front door	[x]-page jam, open front door. [20y.xx]	Open the front door, and then remove the jammed paper.
4	Duplex	[x]-page jam, open front door to clear duplex. [23y.xx]	Open the front door, and then remove the jammed paper.
5	Tray [x]	[x]-page jam, open tray [x]. [24y.xx]	Pull the indicated tray out, and then remove the jammed paper.
6	Manual feeder	[x]-page jam, clear manual feeder. [251.xx]	Remove the jammed paper.
7	Multipurpose feeder	[x]-page jam, clear multipurpose feeder. [250.xx]	Push the paper release lever to lift the paper rollers, and then remove the jammed paper.

[x]-page jam, clear standard bin.

1 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



2 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > **Clear the jam, press OK**, and then press to confirm.

[x]-page jam, open front door to clear fuser.

1 Open the front door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



2 Pull the green lever to open the fuser cover.



3 Hold down the fuser cover, and then remove the jammed paper.

Note: Make sure all paper fragments are removed.

4 Close the front door.



5 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > **Clear the jam, press OK**, and then press to confirm.

[x]-page jam, open front door.

1 Open the front door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



3 Close the front door.



4 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > **Clear the jam, press OK**, and then press to confirm.

[x]-page jam, open front door to clear duplex.

1 Open the front door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



3 Close the front door.



4 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > **Clear the jam, press OK**, and then press to confirm.

[x]-page jam, open tray [x].

1 Pull the tray completely out of the printer.

Note: The message on the printer display determines in which tray the paper jam is located.

2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.

3 Insert the tray.

4 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > **Clear the jam, press OK**, and then press to confirm.

[x]-page jam, clear manual feeder.

1 Pull out the standard 250-sheet tray (Tray 1) and manual feeder.

2 Grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



3 Insert the tray.

4 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > **Clear the jam, press OK**, and then press to confirm.

[x]-page jam, clear multipurpose feeder

1 Push the paper release lever in the multipurpose feeder to access the jammed paper, and then gently pull it out.

Note: Make sure all paper fragments are removed.

2 Flex the sheets of paper back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.



3 Reload paper into the multipurpose feeder.

4 Slide the paper guide until it rests lightly against the edge of the paper stack.

5 From the printer control panel, touch to clear the message and continue printing. For non-touch-screen printer models, select **Next** > > **Clear the jam, press OK** > .

Troubleshooting

Understanding the printer messages

Adjusting color

Wait for the process to complete.

Change [paper source] to [custom type name]

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then select **Finished changing paper** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press ✓ to confirm.

  Note: Make sure the paper size and type are specified in the Paper menu on the printer control panel.
- Cancel the print job.

Change [paper source] to [custom string]

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then select **Finished changing paper** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press ✓ to confirm.

  Note: Make sure the paper size and type are specified in the Paper menu on the printer control panel.
- Cancel the print job.

Change [paper source] to [paper type] [paper size]

Try one or more of the following:

- Load the correct size and type of paper in the tray, and then select **Finished changing paper** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press ✓ to confirm.

  Note: Make sure the paper size and type are specified in the Paper menu on the printer control panel.
- Cancel the print job.

Close door

Make sure the right side cover is installed, and then close the front and top doors to clear the message.

[Color] cartridge low [88.xy]

You may need to order a toner cartridge. If necessary, select **Continue** to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

[Color] cartridge very low, [x] estimated pages remain [88.xy]

You may need to replace the toner cartridge very soon. For more information, see the “Replacing supplies” section of the *User’s Guide*.

If necessary, select **Continue** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

[Type] imaging kit low [84.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

You may need to order an imaging kit. If necessary, select **Continue** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

[Type] imaging kit nearly low [84.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

If necessary, select **Continue** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

[Type] imaging kit very low, [x] estimated pages remain [84.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

You may need to replace the imaging kit very soon. For more information, see the “Replacing supplies” section of the *User’s Guide*.

If necessary, select **Continue** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

Complex page, some data may not have printed [39]

Try one or more of the following:

- From the printer control panel, select **Continue** to ignore the message and continue printing. For non-touch-screen printer models, press to confirm.
- Cancel the current print job. For non-touch-screen printer models, press to confirm.
- Install additional printer memory.

Configuration change, some held jobs were not restored [57]

Held jobs are invalidated because of any of the following possible changes in the printer:

- The printer firmware has been updated.
- The tray for the print job is removed.
- The print job is sent from a flash drive that is no longer attached to the USB port.
- The printer hard disk contains print jobs that were stored when the hard disk was installed in a different printer model.

Note: The printer hard disk and the flash drive are supported only in select printer models.

From the printer control panel, select **Continue** to clear the message. For non-touch-screen printer models, press ✓ to confirm.

Defective flash detected [51]

Try one or more of the following:

- Replace the defective flash memory card.
- From the printer control panel, select **Continue** to ignore the message and continue printing. For non-touch-screen printer models, press ✓ to confirm.
- Cancel the current print job.

Error reading USB drive. Remove USB.

An unsupported USB device is inserted. Remove the USB device, and then insert a supported one.

Error reading USB hub. Remove hub.

An unsupported USB hub has been inserted. Remove the USB hub, and then install a supported one.

Incompatible tray [x] [59]

Remove, and then reinstall the indicated tray to clear the message.

Incorrect paper size, open [paper source] [34]

Try one or more of the following:

- Load the correct size of paper in the tray.
- From the printer control panel, select **Continue** to clear the message and print using a different tray. For non-touch-screen printer models, press ✓ to confirm.
- Check the tray length and width guides and make sure the paper is loaded properly in the tray.
- Make sure the correct paper size and type are specified in the Printing Preferences or in the Print dialog.
- Make sure the paper size and type are specified in the Paper menu on the printer control panel.

- Make sure that the paper size is correctly set. For example, if MP Feeder Size is set to Universal, then make sure the paper is large enough for the data being printed.
- Cancel the print job.

Insert Tray [x]

Insert the indicated tray into the printer.

Insufficient memory for Flash Memory Defragment operation [37]

Try one or more of the following:

- From the printer control panel, select **Continue** to stop the defragmentation and continue printing. For non-touch-screen printer models, press to confirm.
- Delete fonts, macros, and other data from the printer memory.
- Install additional printer memory.

Insufficient memory, some Held Jobs were deleted [37]

The printer deleted some held jobs in order to process current jobs.

Select **Continue** to clear the message. For non-touch-screen printer models, press to confirm.

Insufficient memory to collate job [37]

Try one or more of the following:

- From the printer control panel, select **Continue** to print the part of the job already stored and begin collating the rest of the print job. For non-touch-screen printer models, press to confirm.
- Cancel the current print job.

Insufficient memory to support Resource Save feature [35]

Install additional printer memory or select **Continue** on the printer control panel to disable Resource Save, clear the message, and continue printing. For non-touch-screen printer models, press to confirm.

Insufficient memory, some held jobs will not be restored [37]

Try one or more of the following:

- From the printer control panel, select **Continue** to clear the message. For non-touch-screen printer models, press to confirm.
- Delete other held jobs to free up additional printer memory.

Load [paper source] with [custom type name]

Try one or more of the following:

- Load the tray or feeder with the correct size and type of paper.
- To use the tray with the correct paper size or type, select **Finished loading paper** on the printer control panel. For non-touch-screen printer models, press to confirm.

  Note: If the printer detects a tray that has the correct paper type and size, then it feeds from that tray. If the printer cannot detect a tray that has the correct paper type and size, then it prints from the default paper source.
- Cancel the current job.

Load [paper source] with [custom string]

Try one or more of the following:

- Load the indicated tray or feeder with the correct size and type of paper.
- To use the tray with the correct paper size or type, select **Finished loading paper** on the printer control panel. For non-touch-screen printer models, press to confirm.

  Note: If the printer finds a tray that has the correct paper type and size, then it feeds from that tray. If the printer cannot find a tray with the correct paper type and size, then it prints from the default paper source.
- Cancel the current job.

Load [paper source] with [paper size]

Try one or more of the following:

- Load the tray or feeder with the correct size of paper.
- To use the tray or feeder with the correct paper size, select **Finished loading paper** on the printer control panel. For non-touch-screen printer models, press to confirm.

  Note: If the printer detects a tray that has the correct paper size, then it feeds from that tray. If the printer cannot detect a tray that has the correct paper size, then it prints from the default paper source.
- Cancel the current job.

Load [paper source] with [paper type] [paper size]

Try one or more of the following:

- Load the tray or feeder with the correct size and type of paper.
- To use the tray or feeder with the correct paper size and type, select **Finished loading paper** on the printer control panel. For non-touch-screen printer models, press to confirm.

  Note: If the printer detects a tray that has the correct paper size and type, then it feeds from that tray. If the printer cannot detect a tray that has the correct paper size and type, then it prints from the default paper source.
- Cancel the current job.

Load Manual Feeder with [custom string]

Try one or more of the following:

- Load the feeder with the correct size and type of paper.
- Depending on your printer model, touch **Prompt each page, paper loaded** or press on the printer control panel to clear the message and continue printing.
- Cancel the current job.

Load Manual Feeder with [custom type name]

Try one or more of the following:

- Load the feeder with the correct size and type of paper.
- Depending on your printer model, touch **Prompt each page, paper loaded** or press on the printer control panel to clear the message and continue printing.
- Cancel the current job.

Load Manual Feeder with [paper size]

Try one or more of the following:

- Load the feeder with the correct size of paper.
- Depending on your printer model, touch **Prompt each page, paper loaded** or press on the printer control panel to clear the message and continue printing.
- Cancel the current job.

Load Manual Feeder with [paper type] [paper size]

Try one or more of the following:

- Load the feeder with the correct size and type of paper.
- Depending on your printer model, touch **Prompt each page, paper loaded** or press on the printer control panel to clear the message and continue printing.
- Cancel the current job.

Maintenance kit low [80.xy]

You may need to order a maintenance kit. For more information, contact customer support at **http://support.lexmark.com** or your service representative. If necessary, select **Continue** to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

Maintenance kit nearly low [80.xy]

For more information, contact customer support at **http://support.lexmark.com** or your service representative. If necessary, select **Continue** to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

Maintenance kit very low [80.xy]

You may need to replace the maintenance kit very soon. For more information, contact customer support at **http://support.lexmark.com** or your service representative.

If necessary, select **Continue** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

Memory full [38]

Try one or more of the following:

- From the printer control panel, select **Cancel job** to clear the message. For non-touch-screen printer models, press to confirm.
- Install additional printer memory.

Network [x] software error [54]

Try one or more of the following:

- From the printer control panel, select **Continue** to continue printing. For non-touch-screen printer models, press to confirm.
- Turn off the printer, wait for about 10 seconds, and then turn the printer back on.
- Update the network firmware in the printer or print server. For more information, contact customer support.

Not enough free space in flash memory for resources [52]

Try one or more of the following:

- From the printer control panel, select **Continue** to clear the message and continue printing. For non-touch-screen printer models, press to confirm.
- Delete fonts, macros, and other data stored in the flash memory.
- Upgrade to a larger capacity flash memory card.

Note: Downloaded fonts and macros that are not previously stored in the flash memory are deleted.

Non-Lexmark [color] [supply type], see User's Guide [33.xy]

Note: The supply type can be a toner cartridge or the imaging kit.

The printer has detected a non-Lexmark supply or part installed in the printer.

Your Lexmark printer is designed to function best with genuine Lexmark supplies and parts. Use of third-party supplies or parts may affect the performance, reliability, or life of the printer and its imaging components.

All life indicators are designed to function with Lexmark supplies and parts, and may deliver unpredictable results if third-party supplies or parts are used. Imaging component usage beyond the intended life may damage your Lexmark printer or its associated components.

Warning—Potential Damage: Use of third-party supplies or parts can affect warranty coverage. Damage caused by the use of third-party supplies or parts may not be covered by the warranty.

To accept any and all of these risks, and to proceed with the use of non-genuine supplies or parts in your printer, press and hold and the **#** button on the printer control panel simultaneously for 15 seconds.

If you do not wish to accept these risks, then remove the third-party supply or part from your printer, and then install a genuine Lexmark supply or part.

Note: For the list of supported supplies, see the “Ordering supplies” section of the *User's Guide* or visit **www.lexmark.com**.

PPDS font error [50]

Try one or more of the following:

- From the printer control panel, select **Continue** to clear the message and continue printing. For non-touch-screen printer models, press to confirm.
- If the printer cannot find the requested font, then from the printer control panel, navigate to:

  PPDS menu > **Best Fit** > **On**

  The printer will find a similar font and reformat the affected text.
- Cancel the current print job.

Reinstall missing or unresponsive [color] cartridge [31.xy]

Try one or more of the following:

- Install the missing toner cartridge. For more information, see the “Replacing supplies” section of the *User’s Guide*.
- Remove the unresponsive cartridge, and then reinstall it.

  Note: If the message appears after reinstalling the supply, then the cartridge may be defective. Replace the cartridge.

Reinstall missing or unresponsive [type] imaging kit [31.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

Try one or more of the following:

- Install the missing imaging kit. For more information, see the “Replacing supplies” section of the *User’s Guide*.
- Remove the unresponsive imaging kit, and then reinstall it.

  Note: If the message appears after reinstalling the supply, then the imaging kit may be defective. Replace the imaging kit.

Reload printed pages in Tray [x]

Try any of the following:

- From the printer control panel, select **Continue** to clear the message and continue printing the second side of the sheet. For non-touch-screen printer models, press to confirm.
- Cancel the print job.

Remove packaging material, [area name]

1. Remove any remaining packing material from the indicated location.
2. From the printer control panel, touch **Continue** to clear the message. For non-touch-screen printer models, press to confirm.

Remove paper from standard output bin

Remove the paper stack from the standard bin.

Replace [color] cartridge, 0 estimated pages remain [88.xy]

Replace the indicated toner cartridge to clear the message and continue printing. For more information, see the instruction sheet that came with the supply.

Note: If you do not have a replacement cartridge, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

Replace [color] cartridge, printer region mismatch [42.xy]

Install a toner cartridge that matches the region number of the printer. *x* indicates the value of the printer region. *y* indicates the value of the cartridge region. x and y can have the following values:

Region number	Region
0	Global
1	United States, Canada
2	European Union (EU), European Economic Area (EEA), Switzerland
8	Rest of the world
9	Invalid

Notes:

- The x and y values represent .**xy** in the error code that appears on the printer control panel.
- The x and y values must match for printing to continue.

Replace [type] imaging kit, 0 estimated pages remain [84.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

Replace the indicated imaging kit to clear the message and continue printing. For more information, see the instruction sheet that came with the supply.

Note: If you do not have a replacement imaging kit, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

Replace defective [color] cartridge [31.xy]

Replace the defective toner cartridge to clear the message. For more information, see the instruction sheet that came with the supply.

Note: If you do not have a replacement toner cartridge, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

Replace defective [type] imaging kit [31.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

Replace the defective imaging kit to clear the message and continue printing. For more information, see the instruction sheet that came with the supply.

Note: If you do not have a replacement imaging kit, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

Replace maintenance kit, 0 estimated pages remain [80.xy]

Contact customer support at **http://support.lexmark.com** or your service representative, and then report the message. The printer is scheduled for maintenance.

Replace missing [color] cartridge [31.xy]

Install the indicated toner cartridge to clear the message. For more information, see the “Replacing supplies” section of the *User’s Guide*.

Replace missing [type] imaging kit [31.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

Install the indicated imaging kit to clear the message. For more information, see the “Replacing supplies” section of the *User’s Guide*.

Replace waste toner bottle [82.xy]

Replace the waste toner bottle to clear the message.

Replace unsupported [color] cartridge [32.xy]

Remove the toner cartridge, and then install a supported one to clear the message.

Note: If you do not have a replacement cartridge, then see the “Ordering supplies” section of the *User’s Guide* or visit **www.lexmark.com**.

Replace unsupported [type] imaging kit [32.xy]

Note: The type can be a black imaging kit, or a black and color imaging kit.

Remove the indicated imaging kit, and then install a supported one to clear the message.

Note: If you do not have a replacement imaging kit, then see the "Ordering supplies" section of the *User's Guide* or visit **www.lexmark.com**.

Replace missing waste toner bottle [82.xy]

Install the missing waste toner bottle to clear the message. For more information, see the instruction sheet that came with the supply.

Restore held jobs?

Try one or more of the following:

- From the printer control panel, touch **Restore** to restore all held jobs stored in the printer hard disk.
- From the printer control panel, touch **Do not restore** if you do not want to restore any of the print jobs.

SMTP server not set up. Contact system administrator.

From the printer control panel, touch **Continue** to clear the message.

Note: If the message appears again, then contact your system support person.

Some held jobs were not restored

From the printer control panel, select **Continue** to clear the message. For non-touch-screen printer models, press to confirm.

Note: Held jobs that are not restored remain in the printer hard disk and are inaccessible.

Standard network software error [54]

Try one or more of the following:

- From the printer control panel, select **Continue** to continue printing. For non-touch-screen printer models, press to confirm.
- Turn off the printer and then turn it back on.
- Update the network firmware in the printer or print server. For more information, contact customer support.

Standard USB port disabled [56]

From the printer control panel, select **Continue** to clear the message. For non-touch-screen printer models, press to confirm.

Notes:

- The printer discards any data received through the USB port.
- Make sure the USB Buffer menu is not set to Disabled.

Supply needed to complete job

Try one or more of the following:

- From the printer control panel, touch **Prompt for supplies** to view all error messages that indicate what supplies are needed to continue processing the current job. For non-touch-screen printer models, press to clear the message and continue printing.
  1. Order the missing supply immediately.
  2. Install the supply. For more information, see the instruction sheet that came with the supply.
- Cancel the print job, then install the missing supply, and then resend the print job.

Too many flash options installed [58]

1. Turn off the printer.
2. Unplug the power cord from the electrical outlet.
3. Remove the extra flash memory.
4. Connect the power cord to a properly grounded electrical outlet.
5. Turn the printer back on.

Too many trays attached [58]

1. Turn off the printer.
2. Unplug the power cord from the electrical outlet.
3. Remove the extra trays.
4. Connect the power cord to a properly grounded electrical outlet.
5. Turn the printer back on.

Unformatted flash detected [53]

Try one or more of the following:

- From the printer control, select **Continue** to stop the defragmentation and continue printing. For non-touch-screen printer models, press to confirm.
- Format the flash memory.

Note: If the error message remains, then the flash memory may be defective and need to be replaced.

Waste toner bottle nearly full [82.xy]

You may need to order a waste toner bottle. If necessary, select **Continue** on the printer control panel to clear the message and continue printing. For non-touch-screen printer models, press to confirm.

Weblink server not set up. Contact system administrator.

An error occurred on the Weblink server, or the server is not configured properly. Touch **Continue** to clear the message. If the message appears again, contact your system support person.

Solving printer problems

Basic printer problems

The printer is not responding

Action	Yes	No
Step 1 Make sure the printer is turned on. Is the printer turned on?	Go to step 2.	Turn on the printer.
Step 2 Check if the printer is in Sleep mode or Hibernate mode. Is the printer in Sleep mode or Hibernate mode?	Press the Sleep button to wake the printer from Sleep mode or Hibernate mode.	Go to step 3.
Step 3 Check if one end of the power cord is plugged into the printer and the other to a properly grounded electrical outlet. Is the power cord plugged into the printer and a properly grounded electrical outlet?	Go to step 4.	Plug one end of the power cord into the printer and the other to a properly grounded electrical outlet.
Step 4 Check other electrical equipment plugged into the electrical outlet. Does other electrical equipment work?	Unplug the other electrical equipment, and then turn on the printer. If the printer does not work, then reconnect the other electrical equipment.	Go to step 5.

Action	Yes	No
Step 5 Check if the cables connecting the printer and the computer are inserted in the correct ports. Are the cables inserted in the correct ports?	Go to step 6.	Make sure to match the following: • The USB symbol on the cable with the USB symbol on the printer • The appropriate Ethernet cable with the Ethernet port
Step 6 Make sure the electrical outlet is not turned off by a switch or breaker. Is the electrical outlet turned off by a switch or breaker?	Turn on the switch or reset the breaker.	Go to step 7.
Step 7 Check if the printer is plugged into any surge protectors, uninterruptible power supplies, or extension cords. Is the printer plugged into any surge protectors, uninterruptible power supplies, or extension cords?	Connect the printer power cord directly to a properly grounded electrical outlet.	Go to step 8.
Step 8 Check if one end of the printer cable is plugged into a port on the printer and the other to the computer, print server, option, or other network device. Is the printer cable securely attached to the printer and the computer, print server, option, or other network device?	Go to step 9.	Connect the printer cable securely to the printer and the computer, print server, option, or other network device.
Step 9 Make sure to install all hardware options properly and remove any packing material. Are all hardware options properly installed and all packing material removed?	Go to step 10.	Turn off the printer, remove all packing materials, then reinstall the hardware options, and then turn on the printer.
Step 10 Check if you have selected the correct port settings in the printer driver. Are the port settings correct?	Go to step 11.	Use correct printer driver settings.
Step 11 Check the installed printer driver. Is the correct printer driver installed?	Go to step 12.	Install the correct printer driver.
Step 12 Turn off the printer, then wait for about 10 seconds, and then turn the printer back on. Is the printer working?	The problem is solved.	Contact **customer support**.

Printer display is blank

Action	Yes	No
Step 1 Press the Sleep button on the printer control panel. Does **Ready** appear on the printer display?	The problem is solved.	Go to step 2.
Step 2 Turn off the printer, then wait for about 10 seconds, and then turn the printer back on. Do **Please wait** and **Ready** appear on the printer display?	The problem is solved.	Turn off the printer, and then contact **customer support**.

Hardware and internal option problems

Cannot detect memory card

Action	Yes	No
Make sure the memory card is installed. **a** Install the memory card. For more information, see “Installing a memory card” on page 29. **Note:** Check if the memory card is securely connected to the printer controller board. **b** Print a menu settings page, and then check if the card is listed in the Installed Options list. Is the card listed in the Installed Options list?	The problem is solved.	Contact **customer support**.

Cannot detect internal option

Action	Yes	No
Step 1 Turn off the printer, then wait for about 10 seconds, and then turn the printer back on. Does the internal option operate correctly?	The problem is solved.	Go to step 2.
Step 2 Check if the internal option is properly installed in the controller board. **a** Turn off the printer. **b** Unplug the power cord from the electrical outlet. **c** Make sure the internal option is installed in the appropriate connector in the controller board. **d** Turn the printer back on. Is the internal option properly installed in the controller board?	Go to step 3.	Connect the internal option to the controller board.

Action	Yes	No
Step 3 Print a menu settings page, and then check to see if the internal option is listed in the Installed Options list. Is the internal option listed in the menu settings page?	Go to step 4.	Reinstall the internal option.
Step 4 Check if the option is available in the printer driver. It may be necessary to manually add the internal option in the printer driver to make it available for print jobs. For more information, see “Updating available options in the printer driver” on page 39. Is the internal option available in the printer driver?	Go to step 5.	Manually add the internal option in the printer driver.
Step 5 **a** Check if the internal option is selected. **Note:** From the application you are using, select the internal option. For Mac OS X version 9 users, make sure the printer is set up in Chooser. **b** Resend the print job. Does the internal option operate correctly?	The problem is solved.	Contact **customer support**.

Tray problems

Action	Yes	No
Step 1 **a** Pull out the tray, and then do one or more of the following: • Check for paper jams or misfeeds. • Check if the paper size indicators on the paper guides are aligned with the paper size indicators on the tray. • If you are printing on custom-size paper, then make sure that the paper guides rest against the edges of the paper. • Make sure the paper is below the maximum paper fill indicator. • Make sure paper lies flat in the tray. **b** Check if the tray closes properly. Is the tray working?	The problem is solved.	Go to step 2.
Step 2 **a** Turn off the printer, then wait about 10 seconds, and then turn the printer back on. **b** Resend the print job. Is the tray working?	The problem is solved.	Go to step 3.

Action	Yes	No
Step 3 Check if the tray is installed and recognized by the printer. Print a menu settings page, and then check if the tray is listed in the Installed Features list. Is the tray listed in the menu settings page?	Go to step 4.	Reinstall the tray. For more information, see the setup documentation that came with the tray.
Step 4 Check if the tray is available in the printer driver. **Note:** If necessary, manually add the tray in the printer driver to make it available for print jobs. For more information, see “Updating available options in the printer driver” on page 39. Is the tray available in the printer driver?	The problem is solved.	Contact **customer support**.

Paper feed problems

Jammed pages are not reprinted

Action	Yes	No
a Turn on jam recovery. **1** From the printer control panel, navigate to: **Settings** > **General Settings** > **Print Recovery** > **Jam Recovery** **2** Select **On** or **Auto**. **3** Depending on your printer model, press or touch **Submit**. **b** Resend the pages that did not print. Were the jammed pages reprinted?	The problem is solved.	Contact **customer support**.

Paper frequently jams

Action	Yes	No
Step 1 **a** Pull out the tray, and then do one or more of the following: • Make sure paper lies flat in the tray. • Check if the paper size indicators on the paper guides are aligned with the paper size indicators on the tray. • Check if the paper guides are aligned against the edges of the paper. • Make sure the paper is below the maximum paper fill indicator. • Check if you are printing on a recommended paper size and type. **b** Insert the tray properly. If jam recovery is enabled, then the print jobs will reprint automatically. Do paper jams still occur frequently?	Go to step 2.	The problem is solved.
Step 2 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Do paper jams still occur frequently?	Go to step 3.	The problem is solved.
Step 3 **a** Review the tips on avoiding jams. For more information, see “Avoiding jams” on page 161. **b** Follow the recommendations, and then resend the print job. Do paper jams still occur frequently?	Contact **customer support**.	The problem is solved.

Paper jam message remains after jam is cleared

Action	Yes	No
a Do either of the following: • For touch-screen printer models, touch or **Done**. • For non-touch-screen printer models, select **Next** > > **Clear the jam, press OK** > . **b** Follow the instructions on the printer display. Does the paper jam message remain?	Contact **customer support**.	The problem is solved.

Solving home screen applications problems

- “An application error has occurred” on page 190

An application error has occurred

Action	Yes	No
Step 1 Check the system log for relevant details. **a** Open a Web browser, and then type the printer IP address in the address field. If you do not know the IP address of the printer, then you can: • View the IP address on the printer home screen. • Print a network setup page or the menu settings pages, and then locate the IP address in the TCP/IP section. **Note:** An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123. **b** Click **Settings** > **Apps** > **Apps Management** > **System** tab > **Log**. **c** From the Filter menu, select an application status. **d** From the Application menu, select an application, and then click **Submit**. Does an error message appear in the log?	Go to step 2.	Contact **customer support**.
Step 2 Resolve the error. Is the application working now?	The problem is solved.	Contact **customer support**.

Solving print problems

Printing problems

Incorrect characters print

Action	Yes	No
Step 1 Make sure the printer is not in Hex Trace mode. **Note:** If **Ready Hex** appears on the printer display, then turn off the printer, and then turn it back on to deactivate Hex Trace mode. Is the printer in Hex Trace mode?	Deactivate Hex Trace mode.	Go to step 2.
Step 2 **a** From the printer control panel, select **Standard Network** or **Network [x]**, and then set SmartSwitch to On. **b** Resend the print job. Do incorrect characters print?	Contact **customer support**.	The problem is solved.

Job prints from the wrong tray or on the wrong paper

Action	Yes	No
Step 1 **a** Check if you are printing on paper that is supported by the tray. **b** Resend the print job. Did the job print from the correct tray or on the correct paper?	The problem is solved.	Go to step 2.
Step 2 **a** From the Paper menu on the printer control panel, set the paper size and type to match the paper loaded in the tray. **b** Resend the print job. Did the job print from the correct tray or on the correct paper?	The problem is solved.	Go to step 3.
Step 3 **a** Depending on your operating system, open Printing Preferences or the Print dialog, and then specify the paper type. **b** Resend the print job. Did the job print from the correct tray or on the correct paper?	The problem is solved.	Go to step 4.

Action	Yes	No
Step 4 **a** Check if the trays are not linked. **b** Resend the print job. Did the job print from the correct tray or on the correct paper?	The problem is solved.	Contact **customer support**.

Large jobs do not collate

Action	Yes	No
Step 1 **a** From the Finishing menu on the printer control panel, set Collate to (1,2,3) (1,2,3). **b** Resend the print job. Did the job print and collate correctly?	The problem is solved.	Go to step 2.
Step 2 **a** From the printer software, set Collate to (1,2,3) (1,2,3). **Note:** Setting Collate to (1,1,1) (2,2,2) in the software overrides the setting in the Finishing menu. **b** Resend the print job. Did the job print and collate correctly?	The problem is solved.	Go to step 3.
Step 3 Reduce the complexity of the print job by eliminating the number and size of fonts, the number and complexity of images, and the number of pages in the job. Did the job print and collate correctly?	The problem is solved.	Contact **customer support**.

Error message about reading the flash drive appears

Action	Yes	No
Step 1 Check if the flash drive is inserted into the front USB port. **Note:** The flash drive will not work if it is inserted into the rear USB port. Is the flash drive inserted into the front USB port?	Go to step 2.	Insert the flash drive into the front USB port.
Step 2 Check if the indicator light on the printer control panel is blinking green. **Note:** A green blinking light indicates that the printer is busy. Is the indicator light blinking green?	Wait until the printer is ready, then view the held jobs list, and then print the documents.	Go to step 3.

Action	Yes	No
Step 3 **a** Check for an error message on the display. **b** Clear the message. Does the error message still appear?	Go to step 4.	The problem is solved.
Step 4 Check if the flash drive is supported. For more information on tested and approved USB flash drives, see “Supported flash drives and file types” on page 71. Does the error message still appear?	Go to step 5.	The problem is solved.
Step 5 Check if the USB port is disabled by the system support person. Does the error message still appear?	Contact **customer support**.	The problem is solved.

Printing slows down

Notes:

- When printing using narrow paper, the printer prints at a reduced speed to prevent damage to the fuser.
- The printer speed may be reduced if printing for long periods of time, or printing at elevated temperatures.

Action	Yes	No
Place letter- or A4-size paper in the tray, and then resend the print job. Does the print speed increase?	The problem is solved.	Contact **customer support**.

Print jobs do not print

Action	Yes	No
Step 1 **a** From the document you are trying to print, open the Print dialog and check if you have selected the correct printer. **Note:** If the printer is not the default printer, then you must select the printer for each document that you want to print. **b** Resend the print job. Do the jobs print?	The problem is solved.	Go to step 2.
Step 2 **a** Check if the printer is plugged in and turned on, and if **Ready** appears on the printer display. **b** Resend the print job. Do the jobs print?	The problem is solved.	Go to step 3.

Action	Yes	No
Step 3 If an error message appears on the printer display, then clear the message. **Note:** The printer continues to print after clearing the message. Do the jobs print?	The problem is solved.	Go to step 4.
Step 4 **a** Check if the ports (USB, serial, or Ethernet) are working and if the cables are securely connected to the computer and the printer. **Note:** For more information, see the setup documentation that came with the printer. **b** Resend the print job. Do the jobs print?	The problem is solved.	Go to step 5.
Step 5 **a** Turn off the printer, then wait for about 10 seconds, and then turn the printer back on. **b** Resend the print job. Do the jobs print?	The problem is solved.	Go to step 6.
Step 6 **a** Remove, and then reinstall the printer software. For more information, see “Installing the printer software” on page 39. **Note:** The printer software is available at **http://support.lexmark.com**. **b** Resend the print job. Do the jobs print?	The problem is solved.	Contact **customer support**.

Print job takes longer than expected

Action	Yes	No
Step 1 Change the environmental settings of the printer. **a** From the printer control panel, navigate to: **Settings** > **General Settings** **b** Select **Eco-Mode** or **Quiet Mode**, and then select **Off**. **Note:** Disabling Eco-Mode or Quiet Mode may increase the consumption of energy or supplies, or both. Did the job print?	The problem is solved.	Go to step 2.

Action	Yes	No
Step 2 Reduce the number and size of fonts, the number and complexity of images, and the number of pages in the print job, and then resend the job Did the job print?	The problem is solved.	Go to step 3.
Step 3 **a** Remove held jobs stored in the printer memory. **b** Resend the print job. Did the job print?	The problem is solved.	Go to step 4.
Step 4 **a** Disable the Page Protect feature. From the printer control panel, navigate to: **Settings** > **General Settings** > **Print Recovery** > **Page Protect** > **Off** **b** Resend the print job. Did the job print?	The problem is solved.	Go to step 5.
Step 5 Install additional printer memory, and then resend the print job. Did the job print?	The problem is solved.	Contact **customer support**.

Repeating defects appear on prints



Action	Yes	No
Step 1 Measure the distance between the defects. Check for a distance between the defects that equals: • 25.1 mm (0.98 in.) • 29.8 mm (1.17 in.) • 43.9 mm (1.72 in.) • 45.5 mm (1.79 in.) • 94.2 mm (3.70 in.) Is the distance between defects equal to one of the listed measurements?	Go to step 2.	**1** Check if the distance between the defects is equal to one of the following: • 37.7 mm (1.48 in.) • 78.5 mm (3.09 in.) • 95 mm (3.74 in.) **2** Take note of the distance, and then contact **customer support** or your service representative.
Step 2 Replace the imaging kit, and then resend the print job. Do the repeating defects still appear?	Contact **customer support**.	The problem is solved.

Tray linking does not work

Notes:

- The trays can detect paper length.
- The multipurpose feeder does not automatically detect the paper size. You must set the size from the Paper Size/Type menu.

Action	Yes	No
Step 1 **a** Open the trays, and then check if they contain paper of the same size and type. • Check if the paper guides are in the correct positions for the size of the paper loaded in each tray. • Check if the paper size indicators on the paper guides are aligned with the paper size indicators on the tray. **b** Resend the print job. Do the trays link correctly?	The problem is solved.	Go to step 2.

Action	Yes	No
Step 2 **a** From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the trays to be linked. **Note:** The paper size and type must match for trays to be linked. **b** Resend the print job. Do the trays link correctly?	The problem is solved.	Contact **customer support**.

Multiple-language PDF files do not print

Action	Yes	No
Step 1 **a** Check if the print options for the PDF output are set to embed all fonts. **b** Generate a new PDF file, and then resend the print job. Do the files print?	The problem is solved.	Go to step 2.
Step 2 **a** Open the document you want to print in Adobe Acrobat. **b** Click **File** > **Print** > **Advanced** > **Print As Image** > **OK** > **OK** . Do the files print?	The problem is solved.	Contact **customer support**.

Unexpected page breaks occur

Action	Yes	No
Step 1 Adjust the print timeout settings. **a** From the printer control panel, navigate to: **Settings** > **General Settings** > **Timeouts** > **Print Timeout** **b** Select a higher setting and then, depending on your printer model, select or **Submit**. **c** Resend the print job. Did the file print correctly?	The problem is solved.	Go to step 2.
Step 2 **a** Check the original file for manual page breaks. **b** Resend the print job. Did the file print correctly?	The problem is solved.	Contact **customer support**.

Print quality problems

Characters have jagged or uneven edges



Action	Yes	No
Step 1 **a** Print a font sample list to check if the fonts you are using are supported by the printer. **1** From the printer control panel, navigate to: **Menus** > **Reports** > **Print Fonts** **2** Select **PCL Fonts** or **PostScript Fonts**. **b** Resend the print job. Are you using fonts that are supported by the printer?	Go to step 2.	Select a font that is supported by the printer.
Step 2 Check if the fonts installed on the computer are supported by the printer. Are the fonts installed on the computer supported by the printer?	The problem is solved.	Contact **customer support**.

Clipped pages or images





Action	Yes	No
Step 1 **a** Move the width and length guides in the tray to the correct positions for the paper loaded. **b** Resend the print job. Is the page or image clipped?	Go to step 2.	The problem is solved.

Action	Yes	No
Step 2 From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the tray. Does the paper size match the paper loaded in the tray?	Go to step 3.	Do one or more of the following: • From the printer control panel, change the paper size to match the paper loaded in the tray. • From the printer control panel, change the paper type to match the paper loaded in the tray.
Step 3 **a** Depending on your operating system, specify the paper size from Printing Preferences or from the Print dialog. **b** Resend the print job. Is the page or image clipped?	Go to step 4.	The problem is solved.
Step 4 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Is the page or image clipped?	Contact **customer support**.	The problem is solved.

Gray background on prints



Action	Yes	No
Step 1 Reduce the toner darkness. **a** From the Quality menu on the printer control panel, reduce the toner density. **Note:** 4 is the factory default setting. **b** Resend the print job. Did the gray background disappear?	The problem is solved.	Go to step 2.
Step 2 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Did the gray background disappear?	The problem is solved.	Contact **customer support**.

Horizontal voids appear on prints



Action	Yes	No
Step 1 **a** Make sure your software program is using a correct fill pattern. **b** Resend the print job. Do horizontal voids appear on prints?	Go to step 2.	The problem is solved.
Step 2 **a** Load the specified tray or feeder with a recommended type of paper. **b** Resend the print job. Do horizontal voids appear on prints?	Go to step 3.	The problem is solved.

Action	Yes	No
Step 3 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Do horizontal voids appear on prints?	Go to step 4.	The problem is solved.
Step 4 Replace the imaging kit, and then resend the print job. Do horizontal voids appear on prints?	Contact **customer support**.	The problem is solved.

Incorrect margins on prints



Action	Yes	No
Step 1 **a** Move the width and length guides in the tray to the correct positions for the paper size loaded. **b** Resend the print job. Are the margins correct?	The problem is solved.	Go to step 2.
Step 2 From the printer control panel, set the paper size in the Paper menu to match the paper loaded in the tray. Does the paper size match the paper loaded in the tray?	Go to step 3.	Do one or more of the following: • Specify the paper size from the tray settings to match the paper loaded in the tray. • Change the paper loaded in the tray to match the paper size specified in the tray settings.

Action	Yes	No
Step 3 **a** Depending on your operating system, specify the paper size from Printing Preferences or from the Print dialog. **b** Resend the print job. Are the margins correct?	The problem is solved.	Contact **customer support**.

Paper curl

Action	Yes	No
Step 1 Move the width and length guides in the tray to the correct positions for the size of the paper loaded. Are the width and length guides positioned correctly?	Go to step 2.	Adjust the width and length guides.
Step 2 From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray. Do the paper type and weight match the type and weight of the paper in the tray?	Go to step 3.	Specify the paper type and weight from the tray settings to match the paper loaded in the tray.
Step 3 **a** Depending on your operating system, specify the paper type and weight from Printing Preferences or from the Print dialog. **b** Resend the print job. Is the paper still curled?	Go to step 4.	The problem is solved.
Step 4 **a** Remove the paper from the tray, and then turn it over. **b** Resend the print job. Is the paper still curled?	Go to step 5.	The problem is solved.
Step 5 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Is the paper still curled?	Contact **customer support**.	The problem is solved.

Print irregularities



Action	Yes	No
Step 1 **a** Move the width and length guides in the tray to the correct positions for the size of the paper loaded in the tray. **b** Resend the print job. Do print irregularities still appear?	Go to step 2.	The problem is solved.
Step 2 From the printer control panel, set the paper size and type in the Paper menu to match the paper loaded in the tray. Is the tray set to the size and type of the paper loaded in the tray?	Go to step 3.	Do one or more of the following: • Specify the paper size from the tray settings to match the paper loaded in the tray. • Change the paper loaded in the tray to match the paper size specified in the tray settings.
Step 3 **a** Depending on your operating system, specify the paper type and weight from Printing Preferences or from the Print dialog. **b** Resend the print job. Do print irregularities still appear?	Go to step 4.	The problem is solved.
Step 4 Check if the paper loaded in the tray has texture or rough finishes. Are you printing on textured or rough paper?	From the printer control panel, set the paper texture in the Paper menu to match the paper loaded in the tray.	Go to step 5.
Step 5 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Do print irregularities still appear?	Go to step 6.	The problem is solved.

Action	Yes	No
Step 6 Replace the imaging kit, and then resend the print job. Do print irregularities still appear?	Contact **customer support**.	The problem is solved.

Print is too dark



Action	Yes	No
Step 1 **a** From the Quality menu on the printer control panel, select **Color Adjust**. **b** Resend the print job. Is the print still too dark?	Go to step 2.	The problem is solved.
Step 2 **a** From the Quality menu on the printer control panel, reduce the toner darkness. **Note:** 4 is the factory default setting. **b** Resend the print job. Is the print still too dark?	Go to step 3.	The problem is solved.
Step 3 **a** From the printer control panel, set the paper type, texture, and weight in the Paper menu to match the paper loaded in the tray. **b** Resend the print job. Is the tray set to the type, texture, and weight of the paper loaded?	Go to step 4.	Change the paper loaded in the tray to match the paper type, texture, and weight specified in the tray settings.
Step 4 **a** Depending on your operating system, specify the paper type, texture and weight from Printing Preferences or from the Print dialog. **b** Resend the print job. Is the print still too dark?	Go to step 5.	The problem is solved.

Action	Yes	No
Step 5 Check if the paper loaded in the tray has texture or rough finishes. Are you printing on textured or rough paper?	From the printer control panel, set the paper texture in the Paper menu to match the paper loaded on the tray.	Go to step 6.
Step 6 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Is the print still too dark?	Go to step 7.	The problem is solved.
Step 7 Replace the imaging kit, and then resend the print job. Is the print still too dark?	Contact **customer support**.	The problem is solved.

Print is too light



Action	Yes	No
Step 1 **a** From the Quality menu on the printer control panel, select **Color Adjust**. **b** Resend the print job. Is the print still too light?	Go to step 2.	The problem is solved.
Step 2 **a** From the Quality menu on the printer control panel, increase the toner darkness. **Note:** 4 is the factory default setting. **b** Resend the print job. Is the print still too light?	Go to step 3.	The problem is solved.

Action	Yes	No
Step 3 From the printer control panel, set the paper type, texture, and weight in the Paper menu to match the paper loaded in the tray. Is the tray set to the type, texture, and weight of the paper loaded?	Go to step 4.	Specify the paper type, texture, and weight from the tray settings to match the paper loaded in the tray.
Step 4 **a** Depending on your operating system, specify the paper type, texture, and weight from Printing Preferences or from the Print dialog. **b** Resend the print job. Is the print still too light?	Go to step 5.	The problem is solved.
Step 5 Make sure that the paper has no texture or rough finishes. Are you printing on textured or rough paper?	From the printer control panel, set the paper texture in the Paper menu to match the paper loaded in the tray	Go to step 5.
Step 6 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Is the print still too light?	Go to step 7.	The problem is solved.
Step 7 Replace the imaging kit, and then resend the print job. Is the print still too light?	Contact **customer support**.	The problem is solved.

Printer is printing blank pages



Action	Yes	No
Step 1 **a** Check if there is packing material left on the imaging kit. **1** Remove the imaging kit. **2** Check if the packing material is properly removed from the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **3** Reinstall the imaging kit. **b** Resend the print job. Is the printer still printing blank pages?	Go to step 2.	The problem is solved.
Step 2 Replace the imaging kit, and then resend the print job. Is the printer still printing blank pages?	Contact **customer support**.	The problem is solved.

Printer is printing solid black pages

Action	Yes	No
Step 1 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Is the printer printing solid black pages?	Go to step 2.	The problem is solved.
Step 2 Replace the imaging kit, and then resend the print job. Is the printer printing solid black pages?	Contact **customer support**.	The problem is solved.

Shadow images appear on prints



Action	Yes	No
Step 1 Check if the paper loaded in the tray has the correct paper type and weight. Is paper with the correct paper type and weight loaded in the tray?	Go to step 2.	Load paper with the correct paper type and weight in the tray.
Step 2 From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray. Do the printer settings match the type and weight of the paper loaded?	Go to step 3.	Change the paper type and weight to match the paper loaded in the tray.
Step 3 **a** Depending on your operating system, specify the paper type and weight from Printing Preferences or from the Print dialog. **b** Resend the print job. Do shadow images still appear on prints?	Go to step 4.	The problem is solved.
Step 4 Replace the imaging kit, and then resend the print job. Do shadow images still appear on prints?	Contact **customer support**.	The problem is solved.

Skewed print



Action	Yes	No
Step 1 **a** Move the width and length guides in the tray to the correct positions for the size of the paper loaded. **b** Resend the print job. Is the print still skewed?	Go to step 2.	The problem is solved.
Step 2 **a** Check if you are printing on a paper that is supported by the tray. **b** Resend the print job. Is the print still skewed?	Contact **customer support**.	The problem is solved.

Streaked horizontal lines appear on prints



Action	Yes	No
Step 1 **a** Depending on your operating system, specify the tray or feeder from Printing Preferences or the Print dialog. **b** Resend the print job. Do streaked horizontal lines appear on prints?	Go to step 2.	The problem is solved.
Step 2 From the printer control panel, set the paper type and weight in the Paper menu to match the paper loaded in the tray. Do the paper type and weight match the paper in the tray?	Go to step 3.	Do one or more of the following: • Specify the paper type and weight from the tray settings to match the paper loaded in the tray. • Change the paper loaded in the tray to match the paper type and weight specified in the tray settings.

Action	Yes	No
Step 3 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Do streaked horizontal lines appear on prints?	Go to step 4.	The problem is solved.
Step 4 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Do streaked horizontal lines appear on prints?	Go to step 5.	The problem is solved.
Step 5 Replace the imaging kit, and then resend the print job. Do streaked horizontal lines appear on prints?	Contact **customer support**.	The problem is solved.

Streaked vertical lines appear on prints





Action	Yes	No
Step 1 **a** Depending on your operating system, specify the paper type, texture, and weight from Printing Preferences or from the Print dialog. **b** Resend the print job. Do streaked vertical lines appear on prints?	Go to step 2.	The problem is solved.

Action	Yes	No
Step 2 From the printer control panel, set the paper texture, type, and weight in the Paper menu to match the paper loaded in the tray. Do the paper texture, type, and weight match the paper in the tray?	Go to step 3.	Do one or more of the following: • Specify the paper texture, type, and weight from the tray settings to match the paper loaded in the tray. • Change the paper loaded in the tray to match the paper size specified in the tray settings.
Step 3 **a** Load paper from a fresh package. **Note:** Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it. **b** Resend the print job. Do streaked vertical lines appear on prints?	Go to step 4.	The problem is solved.
Step 4 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Do streaked vertical lines appear on prints?	Go to step 5.	The problem is solved.
Step 5 Replace the imaging kit, and then resend the print job. Do streaked vertical lines appear on prints?	Contact **customer support**.	The problem is solved.

Transparency print quality is poor

Action	Yes	No
Step 1 From the printer control panel, set the paper type in the Paper menu to match the paper loaded in the tray. Is the paper type for the tray set to Transparency?	Go to step 2.	Set the paper type to Transparency.
Step 2 **a** Check if you are using a recommended type of transparency. **b** Resend the print job. Is the print quality still poor?	Contact **customer support**.	The problem is solved.

Toner fog or background shading appears on prints



Action	Yes	No
Step 1 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Does fog or shading disappear from the prints?	The problem is solved.	Go to step 2.
Step 2 Replace the imaging kit, and then resend the print job. Does fog or shading disappear from the prints?	The problem is solved.	Contact **customer support**.

Toner rubs off



Action	Yes	No
Step 1 From the Paper menu on the printer control panel, check the paper type and weight. Do the paper type and texture match the paper loaded in the tray?	Go to step 2.	Specify the paper type and weight from the tray settings to match the paper loaded in the tray.
Step 2 Check if you are printing on paper with texture or rough finishes. Are you printing on textured or rough paper?	From the Paper menu on the printer control panel, set the paper texture.	Contact **customer support**.

Toner specks appear on prints

Action	Yes	No
Replace the imaging kit, and then resend the print job. Do toner specks appear on prints?	Contact **customer support**.	The problem is solved.

Uneven print density



Action	Yes	No
Replace the imaging kit, and then resend the print job. Is the print density uneven?	Contact **customer support**.	The problem is solved.

Vertical voids appear on prints



Action	Yes	No
Step 1 **a** Check if your software program is using a correct fill pattern. **b** Resend the print job. Do vertical voids appear on prints?	Go to step 2.	The problem is solved.
Step 2 **a** From the Paper Menu on the printer control panel, check the paper type and paper weight. **b** Resend the print job. Do vertical voids appear on prints?	Go to step 3.	The problem is solved.
Step 3 Check if you are using a recommended type of paper. **a** Load paper source with a recommended type of paper. **b** Resend the print job. Do vertical voids appear on prints?	Go to step 4.	The problem is solved.
Step 4 **a** Remove, and then reinstall the imaging kit. **Warning—Potential Damage:** Do not expose the imaging kit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems. **Warning—Potential Damage:** Do not touch the underside of the imaging kit. This could damage the imaging kit. **b** Resend the print job. Do vertical voids appear on prints?	Go to step 5.	The problem is solved.
Step 5 Replace the imaging kit, and then resend the print job. Do vertical voids appear on prints?	Contact **customer support**.	The problem is solved.

Color quality problems

FAQ about color printing

What is RGB color?

Red, green, and blue light can be added together in various amounts to produce a large range of colors observed in nature. For example, red and green can be combined to create yellow. Televisions and computer monitors create colors in this manner. RGB color is a method of describing colors by indicating the amount of red, green, or blue needed to produce a certain color.

What is CMYK color?

Cyan, magenta, yellow, and black inks or toners can be printed in various amounts to produce a large range of colors observed in nature. For example, cyan and yellow can be combined to create green. Printing presses, inkjet printers, and color laser printers create colors in this manner. CMYK color is a method of describing colors by indicating the amount of cyan, magenta, yellow, and black needed to reproduce a particular color.

How is color specified in a document to be printed?

Software programs typically specify the document color using RGB or CMYK color combinations. Additionally, they let users modify the color of each object in a document. For more information, see the help information of your operating system.

How does the printer know what color to print?

When a user prints a document, information describing the type and color of each object is sent to the printer. The color information is passed through color conversion tables that translate the color into the appropriate amounts of cyan, magenta, yellow, and black toner needed to produce the color you want. The object information determines the application of color conversion tables. For example, it is possible to apply one type of color conversion table to text while applying a different color conversion table to photographic images.

What is manual color correction?

When manual color correction is enabled, the printer employs user-selected color conversion tables to process objects. However, Color Correction must be set to Manual, or no user-defined color conversion will be implemented. Manual color correction settings are specific to the type of object being printed (text, graphics, or images), and how the color of the object is specified in the software program (RGB or CMYK combinations).

Notes:

- Manual color correction is not useful if the software program does not specify colors with RGB or CMYK combinations. It is also not effective in situations in which the software program or the computer operating system controls the adjustment of colors.
- When **Auto Color Correction** is selected, the color conversion tables will generate preferred colors used for the majority of the documents.

To manually apply a different color conversion table, do the following:

1. From the Quality menu on the printer control panel, select **Color Correction**, and then select **Manual**.
2. From the Quality menu on the printer control panel, select **Manual Color**, and then select the appropriate color conversion table for the affected object type.

Object type	Color conversion tables
RGB Image RGB Text RGB Graphics	• **Vivid**—Produces brighter, more saturated colors and may be applied to all incoming color formats. • **sRGB Display**—Produces an output that approximates the colors displayed on a computer monitor. **Note:** Black toner usage is optimized for printing photographs. • **Display-True Black**—Produces an output that approximates the colors displayed on a computer monitor. This uses only black toner to create all levels of neutral gray. • **sRGB Vivid**—Provides an increased color saturation for the sRGB Display color correction. **Note:** Black toner usage is optimized for printing business graphics. • **Off**—No color correction is implemented.
CMYK Image CMYK Text CMYK Graphics	• **US CMYK**—Applies color correction to approximate the SWOP (Specifications for Web Offset Publishing) color output. • **Euro CMYK**—Applies color correction to approximate Euroscale color output. • **Vivid CMYK**—Increases the color saturation of the US CMYK color correction setting. • **Off**—No color correction is implemented.

How can I match a particular color (such as a corporate logo)?

Nine types of Color Samples sets are available from the Quality menu on the printer control panel. These are also available from the Color Samples page of the Embedded Web Server. Selecting any sample set generates a multiple-page printout consisting of hundreds of colored boxes. Either a CMYK or RGB combination is located on each box, depending on the table selected. The observed color of each box is obtained by passing the CMYK or RGB combination labeled on the box through the selected color conversion table.

By examining Color Samples sets, you can identify the box whose color is the closest to the color you want. The color combination labeled on the box can then be used for modifying the color of the object in a software program. For more information, see the help information of your operating system.

Note: Manual color correction may be necessary to utilize the selected color conversion table for the particular object.

Selecting which Color Samples set to use for a particular color-matching problem depends on the Color Correction setting being used , the type of object being printed, and how the color of the object is specified in the software program. When Color Correction is set to Off, the color is based on the print job information, and no color conversion is implemented.

Note: The Color Samples pages are not useful if the software program does not specify colors with RGB or CMYK combinations. Additionally, certain situations exist in which the software program or the computer operating system adjusts the RGB or CMYK combinations specified in the program through color management. The resulting printed color may not be an exact match of the Color Samples pages.

What are detailed color samples and how do I access them?

Detailed color samples sets are available only through the Embedded Web Server of a network printer. A detailed Color Samples set contains a range of shades that are similar to a user-defined RGB or CMYK value. The likeness of the colors in the set is dependent on the value entered in the RGB or CMYK Increment box.

To access a detailed Color Samples set from the Embedded Web Server, do the following:

1 Open a Web browser, and then type the printer IP address in the address field.

Note: If you do not know the IP address or printer name, then you can:

- View the information on the printer home screen, or in the TCP/IP section in the Networks/Ports menu.
- Print a network setup page or menu settings page, and then locate the information in the TCP/IP section.

2 Click **Configuration** > **Color Samples** > **Detailed Options**.

3 Select a color conversion table.

4 Enter the RGB or CMYK color number.

5 Enter an increment value from 1 to 255.

Note: The closer the value is to 1, the narrower the color sample range will appear.

6 Click **Print**.

Prints on color transparencies appear dark when projected

Note: This problem occurs when projecting transparencies with reflective overhead projectors. To obtain the highest projected color quality, transmissive overhead projectors are recommended.

Action	Yes	No
Step 1 From the printer control panel, make sure the paper type setting is set to Transparency. Is the paper type setting correct?	Go to step 2.	Set the paper type to Transparency.
Step 2 Reduce the toner darkness, and then resend the print job. Does the print on the color transparency look lighter?	The problem is solved.	Go to step 3.
Step 3 Make sure you are using a recommended type of color transparency, and then resend the print job. Does the print on the color transparency look lighter?	The problem is solved.	Contact **customer support**.

The color of the print does not match the color of the original file

Note: The color conversion tables used in Auto Color Correction mode generally approximate the colors of a standard computer monitor. However, because of technology differences that exist between printers and monitors, there are many colors that can also be affected by monitor variations and lighting conditions.

Action	Yes	No
Step 1 **a** Set Color Correction to Off. **Note:** When the printer color correction is disabled, the color is based on the print job information, and no color conversion is implemented. **b** Resend the print job. Does the color of the print match the color of the file on the computer screen?	The problem is solved.	Go to step 2.
Step 2 From the Quality menu on the printer control panel, do the following: **a** Select **Color Correction**, and then select **Manual**. **b** Select **Manual Color**, and then select the appropriate color conversion table for the affected object type. **c** Resend the print job. Does the color of the print match the color of the file on the computer screen?	The problem is solved.	Contact **customer support**.

The print appears tinted

Action	Yes	No
Adjust the color balance. **a** From the Color Balance menu on the printer control panel, increase or decrease the values for cyan, magenta, yellow, and black. **b** Resend the print job. Does the print still appear tinted?	The problem is solved.	Contact **customer support**.

Embedded Web Server does not open

Action	Yes	No
Step 1 **a** Turn on the printer. **b** Open a Web browser, and then type the printer IP address. **c** Press **Enter**. Does the Embedded Web Server open?	The problem is solved.	Go to step 2.

Action	Yes	No
Step 2 Make sure the printer IP address is correct. **a** View the printer IP address: • From the TCP/IP section in the Network/Ports menu • By printing a network setup page or menu settings page, and then finding the TCP/IP section **Note:** An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123. **b** Open a Web browser, and then type the IP address. **Note:** Depending on the network settings, you may need to type "**`https://`**" instead of "**`http://`**" before the printer IP address to access the Embedded Web Server. **c** Press **Enter**. Does the Embedded Web Server open?	The problem is solved.	Go to step 3.
Step 3 Check if the network is working. **a** Print a network setup page. **b** Check the first section of the network setup page and confirm that the status is Connected. **Note:** If the status is Not Connected, then the connection may be intermittent, or the network cable may be defective. Contact your system support person for a solution, and then print another network setup page. **c** Open a Web browser, and then type the printer IP address. **d** Press **Enter**. Does the Embedded Web Server open?	The problem is solved.	Go to step 4.
Step 4 Check if the cable connections to the printer and print server are secure. **a** Connect the cables properly. For more information, see the setup documentation that came with the printer. **b** Open a Web browser, and then type the printer IP address. **c** Press **Enter**. Does the Embedded Web Server open?	The problem is solved.	Go to step 5.
Step 5 Temporarily disable the Web proxy servers. Proxy servers may block or restrict you from accessing certain Web sites including the Embedded Web Server. Does the Embedded Web Server open?	The problem is solved.	Contact your system support person.

Contacting customer support

When you contact customer support, you will need to be able to describe the problem you are experiencing, the message on the printer display, and the troubleshooting steps you have already taken to find a solution.

You need to know your printer model type and serial number. For more information, see the label at the back of the printer. The serial number is also listed on the menu settings page.

Lexmark has various ways to help you solve your printing problem. Visit the Lexmark Web site at **http://support.lexmark.com**, and then select one of the following:

Tech Library	You can browse our library of manuals, support documentation, drivers, and other downloads to help you solve common problems.
E-mail	You can send an e-mail to the Lexmark team, describing your problem. A service representative will respond and provide you with information to solve your problem.
Live chat	You can chat directly with a service representative. They can work with you to solve your printer problem or provide assistance through Assisted Service where the service representative can remotely connect to your computer through the Internet to troubleshoot problems, install updates, or complete other tasks to help you successfully use your Lexmark product.

Telephone support is also available. In the U.S. or Canada, call 1-800-539-6275. For other countries or regions, visit **http://support.lexmark.com**.

Notices

Product information

Product name:

C2132

Machine type:

5027

Model(s):

639

Edition notice

April 2013

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user’s responsibility.

For Lexmark technical support, visit **http://support.lexmark.com**.

For information on supplies and downloads, visit **www.lexmark.com**.

© 2013 Lexmark International, Inc.

All rights reserved.

GOVERNMENT END USERS

The Software Program and any related documentation are "Commercial Items," as that term is defined in 48 C.F.R. 2.101, "Computer Software" and "Commercial Computer Software Documentation," as such terms are used in 48 C.F.R. 12.212 or 48 C.F.R. 227.7202, as applicable. Consistent with 48 C.F.R. 12.212 or 48 C.F.R. 227.7202-1 through 227.7207-4, as applicable, the Commercial Computer Software and Commercial Software Documentation are licensed to the U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein.

Trademarks

Lexmark, Lexmark with diamond design, and MarkVision are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Mac and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is Hewlett-Packard Company's designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

The following terms are trademarks or registered trademarks of these companies:

Albertus	The Monotype Corporation plc
Antique Olive	Monsieur Marcel OLIVE
Apple-Chancery	Apple Computer, Inc.
Arial	The Monotype Corporation plc
CG Times	Based on Times New Roman under license from The Monotype Corporation plc, is a product of Agfa Corporation
Chicago	Apple Computer, Inc.
Clarendon	Linotype-Hell AG and/or its subsidiaries
Eurostile	Nebiolo
Geneva	Apple Computer, Inc.
GillSans	The Monotype Corporation plc
Helvetica	Linotype-Hell AG and/or its subsidiaries
Hoefler	Jonathan Hoefler Type Foundry
ITC Avant Garde Gothic	International Typeface Corporation
ITC Bookman	International Typeface Corporation
ITC Mona Lisa	International Typeface Corporation
ITC Zapf Chancery	International Typeface Corporation
Joanna	The Monotype Corporation plc
Marigold	Arthur Baker
Monaco	Apple Computer, Inc.
New York	Apple Computer, Inc.
Oxford	Arthur Baker
Palatino	Linotype-Hell AG and/or its subsidiaries
Stempel Garamond	Linotype-Hell AG and/or its subsidiaries
Taffy	Agfa Corporation
Times New Roman	The Monotype Corporation plc
Univers	Linotype-Hell AG and/or its subsidiaries

All other trademarks are the property of their respective owners.

Federal Communications Commission (FCC) compliance information statement

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The FCC Class B limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your point of purchase or service representative for additional suggestions.

The manufacturer is not responsible for radio or television interference caused by using other than recommended cables or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate this equipment.

Note: To assure compliance with FCC regulations on electromagnetic interference for a Class B computing device, use a properly shielded and grounded cable such as Lexmark part number 1021231 for parallel attach or 1021294 for USB attach. Use of a substitute cable not properly shielded and grounded may result in a violation of FCC regulations.

Any questions regarding this compliance information statement should be directed to:

Director of Lexmark Technology & Services
Lexmark International, Inc.
740 West New Circle Road
Lexington, KY 40550
(859) 232–3000

Licensing notices

All licensing notices associated with this product can be viewed from the root directory of the installation software CD.

Noise emission levels

The following measurements were made in accordance with ISO 7779 and reported in conformance with ISO 9296.

Note: Some modes may not apply to your product.

1-meter average sound pressure, dBA	
Printing	50 dBA
Ready	16 dBA

Values are subject to change. See **www.lexmark.com** for current values.

Waste from Electrical and Electronic Equipment (WEEE) directive

The WEEE logo signifies specific recycling programs and procedures for electronic products in countries of the European Union. We encourage the recycling of our products.

If you have further questions about recycling options, visit the Lexmark Web site at **www.lexmark.com** for your local sales office phone number.

Product disposal

Do not dispose of the printer or supplies in the same manner as normal household waste. Consult your local authorities for disposal and recycling options.

Static sensitivity notice

This symbol identifies static-sensitive parts. Do not touch in the areas near these symbols without first touching the metal frame of the printer.

ENERGY STAR

Any Lexmark product bearing the ENERGY STAR emblem on the product or on a start-up screen is certified to comply with Environmental Protection Agency (EPA) ENERGY STAR requirements as configured when shipped by Lexmark.

Temperature information

Ambient operating temperature	15.6 to 32.2°C (60 to 90°F)
Shipping temperature	-40 to 43.3°C (-40 to 110°F)
Storage temperature and relative humidity	1 to 35°C (34 to 95°F) 8 to 80% RH

Información de la energía de México

Consumo de energía en operación:

540 Wh

Consumo de energía en modo de espera:

0.2 Wh

Cantidad de producto por unidad de energía consumida:

2.78 páginas / Wh

Laser notice

The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR, Chapter I, Subchapter J for Class I (1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 60825-1.

Class I laser products are not considered to be hazardous. The printer contains internally a Class IIIb (3b) laser that is nominally a 7 milliwatt gallium arsenide laser operating in the wavelength of 655-675 nanometers. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service condition.

Laser advisory label

A laser notice label may be affixed to this printer as shown:

DANGER - Invisible laser radiation when cartridges are removed and interlock defeated. Avoid exposure to laser beam.
PERIGO - Radiação a laser invisível será liberada se os cartuchos forem removidos e o lacre rompido. Evite a exposição aos feixes de laser.
Opasnost - Nevidljivo lasersko zračenje kada su kasete uklonjene i poništena sigurnosna veza. Izbjegavati izlaganje zracima.
NEBEZPEČÍ - Když jsou vyjmuty kazety a je odblokována pojistka, ze zařízení je vysíláno neviditelné laserové záření. Nevystavujte se působení laserového paprsku.
FARE - Usynlig laserstråling, når patroner fjernes, og spærreanordningen er slået fra. Undgå at blive udsat for laserstrålen.
GEVAAR - Onzichtbare laserstraling wanneer cartridges worden verwijderd en een vergrendeling wordt genegeerd. Voorkom blootstelling aan de laser.
DANGER - Rayonnements laser invisibles lors du retrait des cartouches et du déverrouillage des loquets. Eviter toute exposition au rayon laser.
VAARA - Näkymätöntä lasersäteilyä on varottava, kun värikasetit on poistettu ja lukitus on auki. Vältä lasersäteelle altistumista.
GEFAHR - Unsichtbare Laserstrahlung beim Herausnehmen von Druckkassetten und offener Sicherheitssperre. Laserstrahl meiden.
ΚΙΝΔΥΝΟΣ - Έκλυση αόρατης ακτινοβολίας laser κατά την αφαίρεση των κασετών και την απασφάλιση της μανδάλωσης. Αποφεύγετε την έκθεση στην ακτινοβολία laser.
VESZÉLY – Nem látható lézersugárzás fordulhat elő a patronok eltávolításakor és a zárószerkezet felbontásakor. Kerülje a lézersugárnak való kitettséget.
PERICOLO - Emissione di radiazioni laser invisibili durante la rimozione delle cartucce e del blocco. Evitare l´esposizione al raggio laser.
FARE – Usynlig laserstråling når kassettene tas ut og sperren er satt ut av spill. Unngå eksponering for laserstrålen.
NIEBEZPIECZEŃSTWO - niewidzialne promieniowanie laserowe podczas usuwania kaset i blokady. Należy unikać naświetlenia promieniem lasera.
ОПАСНО! Невидимое лазерное излучение при извлеченных картриджах и снятии блокировки. Избегайте воздействия лазерных лучей.
Pozor – Nebezpečenstvo neviditeľného laserového žiarenia pri odobratých kazetách a odblokovanej poistke. Nevystavujte sa lúčom.
PELIGRO: Se producen radiaciones láser invisibles al extraer los cartuchos con el interbloqueo desactivado. Evite la exposición al haz de láser.
FARA – Osynlig laserstrålning när patroner tas ur och spärrmekanismen är upphävd. Undvik exponering för laserstrålen.
危**险** - 当移除碳粉盒及互**锁**失效**时**会**产**生看不**见**的激光**辐**射，**请**避免暴露在激光光束下。
危險 - 移除碳粉匣與安全連續開關失效時會**產**生看不見的雷射輻射。請避免曝露在雷射光束下。
危険 - カートリッジが取り外され、内部ロックが無効になると、見えないレーザー光が放射されます。 このレーザー光に当たらないようにしてください。

Power consumption

Product power consumption

The following table documents the power consumption characteristics of the product.

Note: Some modes may not apply to your product.

Mode	Description	Power consumption (Watts)
Printing	The product is generating hard-copy output from electronic inputs.	480 W (25 ppm), 580 W (32 ppm)
Copy	The product is generating hard-copy output from hard-copy original documents.	N/A
Scan	The product is scanning hard-copy documents.	N/A
Ready	The product is waiting for a print job.	30 W
Sleep Mode	The product is in a high-level energy-saving mode.	6 W
Hibernate	The product is in a low-level energy-saving mode.	0.5 W
Off	The product is plugged into an electrical outlet, but the power switch is turned off.	0.0 W

The power consumption levels listed in the previous table represent time-averaged measurements. Instantaneous power draws may be substantially higher than the average.

Values are subject to change. See **www.lexmark.com** for current values.

Sleep Mode

This product is designed with an energy-saving mode called *Sleep Mode*. The Sleep Mode saves energy by lowering power consumption during extended periods of inactivity. The Sleep Mode is automatically engaged after this product is not used for a specified period of time, called the *Sleep Mode Timeout*.

Factory default Sleep Mode Timeout for this product (in minutes):	30 minutes

By using the configuration menus, the Sleep Mode Timeout can be modified between 1 minute and 180 minutes. Setting the Sleep Mode Timeout to a low value reduces energy consumption, but may increase the response time of the product. Setting the Sleep Mode Timeout to a high value maintains a fast response, but uses more energy.

Off mode

If this product has an off mode which still consumes a small amount of power, then to completely stop product power consumption, disconnect the power supply cord from the electrical outlet.

Total energy usage

It is sometimes helpful to calculate the total product energy usage. Since power consumption claims are provided in power units of Watts, the power consumption should be multiplied by the time the product spends in each mode in order to calculate energy usage. The total product energy usage is the sum of each mode's energy usage.

Industry Canada compliance statement

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003.

Avis de conformité aux normes de l’industrie du Canada

Cet appareil numérique de classe B est conforme aux exigences de la norme canadienne relative aux équipements pouvant causer des interférences NMB-003.

日本の VCCI 規定

製品にこのマークが表示されている場合、次の要件を満たしています。

この装置は、クラス B 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをしてください。

VCCI-B

European Community (EC) directives conformity

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and the ecodesign of energy-related products.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950.

Regulatory notices for wireless products

This section contains the following regulatory information pertaining to wireless products that contain transmitters, for example, but not limited to, wireless network cards or proximity card readers.

Modular component notice

Wireless-equipped models contain the following modular component(s):

Lexmark Regulatory Type-Model LEX-M01-005; FCC ID:IYLLEXM01005; IC:2376A-M01005

Exposure to radio frequency radiation

The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

Industry Canada (Canada)

This device complies with Industry Canada specification RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate only with the antenna provided. Use of any other antenna is strictly prohibited per regulations of Industry Canada.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF fields in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca/rpb.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Industry Canada (Canada)

Cet appareil est conforme à la norme RSS-210 d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas provoquer d'interférences et (2) il doit accepter toute interférence reçue, y compris celles risquant d'altérer son fonctionnement.

Cet appareil a été conçu pour fonctionner uniquement avec l'antenne fournie. L'utilisation de toute autre antenne est strictement interdite par la réglementation d'Industry Canada.

En application des réglementations d'Industry Canada, l'utilisation d'une antenne de gain supérieur est strictement interdite.

Pour empêcher toute interférence radio au service faisant l'objet d'une licence, cet appareil doit être utilisé à l'intérieur et loin des fenêtres afin de garantir une protection optimale.

Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

L'installateur de cet équipement radio doit veiller à ce que l'antenne soit implantée et dirigée de manière à n'émettre aucun champ HF dépassant les limites fixées pour l'ensemble de la population par Santé Canada. Reportez-vous au Code de sécurité 6 que vous pouvez consulter sur le site Web de Santé Canada www.hc-sc.gc.ca/rpb.

Le terme « IC » précédant le numéro de d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

Notice to users in the European Union

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits, radio equipment and telecommunications terminal equipment and on the ecodesign of energy-related products.

Compliance is indicated by the CE marking.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950.

Products equipped with 2.4GHz Wireless LAN option are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment and on the ecodesign of energy-related products.

Compliance is indicated by the CE marking.

Operation is allowed in all EU and EFTA countries, but is restricted to indoor use only.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product may be used in the countries indicated in the table below.

AT	BE	BG	CH	CY	CZ	DE	DK	EE
EL	ES	FI	FR	HR	HU	IE	IS	IT
LI	LT	LU	LV	MT	NL	NO	PL	PT
RO	SE	SI	SK	TR	UK			

Česky	Společnost Lexmark International, Inc. tímto prohlašuje, že výrobek tento výrobek je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.
Dansk	Lexmark International, Inc. erklærer herved, at dette produkt overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Deutsch	Hiermit erklärt Lexmark International, Inc., dass sich das Gerät dieses Gerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Ελληνική	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η LEXMARK INTERNATIONAL, INC. ΔΗΛΩΝΕΙ ΟΤΙ ΑΥΤΟ ΤΟ ΠΡΟΪΟΝ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
English	Hereby, Lexmark International, Inc., declares that this type of equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Español	Por medio de la presente, Lexmark International, Inc. declara que este producto cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Eesti	Käesolevaga kinnitab Lexmark International, Inc., et seade see toode vastab direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele muudele asjakohastele sätetele.
Suomi	Lexmark International, Inc. vakuuttaa täten, että tämä tuote on direktiivin 1999/5/EY oleellisten vaatimusten ja muiden sitä koskevien direktiivin ehtojen mukainen.
Français	Par la présente, Lexmark International, Inc. déclare que l'appareil ce produit est conforme aux exigences fondamentales et autres dispositions pertinentes de la directive 1999/5/CE.
Magyar	Alulírott, Lexmark International, Inc. nyilatkozom, hogy a termék megfelel a vonatkozó alapvetõ követelményeknek és az 1999/5/EC irányelv egyéb elõírásainak.
Íslenska	Hér með lýsir Lexmark International, Inc. yfir því að þessi vara er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.
Italiano	Con la presente Lexmark International, Inc. dichiara che questo questo prodotto è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latviski	Ar šo Lexmark International, Inc. deklarē, ka šis izstrādājums atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių	Šiuo Lexmark International, Inc. deklaruoja, kad šis produktas atitinka esminius reikalavimus ir kitas 1999/5/EB direktyvos nuostatas.

Malti	Bil-preżenti, Lexmark International, Inc., jiddikjara li dan il-prodott huwa konformi mal-ħtiġijiet essenzjali u ma dispożizzjonijiet oħrajn relevanti li jinsabu fid-Direttiva 1999/5/KE.
Nederlands	Hierbij verklaart Lexmark International, Inc. dat het toestel dit product in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Norsk	Lexmark International, Inc. erklærer herved at dette produktet er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.
Polski	Niniejszym Lexmark International, Inc. oświadcza, że niniejszy produkt jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
Português	A Lexmark International Inc. declara que este este produto está conforme com os requisitos essenciais e outras disposições da Diretiva 1999/5/CE.
Slovensky	Lexmark International, Inc. týmto vyhlasuje, že tento produkt spĺňa základné požiadavky a všetky príslušné ustanovenia smernice 1999/5/ES.
Slovensko	Lexmark International, Inc. izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
Svenska	Härmed intygar Lexmark International, Inc. att denna produkt står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Patent acknowledgment

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Elliptic Curve Cryptography (ECC) Cipher Suites for Transport Layer Security (TLS) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for TLS Elliptic Curve Cipher Suites with SHA-256/382 and AES Galois Counter Mode (GCM) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for TLS Suite B Profile for Transport Layer Security (TLS) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Addition of the Camellia Cipher Suites to Transport Layer Security (TLS) implemented in the product or service.

The use of certain patents in this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for AES-CCM ECC Cipher Suites for TLS implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for IKE and IKEv2 Authentication Using the Eliptic Curve Digital Signature Algorithm (ECDSA) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Suite B Cryptographic Suites for IPSec implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Algorithms for Internet Key Exchange version 1 (IKEv1) implemented in the product or service.

STATEMENT OF LIMITED WARRANTY FOR LEXMARK LASER PRINTERS, LEXMARK LED PRINTERS, AND LEXMARK MULTIFUNCTION LASER PRINTERS

Lexmark International, Inc., Lexington, KY

This limited warranty applies to the United States and Canada. For customers outside the U.S., refer to the country-specific warranty information that came with your product.

This limited warranty applies to this product only if it was originally purchased for your use, and not for resale, from Lexmark or a Lexmark Remarketer, referred to in this statement as “Remarketer.”

Limited warranty

Lexmark warrants that this product:

—Is manufactured from new parts, or new and serviceable used parts, which perform like new parts

—Is, during normal use, free from defects in material and workmanship

If this product does not function as warranted during the warranty period, contact a Remarketer or Lexmark for repair or replacement (at Lexmark's option).

If this product is a feature or option, this statement applies only when that feature or option is used with the product for which it was intended. To obtain warranty service, you may be required to present the feature or option with the product.

If you transfer this product to another user, warranty service under the terms of this statement is available to that user for the remainder of the warranty period. You should transfer proof of original purchase and this statement to that user.

Limited warranty service

The warranty period starts on the date of original purchase as shown on the purchase receipt and ends 12 months later provided that the warranty period for any supplies and for any maintenance items included with the printer shall end earlier if it, or its original contents, are substantially used up, depleted, or consumed. Fuser Units, Transfer/Transport Units, Paper Feed items, if any, and any other items for which a Maintenance Kit is available are substantially consumed when the printer displays a “Life Warning” or “Scheduled Maintenance” message for such item.

To obtain warranty service you may be required to present proof of original purchase. You may be required to deliver your product to the Remarketer or Lexmark, or ship it prepaid and suitably packaged to a Lexmark designated location. You are responsible for loss of, or damage to, a product in transit to the Remarketer or the Lexmark designated location.

When warranty service involves the exchange of a product or part, the item replaced becomes the property of the Remarketer or Lexmark. The replacement may be a new or repaired item.

The replacement item assumes the remaining warranty period of the original product.

Replacement is not available to you if the product you present for exchange is defaced, altered, in need of a repair not included in warranty service, damaged beyond repair, or if the product is not free of all legal obligations, restrictions, liens, and encumbrances.

As part of your warranty service and/or replacement, Lexmark may update the firmware in your printer to the latest version. Firmware updates may modify printer settings and cause counterfeit and/or unauthorized products, supplies, parts, materials (such as toners and inks), software, or interfaces to stop working. Authorized use of genuine Lexmark products will not be impacted.

Before you present this product for warranty service, remove all print cartridges, programs, data, and removable storage media (unless directed otherwise by Lexmark).

For further explanation of your warranty alternatives and the nearest Lexmark authorized servicer in your area contact Lexmark on the World Wide Web.

Remote technical support is provided for this product throughout its warranty period. For products no longer covered by a Lexmark warranty, technical support may not be available or only be available for a fee.

Extent of limited warranty

Lexmark does not warrant uninterrupted or error-free operation of any product or the durability or longevity of prints produced by any product.

Warranty service does not include repair of failures caused by:

—Modification or unauthorized attachments

—Accidents, misuse, abuse or use inconsistent with Lexmark user’s guides, manuals, instructions or guidance

—Unsuitable physical or operating environment

—Maintenance by anyone other than Lexmark or a Lexmark authorized servicer

—Operation of a product beyond the limit of its duty cycle

—Use of printing media outside of Lexmark specifications

—Refurbishment, repair, refilling or remanufacture by a third party of products, supplies or parts

—Products, supplies, parts, materials (such as toners and inks), software, or interfaces not furnished by Lexmark

TO THE EXTENT PERMITTED BY APPLICABLE LAW, NEITHER LEXMARK NOR ITS THIRD PARTY SUPPLIERS OR REMARKETERS MAKE ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS PRODUCT, AND SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY. ANY WARRANTIES THAT MAY NOT BE DISCLAIMED UNDER APPLICABLE LAW ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES, EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD. ALL INFORMATION, SPECIFICATIONS, PRICES, AND SERVICES ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE.

Limitation of liability

Your sole remedy under this limited warranty is set forth in this document. For any claim concerning performance or nonperformance of Lexmark or a Remarketer for this product under this limited warranty, you may recover actual damages up to the limit set forth in the following paragraph.

Lexmark's liability for actual damages from any cause whatsoever will be limited to the amount you paid for the product that caused the damages. This limitation of liability will not apply to claims by you for bodily injury or damage to real property or tangible personal property for which Lexmark is legally liable. **IN NO EVENT WILL LEXMARK BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, INCIDENTAL DAMAGE, OR OTHER ECONOMIC OR CONSEQUENTIAL DAMAGES.** This is true even if you advise Lexmark or a Remarketer of the possibility of such damages. Lexmark is not liable for any claim by you based on a third party claim.

This limitation of remedies also applies to claims against any Suppliers and Remarketers of Lexmark. Lexmark's and its Suppliers' and Remarketers' limitations of remedies are not cumulative. Such Suppliers and Remarketers are intended beneficiaries of this limitation.

Additional rights

Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations or exclusions contained above may not apply to you.

This limited warranty gives you specific legal rights. You may also have other rights that vary from state to state.

Index

Numerics

250-sheet tray
  loading 48
550-sheet tray
  installing 36
  loading 48
650-sheet duo tray
  installing 36
  loading 48

Symbols

[Color] cartridge low [88.xy] 173
[Color] cartridge very low, [x] estimated pages remain [88.xy] 173
[Type] imaging kit low [84.xy] 173
[Type] imaging kit nearly low [84.xy] 173
[Type] imaging kit very low, [x] estimated pages remain [84.xy] 173
[x]-page jam, open front door to clear fuser. 164
[x]-page jam, open front door. 165
[x]-page jam, clear manual feeder. 169
[x]-page jam, clear multipurpose feeder 169
[x]-page jam, clear standard bin. 163
[x]-page jam, open front door to clear duplex. 166
[x]-page jam, open tray [x]. 168

A

accessing the Embedded Web Server 22
Active NIC menu 87
adjusting brightness
  Embedded Web Server 127
  printer control panel 127
Adjusting color 172
adjusting display brightness 127
adjusting Sleep mode 125
adjusting toner darkness 69
administrator settings
  Embedded Web Server 158
AppleTalk menu 92
attaching cables 40
available internal options 26
avoiding jams 64
avoiding paper jams 161

B

Background and Idle Screen
  using 23
black-and-white printing 68
buttons, printer control panel 17
buttons, touch screen
  using 19

C

cables
  Ethernet 40
  USB 40
canceling
  print job, from computer 74
canceling a print job
  from a computer 74
  from the printer control panel 74
cannot open Embedded Web Server 218
card stock
  loading 52
  tips 61
Change [paper source] to [custom string] 172
Change [paper source] to [custom type name] 172
Change [paper source] to [paper type] [paper size] 172
checking an unresponsive printer 184
checking status of parts and supplies 134
checking the printer status
  using the Embedded Web Server 158
checking the status of parts and supplies 134
checking the virtual display
  using the Embedded Web Server 158
cleaning
  exterior of the printer 134
  interior of the printer 134
cleaning the printer 134
Close door 172
color quality troubleshooting
  color of print and color on computer screen do not match 218
  prints on color transparencies appear dark when projected 217
color quality, troubleshooting
  print appears tinted 218
Complex page, some data may not have printed [39] 173
confidential data
  information on securing 132
confidential jobs
  modifying print settings 159
confidential print jobs 72
  printing from a Macintosh computer 72
  printing from Windows 72
Confidential Print menu 95
Configuration change, some held jobs were not restored [57] 174
configuration information
  wireless network 43
configurations
  printer 14
Configure MP menu 80
configuring
  multiple printers 160
  supply notifications, imaging kit 159
  supply notifications, maintenance kit 159
  supply notifications, toner cartridge 159
  supply notifications, waste toner bottle 159
configuring supply notifications from the Embedded Web Server 159
connecting to a wireless network
  using PIN (Personal Identification Number) method 45
  using Push Button Configuration method 45

using the Embedded Web Server 46
using wireless setup wizard 44
conservation settings
brightness, adjusting 127
conserving supplies 123
Eco-Mode 124
Hibernate Mode 126
Hibernate Timeout 126
Quiet Mode 124
Schedule Power Modes 127
Sleep Mode 125
conserving supplies 123
contacting customer support 220
control panel, printer
indicator light 17
Sleep button light 17
controller board
accessing 26
creating custom name
paper type 56
Custom Names menu 85
custom paper type name
assigning 57
Custom Type [x]
creating custom name 56
Custom Types menu 85
customer support
contacting 220

D

Default Source menu 77
Defective flash detected [51] 174
developer unit
replacing 140, 150
device and network settings information
erasing 131
directory list
printing 73
disk wiping 132
Disk Wiping menu 96
display troubleshooting
printer display is blank 186
display, printer control panel 17
adjusting brightness 127
disposing of printer hard disk 130
documents, printing
from Macintosh 68
from Windows 68

E

Eco-Mode setting 124
Eco-Settings
about 24
embedded solutions information
erasing 131
Embedded Web Server 159
accessing 15, 22
administrator settings 158
checking printer status 158
checking the status of parts 134
checking the status of supplies 134
copying settings to other printers 160
functions 15
modifying confidential print settings 159
networking settings 158
problem accessing 218
using 15
Embedded Web Server Administrator's Guide
where to find 132, 158
emission notices 223, 227, 228, 229
encrypting the printer hard disk 133
envelopes
loading 52, 54
tips on using 60
environmental settings
conserving supplies 123
display brightness, adjusting 127
Eco-Mode 124
Hibernate Mode 126
Hibernate Timeout 126
Quiet Mode 124
Schedule Power Modes 127
Sleep Mode 125
erasing hard disk memory 132
erasing non-volatile memory 131
erasing volatile memory 131
Error reading USB drive. Remove USB. 174
Error reading USB hub. Remove hub. 174
Ethernet network
preparing to set up for Ethernet printing 41
Ethernet network setup
using Macintosh 42
using Windows 42
Ethernet networking
Macintosh 42
Windows 42
Ethernet port 40
Ethernet setup
preparing for an 41
exporting a configuration
using the Embedded Web Server 24
exterior of the printer
cleaning 134

F

factory defaults
restoring 160
FAQ about color printing 215
FCC notices 223, 228
finding more information about the printer 12
Finishing menu 110
firmware card 26
flash drive
printing from 70
Flash Drive menu 108
flash drives
supported file types 71
font sample list
printing 73
Forms and Favorites
setting up 23

G

General Settings menu 100
green settings
Eco-Mode 124
Hibernate Mode 126
Hibernate Timeout 126
Quiet Mode 124
Schedule Power Modes 127

H

held jobs 72
printing from a Macintosh computer 72
printing from Windows 72
Help menu 122
Hibernate Mode
using 126
Hibernate Timeout
setting 126

hiding icons on the home screen 22
Home button 17
home screen
buttons, understanding 18
customizing 22
hiding icons 22
showing icons 22
home screen applications
configuring 22
finding information 22
home screen buttons
understanding 18
HTML menu 120

I

icons on the home screen
hiding 22
showing 22
Image menu 121
imaging kit
replacing 140
imaging kits
ordering 136
importing a configuration
using the Embedded Web Server 24
Incompatible tray [x] [59] 174
Incorrect paper size, open [paper source] [34] 174
indicator light 17
individual settings information
erasing 131
Insert Tray [x] 175
installing an optional card 31
installing options
order of installation 36
installing printer hard disk 32
installing printer on a network
Ethernet networking 42
installing printer software
adding options 39
installing printer software (Windows) 39
Insufficient memory for Flash Memory Defragment operation [37] 175
Insufficient memory to collate job [37] 175
Insufficient memory to support Resource Save feature [35] 175
Insufficient memory, some Held Jobs were deleted [37] 175
Insufficient memory, some held jobs will not be restored [37] 175
interior of the printer
cleaning 134
internal options 26
IP address of computer
finding 21
IPv6 menu 90

J

jams
avoiding 161
locating doors and trays 162
locations 162
messages 162
jams, clearing
in fuser area 164
in manual feeder 169
in multipurpose feeder 169
in standard bin 163
Tray 1 168
Tray 2 168
Job Accounting menu 115

K

keypad 17

L

labels, paper
tips 60
letterhead
loading, multipurpose feeder 58
loading, trays 58
linking trays 56, 57
Load [paper source] with [custom string] 176
Load [paper source] with [custom type name] 176
Load [paper source] with [paper size] 176
Load [paper source] with [paper type] [paper size] 176
Load Manual Feeder with [custom string] 177
Load Manual Feeder with [custom type name] 177
Load Manual Feeder with [paper size] 177
Load Manual Feeder with [paper type] [paper size] 177
loading
250-sheet tray 48
550-sheet tray 48
650-sheet duo tray 48
card stock 52
envelopes 52, 54
manual feeder 54
multipurpose feeder 52
transparencies 52
loading letterhead
paper orientation 58
lock, security 130

M

Maintenance kit low [80.xy] 177
Maintenance kit nearly low [80.xy] 178
Maintenance kit very low [80.xy] 178
manual feeder
loading 54
Max Speed and Max Yield
using 69
memory
types installed on printer 130
memory card 26
installing 29
troubleshooting 186
Memory full [38] 178
menu settings
loading on multiple printers 160
menu settings page
printing 46
menus
Active NIC 87
AppleTalk 92
Confidential Print 95
Configure MP 80
Custom Names 85
Custom Types 85
Default Source 77
Disk Wiping 96
Finishing 110
Flash Drive 108
General Settings 100
Help 122
HTML 120
Image 121
IPv6 90
Job Accounting 115
list 75
Miscellaneous 95

Network [x] 87
Network Card 89
Network Reports 88
Paper Loading 84
Paper Size/Type 77
Paper Texture 80
Paper Weight 82
PCL Emul 118
PDF 117
PostScript 117
Quality 112
Reports 86
Security Audit Log 97
Set Date/Time 97
Setup 98
SMTP Setup menu 94
Standard Network 87
Standard USB 92
Substitute Size 80
Supplies 76
TCP/IP 89
Universal Setup 85
Utilities 116
Wireless 91
XPS 117
menus list 75
Miscellaneous menu 95
mobile device
printing from 71
moving the printer 13, 157
multipurpose feeder
loading 52

N

Network [x] menu 87
Network [x] software error [54] 178
Network Card menu 89
Network Reports menu 88
network settings
Embedded Web Server 158
network setup page
printing 47
Networking Guide
where to find 158
noise emission levels 223
Non-Lexmark [color] [supply type], see User's Guide [33.xy] 178
non-volatile memory 130
erasing 131
Not enough free space in flash memory for resources [52] 178
notices 222, 223, 224, 225, 226, 227, 228, 229, 230
number of remaining pages
estimate 135

O

optional card
installing 31
options
550-sheet tray 36
650-sheet duo tray 36
firmware cards 26
memory card 29
memory cards 26
printer hard disk, installing 32
printer hard disk, removing 34
updating in printer driver 39
ordering
imaging kits 136
toner cartridges 135
waste toner bottle 136

P

paper
characteristics 61
letterhead 63
preprinted forms 63
recycled 63
selecting 62
storing 64
unacceptable 62
Universal size setting 48
using recycled 123
paper feed troubleshooting
message remains after jam is cleared 189
paper jams
avoiding 161
paper jams, clearing
[x]-page jam, open front door to clear fuser. 164
[x]-page jam, open front door. 165
[x]-page jam, open front door to clear duplex. 166
in fuser area 164
in manual feeder 169
in multipurpose feeder 169
in standard bin 163
Tray 1 168
Tray 2 168
Paper Loading menu 84
paper size
setting 48
Paper Size/Type menu 77
paper sizes
supported by the printer 64
Paper Texture menu 80
paper type
setting 48
paper types
supported by printer 66
where to load 66
Paper Weight menu 82
paper weights
supported by printer 66
parts
checking status 134
checking, on the printer control panel 134
checking, using the Embedded Web Server 134
using genuine Lexmark 135
PCL Emul menu 118
PDF menu 117
Personal Identification Number method
using 45
PostScript menu 117
power cord socket 40
PPDS font error [50] 179
preparing to set up the printer on an Ethernet network 41
print irregularities 203
print job
canceling, from computer 74
print quality
replacing a developer unit 150
replacing imaging kit 140
replacing the waste toner bottle 137
print quality troubleshooting
blank pages 206
characters have jagged edges 198
clipped pages or images 198
gray background on prints 199
horizontal voids appear on prints 200
print irregularities 203
print is too dark 204
print is too light 205
printer is printing solid black pages 207

repeating print defects 195
shadow images appear on prints 208
skewed print 208
streaked horizontal lines appear on prints 209
streaked vertical lines appear on prints 210
toner fog or background shading appears on prints 212
toner rubs off 213
toner specks appear on prints 213
transparency print quality is poor 212
uneven print density 213
vertical voids appear on prints 214
print troubleshooting
error reading flash drive 192
incorrect characters print 191
incorrect margins on prints 201
jammed pages are not reprinted 188
job prints from wrong tray 191
job prints on wrong paper 191
jobs do not print 193
Large jobs do not collate 192
multiple-language PDF files do not print 197
paper curl 202
paper frequently jams 189
print job takes longer than expected 194
printing slows down 193
tray linking does not work 196
unexpected page breaks occur 197
printer
configurations 14
minimum clearances 13
models 14
moving 13, 157
selecting a location 13
shipping 157
printer control panel
factory defaults, restoring 160
indicator light 17
parts 17
Sleep button light 17
using 17
printer control panel, virtual display
using the Embedded Web Server 158
printer hard disk
disposing of 130
encrypting 133
installing 32
removing 34
wiping 132
printer hard disk encryption 133
printer hard disk memory
erasing 132
printer information
where to find 12
printer is printing blank pages 206
printer messages
[Color] cartridge low [88.xy] 173
[Color] cartridge very low, [x] estimated pages remain [88.xy] 173
[Type] imaging kit low [84.xy] 173
[Type] imaging kit nearly low [84.xy] 173
[Type] imaging kit very low, [x] estimated pages remain [84.xy] 173
[x]-page jam, clear manual feeder. 169
[x]-page jam, clear multipurpose feeder 169
[x]-page jam, clear standard bin. 163
[x]-page jam, open tray [x]. 168
Adjusting color 172
Change [paper source] to [custom string] 172
Change [paper source] to [custom type name] 172
Change [paper source] to [paper type] [paper size] 172
Close door 172
Complex page, some data may not have printed [39] 173
Configuration change, some held jobs were not restored [57] 174
Defective flash detected [51] 174
Error reading USB drive. Remove USB. 174
Error reading USB hub. Remove hub. 174
Incompatible tray [x] [59] 174
Incorrect paper size, open [paper source] [34] 174
Insert Tray [x] 175
Insufficient memory for Flash Memory Defragment operation [37] 175
Insufficient memory to collate job [37] 175
Insufficient memory to support Resource Save feature [35] 175
Insufficient memory, some Held Jobs were deleted [37] 175
Insufficient memory, some held jobs will not be restored [37] 175
Load [paper source] with [custom string] 176
Load [paper source] with [custom type name] 176
Load [paper source] with [paper size] 176
Load [paper source] with [paper type] [paper size] 176
Load Manual Feeder with [custom string] 177
Load Manual Feeder with [custom type name] 177
Load Manual Feeder with [paper size] 177
Load Manual Feeder with [paper type] [paper size] 177
Maintenance kit low [80.xy] 177
Maintenance kit nearly low [80.xy] 178
Maintenance kit very low [80.xy] 178
Memory full [38] 178
Network [x] software error [54] 178
Non-Lexmark [color] [supply type], see User's Guide [33.xy] 178
Not enough free space in flash memory for resources [52] 178
PPDS font error [50] 179
Reinstall missing or unresponsive [color] cartridge [31.xy] 179
Reload printed pages in Tray [x] 180
Remove packaging material, [area name] 180
Remove paper from standard output bin 180

Replace [color] cartridge, 0 estimated pages remain [88.xy] 180
Replace [color] cartridge, printer region mismatch [42.xy] 180
Replace [type] imaging kit, 0 estimated pages remain [84.xy] 180
Replace defective [color] cartridge [31.xy] 181
Replace defective [type] imaging kit [31.xy] 181
Replace maintenance kit, 0 estimated pages remain [80.xy] 181
Replace missing [color] cartridge [31.xy] 181
Replace missing [type] imaging kit [31.xy] 181
Replace missing or unresponsive [type] imaging kit [31.xy] 179
Replace missing waste toner bottle [82.xy] 182
Replace unsupported [color] cartridge [32.xy] 181
Replace unsupported [type] imaging kit [32.xy] 182
Replace waste toner bottle [82.xy] 181
Restore held jobs? 182
SMTP server not set up. Contact system administrator. 182, 184
Some held jobs were not restored 182
Standard network software error [54] 182
Standard USB port disabled [56] 182
Supply needed to complete job 183
Too many flash options installed [58] 183
Too many trays attached [58] 183
Unformatted flash detected [53] 183
Unsupported USB hub, please remove 174
Waste toner bottle nearly full [82.xy] 184
printer options troubleshooting
internal option is not detected 186
memory card 186
tray problems 187
printer problems, solving basic 184
printer security
information on 132
printer software, installing (Windows) 39
printer status
checking, using the Embedded Web Server 158
printing
black-and-white 68
canceling, from the printer control panel 74
directory list 73
font sample list 73
forms 68
from a mobile device 71
from flash drive 70
from Macintosh 68
from Windows 68
Max Speed and Max Yield 69
menu settings page 46
network setup page 47
printing a directory list 73
printing a document 68
printing a font sample list 73
printing a menu settings page 46
printing a network setup page 47
printing confidential and other held jobs
from a Macintosh computer 72
from Windows 72
printing forms 68
printing from a flash drive 70
printing from a mobile device 71
printing in black and white 68
publications
where to find 12
Push Button Configuration method
using 45

Q

Quality menu 112
Quiet Mode 124

R

recycled paper
using 63, 123
recycling
Lexmark packaging 128
Lexmark products 128
toner cartridges 128
reducing noise 124
Reinstall missing or unresponsive [color] cartridge [31.xy] 179
Reload printed pages in Tray [x] 180
remaining pages, number of
estimate 135
Remove packaging material, [area name] 180
Remove paper from standard output bin 180
removing printer hard disk 34
repeat print jobs 72
printing from a Macintosh computer 72
printing from Windows 72
repeating print defects 195
Replace [color] cartridge, 0 estimated pages remain [88.xy] 180
Replace [color] cartridge, printer region mismatch [42.xy] 180
Replace [type] imaging kit, 0 estimated pages remain [84.xy] 180
Replace defective [color] cartridge [31.xy] 181
Replace defective [type] imaging kit [31.xy] 181
Replace maintenance kit, 0 estimated pages remain [80.xy] 181
Replace missing [color] cartridge [31.xy] 181
Replace missing [type] imaging kit [31.xy] 181
Replace missing or unresponsive [type] imaging kit [31.xy] 179
Replace missing waste toner bottle [82.xy] 182
Replace unsupported [color] cartridge [32.xy] 181
Replace unsupported [type] imaging kit [32.xy] 182
Replace waste toner bottle [82.xy] 181
reports
viewing 158
Reports menu 86

reserve print jobs
printing from a Macintosh computer 72
printing from Windows 72
Restore held jobs? 182
restoring factory default settings 160

S

safety information 10, 11
Schedule Power Modes
using 127
security
modifying confidential print settings 159
Security Audit Log menu 97
security lock 130
security lock port 40
security settings information
erasing 131
security Web page
where to find 132
selecting a location for the printer 13
selecting paper 62
Set Date/Time menu 97
setting
paper size 48
paper type 48
TCP/IP address 89
setting Hibernate Timeout 126
setting the Universal paper size 48
setting up the printer
on an Ethernet network (Macintosh only) 42
on an Ethernet network (Windows only) 42
Setup menu 98
shipping the printer 157
showing icons on the home screen 22
Sleep button 17
Sleep Mode
adjusting 125
SMTP server not set up. Contact system administrator. 182, 184
SMTP Setup menu 94
Some held jobs were not restored 182
Standard Network menu 87
Standard network software error [54] 182
standard tray
loading 48
Standard USB menu 92
Standard USB port disabled [56] 182
statement of volatility 130
status of parts
checking 134
status of supplies
checking 134
Stop or Cancel button 17
storing
paper 64
supplies 136
storing print jobs 72
streaked horizontal lines appear on prints 209
streaked vertical lines appear on prints 210
Substitute Size menu 80
supplies
checking status 134
checking, on the printer control panel 134
checking, using the Embedded Web Server 134, 158
conserving 123
storing 136
using genuine Lexmark 135
using recycled paper 123
Supplies menu 76
supplies, ordering
imaging kits 136
toner cartridges 135
waste toner bottle 136
Supply needed to complete job 183
supply notifications
configuring 159
supported flash drives 71

T

TCP/IP menu 89
tips
card stock 61
labels, paper 60
on using envelopes 60
on using letterhead 58
transparencies 60
tips on using envelopes 60
tips on using letterhead 58
toner cartridges
ordering 135
recycling 128
replacing 148
toner darkness
adjusting 69
Too many flash options installed [58] 183
Too many trays attached [58] 183
touch screen
buttons, using 19
transparencies
loading 52
tips on using 60
trays
linking 56, 57
unlinking 56, 57
troubleshooting
an application error has occurred 190
cannot open Embedded Web Server 218
checking an unresponsive printer 184
contacting customer support 220
FAQ about color printing 215
solving basic printer problems 184
troubleshooting, color quality
color of print and color on computer screen do not match 218
print appears tinted 218
prints on color transparencies appear dark when projected 217
troubleshooting, display
printer display is blank 186
troubleshooting, paper feed
message remains after jam is cleared 189
troubleshooting, print
error reading flash drive 192
incorrect characters print 191
incorrect margins on prints 201
jammed pages are not reprinted 188
job prints from wrong tray 191
job prints on wrong paper 191
jobs do not print 193
Large jobs do not collate 192
multiple-language PDF files do not print 197
paper curl 202
paper frequently jams 189

print job takes longer than expected 194
printing slows down 193
tray linking does not work 196
unexpected page breaks occur 197
troubleshooting, print quality
blank pages 206
characters have jagged edges 198
clipped pages or images 198
gray background on prints 199
horizontal voids appear on prints 200
print irregularities 203
print is too dark 204
print is too light 205
printer is printing solid black pages 207
repeating print defects 195
shadow images appear on prints 208
skewed print 208
streaked horizontal lines appear on prints 209
streaked vertical lines appear on prints 210
toner fog or background shading appears on prints 212
toner rubs off 213
toner specks appear on prints 213
transparency print quality is poor 212
uneven print density 213
vertical voids appear on prints 214
troubleshooting, printer options
internal option is not detected 186
memory card 186
tray problems 187

U

understanding the home screen 18
uneven print density 213
Unformatted flash detected [53] 183
Universal Paper Size setting 48
Universal Setup menu 85
unlinking trays 56, 57
Unsupported USB hub, please remove 174
updating options in printer driver 39
USB port 17, 40
using Forms and Favorites 68
using Hibernate Mode 126
using Max Speed and Max Yield 69
using recycled paper 123
using Schedule Power Modes 127
using the Embedded Web Server 15
using the printer control panel 17
using the touch-screen buttons 19
Utilities menu 116

V

verify print jobs 72
printing from a Macintosh computer 72
printing from Windows 72
vertical voids appear on prints 214
viewing
reports 158
virtual display
checking, using Embedded Web Server 158
volatile memory 130
erasing 131
volatility
statement of 130

W

waste toner bottle
ordering 136
replacing 137
Waste toner bottle nearly full [82.xy] 184
wiping the printer hard disk 132
Wireless menu 91
wireless network
configuration information 43
wireless network setup
using the Embedded Web Server 46
wireless setup wizard
using 44

X

XPS menu 117